

V1.2-2026-04-29

Residential All-In-One Energy Storage System

ESA 5-30kW

GW5.1-BAT-D-G20

GW8.3-BAT-D-G20

GW5.1-BAT-D-G21

GW8.3-BAT-D-G21

GW6.0-BAT-D-G20

GW9.0-BAT-D-G20

Solutions Manual

GOODWE

Copyright Statement

Copyright Statement

Copyright© GoodWe Technologies Co., Ltd. 2026. All rights reserved.

Without the authorization of GoodWe Technologies Co., Ltd., no part of this manual may be reproduced, distributed, or uploaded to third-party platforms such as public networks in any form.

Trademark Authorization

GOODWE and other GOODWE trademarks used in this manual are owned by GoodWe Technologies Co., Ltd. All other trademarks or registered trademarks mentioned in this manual belong to their respective owners.

NOTICE

Due to product version upgrades or other reasons, the content of this document is updated periodically. Unless otherwise agreed, the content of this document cannot replace the safety precautions on the product label. All descriptions in the document are for guidance only.

About This Manual

Overview

This document primarily introduces the product information, installation wiring, configuration and commissioning, troubleshooting, and maintenance content for the energy storage system composed of inverters, Battery system, and smart meters. Please read this manual carefully before installing and using the product to understand the product safety information and familiarize yourself with the product's functions and features. The document may be updated periodically; please obtain the latest version of the materials and more product information from the official website.

Applicable Model

The energy storage system includes the following products:

| Product Type | Product Information | Description |
|----------------|--|--------------------------------|
| Inverter | GW5K-ETA-G20 GW6K-ETA-G20 GW8K-ETA-G20 GW9.999K-ETA-G20 GW10K-ETA-G20 GW12K-ETA-G20 GW15K-ETA-G20 GW20K-ETA-G20 GW25K-ETA-G20 GW29.999K-ETA-G20 GW30K-ETA-G20 GW5K-BTA-G20 GW6K-BTA-G20 GW8K-BTA-G20 GW9.999K-BTA-G20 GW10K-BTA-G20 GW12K-BTA-G20 GW15K-BTA-G20 GW20K-BTA-G20 GW25K-BTA-G20 GW29.999K-BTA-G20 GW30K-BTA-G20 | Nominal output power: 5kW-30kW |
| Battery system | GW5.1-BAT-D-G20 GW5.1-BAT-D-G21 | Rated energy 5.12kWh |
| | GW8.3-BAT-D-G20 GW8.3-BAT-D-G21 | Rated energy 8.32kWh |
| | GW6.0-BAT-D-G20 | Rated energy 6kWh |

| Product Type | Product Information | Description |
|--------------|---------------------|---|
| | GW9.0-BAT-D-G20 | Rated energy 9kWh |
| Meter | GMK330 GM330 | Monitoring module in the energy storage system, capable of detecting operational voltage, current, and other information within the system. |
| smart dongle | WiFi/LAN Kit-20 | Uploads system operational information to the monitoring platform via WiFi or LAN signals. |
| | 4G Kit-G20 | Uploads system operational information to the monitoring platform via 4G. |

Symbol Definition

| |
|--|
|  DANGER |
| Indicates a highly potential danger that, if not avoided, will result in death or serious injury. |
|  WARNING |
| Indicates a moderately potential danger that, if not avoided, may result in death or serious injury. |
|  CAUTION |
| Indicates a low potential danger that, if not avoided, may result in moderate or minor injury. |
| NOTICE |
| Emphasizes and supplements the content, and may also provide tips or tricks for optimizing product use, helping you solve a problem or save your time. |

Table of Contents

| | |
|---|----|
| 1 Safety Precautions | 10 |
| 1.1 General Safety | 10 |
| 1.2 personnel requirements | 11 |
| 1.3 System Safety | 12 |
| 1.3.1 PV String Safety | 14 |
| 1.3.2 Inverter Safety | 15 |
| 1.3.3 Battery Safety | 16 |
| 1.3.4 Smart Meter Safety | 19 |
| 1.4 Safety Symbols and Certification Marks | 19 |
| 1.5 EU Declaration of Conformity | 21 |
| 1.5.1 Equipment with Wireless Communication Modules | 21 |
| 1.5.2 Equipment without Wireless Communication Modules (Except Battery) | 21 |
| 1.5.3 Battery | 22 |
| 2 System Introduction | 23 |
| 2.1 System Overview | 23 |
| 2.2 Product Overview | 39 |
| 2.2.1 Residential All-in-One System | 39 |
| 2.2.2 Smart Meter | 46 |
| 2.2.3 smart dongle | 47 |
| 2.3 Supported Grid Types | 48 |
| 2.4 System Working Mode | 48 |

| | |
|---|----|
| 2.5 Features | 58 |
| 3 Check and Storage | 62 |
| 3.1 Check Before Receiving | 62 |
| 3.2 deliverables | 62 |
| 3.2.1 Inverter Deliverables | 62 |
| 3.2.2 Batteries Deliverables | 66 |
| 3.2.2.1 Expansion Cluster Base Deliverables | 67 |
| 3.2.2.2 Wall-Mount Bracket Deliverables | 69 |
| 3.2.3 Smart Meter Deliverables GM330&GMK330 | 69 |
| 3.2.3.1 Accessory List | 69 |
| 3.3 Storage | 70 |
| 4 Installation | 73 |
| 4.1 Installation Requirements | 73 |
| 4.1.1 Installation Environment Requirements | 73 |
| 4.1.2 Installation Space Requirements | 75 |
| 4.1.3 Tool Requirements | 77 |
| 4.2 Equipment Handling | 79 |
| 4.3 Installing the Equipment | 80 |
| 4.4 Installing the Smart Meter | 85 |
| 5 System Wirings | 87 |
| 5.1 System Wiring Electrical Block Diagram | 88 |
| 5.2 Detailed System Wiring Diagram | 92 |

| | |
|---|-----|
| 5.2.1 Detailed System Wiring Diagram for Single Inverter..... | 96 |
| 5.2.2 Detailed System Wiring Diagram for Parallel System..... | 105 |
| 5.3 Preparing Materials..... | 109 |
| 5.3.1 Preparing Breakers..... | 110 |
| 5.3.2 Preparing Cables..... | 114 |
| 5.4 Connecting the PE cable..... | 117 |
| 5.5 Connecting the PV Cable..... | 118 |
| 5.6 Connecting the Battery Cable..... | 120 |
| 5.7 Connecting the AC Cable..... | 122 |
| 5.8 Connecting the Meter Cable..... | 124 |
| 5.9 Connecting the Inverter Communication Cable..... | 127 |
| 6 System Commissioning..... | 132 |
| 6.1 Check Before Power ON..... | 132 |
| 6.2 Power ON..... | 132 |
| 6.3 Installing the Protective Cover..... | 136 |
| 6.4 Indicators..... | 136 |
| 6.4.1 Inverter Indicators..... | 136 |
| 6.4.2 Battery Indicators..... | 139 |
| 6.4.3 Smart Meter Indicators GM330&GMK330..... | 140 |
| 6.4.3.1 Indicator Description..... | 140 |
| 6.4.4 Smart Dongle Indicator..... | 141 |
| 7 System Commissioning..... | 143 |

| | |
|--|-----|
| 7.1 Setting Inverter Parameters via App | 143 |
| 7.1.1 Downloading and Installing SEMS+ App | 143 |
| 7.2 Monitoring Power Station via SEMS+ WEB | 144 |
| 8 Maintenance | 145 |
| 8.1 Power OFF the System | 145 |
| 8.2 Removing the Equipment | 147 |
| 8.3 Disposing of the Equipment | 148 |
| 8.4 Routine Maintenance | 148 |
| 8.5 fault | 151 |
| 8.5.1 Viewing Fault/Alarms Information | 151 |
| 8.5.2 Fault Information and Troubleshooting | 152 |
| 8.5.2.1 Inverter Fault | 153 |
| 8.5.2.1.1 Troubleshooting (Fault Code F01-F40) | 153 |
| 8.5.2.1.2 Troubleshooting (Fault Code F41-F80) | 171 |
| 8.5.2.1.3 Troubleshooting (Fault Code F81-F121) | 180 |
| 8.5.2.1.4 Troubleshooting (Fault Code F122-F163) | 192 |
| 8.5.2.1.5 Troubleshooting Fault Phenomena | 201 |
| 8.5.2.2 Battery Fault | 219 |
| 9 technical parameter | 240 |
| 9.1 Inverter Parameters | 240 |
| 9.2 Battery Technical Data | 293 |
| 9.3 Smart Meter Technical Data | 297 |

| | |
|--|-----|
| 9.3.1 GM330 | 297 |
| 9.3.2 GMK330 | 299 |
| 9.4 Smart Dongle Technical Data | 300 |
| 9.4.1 WiFi/LAN Kit-20 | 300 |
| 9.4.2 4G Kit-G20 | 301 |
| 10 Appendix | 303 |
| 10.1 FAQ | 303 |
| 10.1.1 How to conduct auxiliary detection for smart meters/CT? | 303 |
| 10.1.2 How to Upgrade the Device Version | 303 |
| 10.2 Explanation of Terms | 304 |
| 10.3 Battery SN Code Meaning | 305 |
| 11 Contact Information | 307 |

1 Safety Precautions

The safety precautions information contained in this document must always be followed when operating the device.

WARNING

The device has been strictly designed and tested in accordance with safety regulations, but as an electrical device, before performing any operations on the device, relevant safety instructions must be followed. Improper operation may lead to serious injury or property damage.

1.1 General Safety

NOTICE

- Due to product version upgrades or other reasons, the document content will be updated periodically. Unless otherwise agreed, the document content cannot replace the safety precautions on product labels. All descriptions in the document are for guidance only.
- Please read this document carefully before installing the device to understand the product and precautions.
- All operations of the device must be performed by professional and qualified electrical technicians who are familiar with the relevant standards and safety regulations at the project location.
- When operating the device, use insulated tools and wear personal protective equipment to ensure personal safety. When handling electronic components, wear anti-static gloves, anti-static wrist straps, anti-static clothing, etc., to protect the device from electrostatic damage.
- Unauthorized disassembly or modification may cause device damage, and such damage is not covered by the warranty.
- Device damage or personal injury caused by not installing, using, or configuring the device according to the requirements of this document or the corresponding user manual is beyond the manufacturer's liability. For more product warranty information, please obtain it through the official website:
<https://en.goodwe.com/warrantyrelated.html>.

1.2 personnel requirements

NOTICE

To ensure safety, compliance, and efficiency throughout the entire process of equipment transportation, Installation, wiring, operation, and maintenance, operations must be performed by qualified personnel.

1. Qualified personnel include:
 - Personnel who have mastered knowledge of equipment working principles, system structure, risks and hazards, and have received professional operation training or possess extensive practical experience.
 - Personnel who have received relevant technical and safety training, possess certain operational experience, are aware of potential dangers specific tasks may pose to themselves, and can take protective measures to minimize risks to themselves and others.
 - Qualified electrical technicians meeting the regulatory requirements of the country/region.
 - Personnel holding a degree in electrical engineering/an advanced diploma in electrical discipline or equivalent/possessing professional qualifications in the electrical field, with at least 2/3/4 years of experience in testing and supervision work using electrical equipment safety standards.
2. Personnel involved in special tasks such as electrical work, work at heights, and special equipment operation must hold valid qualification certificates as required by the equipment's location.
3. Medium-voltage equipment operation must be performed by certified high-voltage electricians.
4. Equipment and component replacement is only permitted to be performed by authorized personnel.

1.3 System Safety



- Before performing electrical connections, disconnect all upstream switches of the device to ensure it is powered off. Working on live circuits is strictly prohibited, as it may lead to hazards such as electric shock.
- To prevent personal injury or equipment damage caused by working on live circuits, a circuit breaker must be added to the voltage input side of the device.
- All operations including transportation, storage, installation, operation, use, and maintenance must comply with applicable laws, regulations, standards, and specifications.
- The specifications of cables and components used for electrical connections must comply with local laws, regulations, standards, and specifications.
- Use the cable connectors provided in the package to connect the device cables. If other models of connectors are used, any resulting equipment damage is not within the manufacturer's liability.
- Ensure all cables of the device are correctly connected, securely fastened, and free from looseness. Improper wiring may cause poor contact or damage the equipment.
- The equipment's protective grounding wire must be firmly connected.
- To protect the equipment and its components from damage during transportation, ensure that transport personnel are professionally trained. Record the operation steps during transportation and keep the equipment balanced to avoid dropping.
- The equipment is heavy. Assign personnel according to the equipment's weight to prevent it from exceeding the human lifting capacity and causing injury from falling.
- Ensure the equipment is placed stably and not tilted. Equipment tipping over may cause equipment damage and personal injury.

 **WARNING**

- During equipment installation, avoid having the terminals bear weight, as this may cause terminal damage.
- If the cable is subjected to excessive tension, it may lead to poor connections. When wiring, leave a certain length of cable slack before connecting it to the equipment's terminal ports.
- Cables of the same type should be bundled together. Different types of cables should be routed at least 30mm apart and must not be intertwined or cross-routed.
- Using cables in high-temperature environments may cause insulation aging and damage. Maintain a distance of at least 30mm between cables and heat-generating components or the periphery of heat source areas.

1.3.1 PV String Safety

WARNING

- Ensure the component frame and mounting system are properly grounded.
- After connecting the DC cables, ensure the cable connections are tight and secure with no looseness. Improper wiring may cause poor contact or high impedance, and damage the inverter.
- Use a multimeter to measure the positive and negative poles of the DC cables to ensure correct polarity, with no reverse connection; and that the voltage is within the permissible range.
- Use a multimeter to measure the DC cables to ensure correct polarity, with no reverse connection; the voltage should be lower than the maximum DC input voltage. Damage caused by reverse connection and overvoltage is not covered by the equipment manufacturer's warranty.
- The PV string output does not support grounding. Before connecting the PV string to the inverter, ensure the minimum insulation resistance to ground of the PV string meets the minimum insulation resistance requirement ($R = \text{Max. Input Voltage (V)} / 30\text{mA}$).
- Do not connect the same PV string to multiple inverters, as this may damage the inverters.
- The PV modules used with the inverter must comply with IEC 61730 Class A standards.
- When the PV string input voltage or input current is high, it may cause the inverter output power to derate.

1.3.2 Inverter Safety

WARNING

- Ensure the voltage and frequency at the grid connection point comply with the inverter's grid-connection specifications.
- It is recommended to install protective devices such as circuit breakers or fuses on the AC side of the inverter. The rating of the protective device must be greater than 1.25 times the maximum AC output current of the inverter.
- If the inverter triggers an arc fault alarm less than 5 times within 24 hours, the alarm can be cleared automatically. After the 5th arc fault alarm, the inverter will shut down for protection. The inverter can resume normal operation only after the fault is cleared.
- If a battery is not configured in the photovoltaic system, it is not recommended to use the BACK-UP function, as it may cause a system power outage risk.
- Grid voltage and frequency fluctuations may cause the inverter output power to derate.

1.3.3 Battery Safety

DANGER

- Before operating any devices in the system, ensure that the devices are powered off to avoid the risk of electric shock. During device operation, strictly adhere to all safety precautions in this manual and the safety labels on the devices.
- Do not disassemble, modify, or repair the battery without official authorization from the device manufacturer. Otherwise, it may cause electric shock or device damage, and any losses incurred are beyond the manufacturer's liability.
- Do not impact, pull, drag, squeeze, or step on the device, and do not place the battery in fire, as the battery may explode.
- Do not place the battery in high-temperature environments. Ensure there are no heat sources near the battery and that it is not exposed to direct sunlight. If the ambient temperature exceeds 60°C, it may cause a fire.
- Do not use the battery if it has obvious defects, cracks, damage, or other conditions. Battery damage may lead to electrolyte leakage.
- Do not move the battery system while it is operating. If battery replacement or addition is needed, contact the after-sales service center.
- Battery short circuits may cause personal injury. The instantaneous high current from a short circuit can release a large amount of energy, which may lead to a fire.
- To protect the battery pack and its components from damage during transportation, ensure that transport personnel are professionally trained. Record the operating steps during transportation and keep the device balanced to avoid dropping.
- The battery device is heavy. Assign personnel according to the device's weight to prevent it from exceeding the weight range that can be manually handled, which could cause injury to personnel.

 **WARNING**

- Battery current may be affected by factors such as temperature, Humidity, weather conditions, etc., which may cause current limiting and affect load capacity.
- If the battery cannot start, contact the after-sales service center as soon as possible. Otherwise, the battery may be permanently damaged.
- Regularly inspect and maintain the battery according to its maintenance requirements.
- Ensure that the battery system is not damaged during transportation and storage. Ensure that the device is placed stably and not tilted, as tipping may cause device damage and personal injury.

Emergency Response Measures

- Battery electrolyte leakage
If a battery module leaks electrolyte, avoid contact with the leaking liquid or gas. Electrolyte is corrosive and contact may cause skin irritation and chemical burns. If accidental contact with the leaked substance occurs, take the following actions:
 - inhalation: Evacuate from the contaminated area and seek medical help immediately.
 - Eye contact: Rinse with clean water for at least 15 minutes and seek medical help immediately.
 - Skin contact: Wash the affected area thoroughly with soap and water and seek medical help immediately.
 - Ingestion: Induce vomiting and seek medical assistance immediately.
- Fire
 - When the battery temperature exceeds 150°C, there is a risk of fire. A battery fire may release toxic and harmful gases.
 - To prevent fire, ensure carbon dioxide or water fire extinguishing equipment is available near the device.
 - When extinguishing a fire, do not use ABC dry powder fire extinguishers. Firefighters must wear protective clothing and self-contained breathing apparatus.
- Battery triggers fire protection
For batteries equipped with optional fire protection functionality, after the fire protection function is triggered, perform the following actions:
 - Immediately cut off the main power switch to ensure no current flows through the battery system.

- Conduct a preliminary visual inspection of the battery for any damage, deformation, leakage, or unusual odor. Check the battery casing, connectors, and cables.
- Use a temperature sensor to detect the battery and its ambient temperature to ensure there is no risk of overheating.
- Isolate and label the damaged battery, and dispose of it properly according to local regulations.

1.3.4 Smart Meter Safety

WARNING

If the grid voltage fluctuation exceeds 265V, long-term overvoltage operation may cause damage to the meter. It is recommended to add a fuse with a rated current of 0.5A on the voltage input side of the meter to protect it.


1.4 Safety Symbols and Certification Marks

DANGER

- After equipment installation, labels and warning signs on the enclosure must remain clearly visible. Do not cover, alter, or damage them.
- The following enclosure warning label descriptions are for reference only. Please refer to the actual labels used on the equipment.

| No. | Symbol | Meaning |
|-----|---|---|
| 1 |  | Potential hazard exists during equipment operation. Please take protective measures when operating the equipment. |
| 2 |  | High voltage hazard. High voltage is present during equipment operation. Please ensure the equipment is powered off before performing any operations. |

| No. | Symbol | Meaning |
|-----|---|--|
| 3 |  | The inverter surface is at high temperature. Do not touch during operation to avoid burns. |
| 4 |  | Use the equipment properly. There is a risk of explosion under extreme conditions. |
| 5 |  | Battery contains flammable materials. Beware of fire. |
| 6 |  | The equipment contains corrosive electrolyte. Avoid contact with leaked electrolyte or volatile gases. |
| 7 |  | Delayed discharge. After powering off the equipment, please wait 5 minutes for it to discharge completely. |
| 8 |  | Keep the equipment away from open flames or ignition sources. |
| 9 |  | Keep the equipment out of reach of children. |
| 10 |  | Do not extinguish with water. |
| 11 |  | Please read the product manual carefully before operating the equipment. |
| 12 |  | Personal protective equipment must be worn during installation, operation, and maintenance. |

| No. | Symbol | Meaning |
|-----|---|--|
| 13 |  | This equipment must not be disposed of as household waste. Please dispose of it according to local laws and regulations, or return it to the manufacturer. |
| 14 |  | Grounding point. |
| 15 |  | Recycling symbol. |
| 16 |  | CE certification mark. |
| 17 |  | TUV mark. |
| 18 |  | RCM mark. |

1.5 EU Declaration of Conformity

1.5.1 Equipment with Wireless Communication Modules

Equipment with wireless communication modules sold in the European market must comply with the following directives:

- Radio Equipment Directive 2014/53/EU (RED)
- Restrictions of Hazardous Substances Directive 2011/65/EU and (EU) 2015/863 (RoHS)
- Waste Electrical and Electronic Equipment 2012/19/EU
- Registration, Evaluation, Authorization and Restriction of Chemicals (EC) No 1907/2006 (REACH)

1.5.2 Equipment without Wireless Communication Modules (Except Battery)

Equipment without wireless communication modules that can be sold in the European market meets the requirements of the following directives:

- Electromagnetic compatibility Directive 2014/30/EU (EMC)
- Electrical Apparatus Low Voltage Directive 2014/35/EU (LVD)
- Restrictions of Hazardous Substances Directive 2011/65/EU and (EU) 2015/863 (RoHS)
- Waste Electrical and Electronic Equipment 2012/19/EU
- Registration, Evaluation, Authorization and Restriction of Chemicals (EC) No 1907/2006 (REACH)

1.5.3 Battery

The Battery sold in the European market complies with the following directives:

- Electromagnetic compatibility Directive 2014/30/EU (EMC)
- Electrical Apparatus Low Voltage Directive 2014/35/EU (LVD)
- Restrictions of Hazardous Substances Directive 2011/65/EU and (EU) 2015/863 (RoHS)*¹
- Regulation (EU) 2023/1542 Article 12 - Safety of stationary battery energy storage systems
- Regulation (EU) 2023/1542 Article 10 - Performance and durability requirements for rechargeable industrial batteries, LMT batteries and electric vehicle batteries
- Regulation (EU) 2023/1542 Article 14 - Information on the state of health and expected lifetime of batteries
- Waste Electrical and Electronic Equipment 2012/19/EU
- Registration, Evaluation, Authorization and Restriction of Chemicals (EC) No 1907/2006 (REACH)

Our Battery products comply with the hazardous substance restriction requirements stipulated by this act.

More EU Declaration of Conformity can be obtained from [Official Website](#) Acquisition.

2 System Introduction

2.1 System Overview

The Household Storage Integrated Unit solution integrates devices such as inverters, batteries, smart meters, and smart communication sticks. In a photovoltaic system, it converts solar energy into electricity to meet household power demands. The energy IoT devices in the system control power-consuming devices by identifying the overall power situation in the system, thereby achieving intelligent management of power for load usage, storage to batteries, or output to the grid, etc.

WARNING

- The energy storage system is not suitable for connecting to devices that rely on stable power supply, such as life-sustaining medical equipment. Please ensure that system power failure will not cause personal injury.
- If the residential storage all-in-one unit is in a high-temperature environment or under BMS current limiting conditions, it may cause the battery charging power to be limited, leading to excessively high system voltage triggering overvoltage protection.
- The inverter only supports GoodWe brand batteries specified in this manual. If no battery is connected, it can only operate in grid-tied mode and must be installed on the base provided with the package.
- In microgrid scenarios, it is recommended that the PV open-circuit voltage of the residential storage all-in-one unit be $< 0.85 * \text{PV maximum input voltage}$ to avoid system overvoltage triggering overvoltage protection under harsh operating conditions.
- In microgrid scenarios, please ensure the over-frequency power reduction point of the grid-tied inverter matches that of the residential storage all-in-one unit.
- If output power limiting is required for the grid-tied inverter, please connect a separate meter or CT device.
- Please ensure the over-frequency power reduction curve of the grid-tied inverter is set as follows:
 - Set the endpoint power to 0% P_n
 - Set the response delay time to 0, and disable the hysteresis function
- In a system where the inverter operates completely off-grid, if the battery

WARNING

experiences prolonged periods of low sunlight or rainy weather without timely recharging, it may lead to over-discharge, causing battery performance degradation or damage. To ensure long-term stable system operation, avoid completely draining the battery. Recommended measures are as follows:

- When operating off-grid, set a minimum SOC protection threshold. It is recommended to set the off-grid battery SOC lower limit to 30%.
- When the SOC approaches the protection threshold, the system will automatically enter load limiting or protection mode.
- If there are multiple consecutive days of insufficient sunlight and the battery SOC is too low, promptly replenish the battery using an external energy source (such as a generator or grid-assisted charging).
- Regularly check the battery status to ensure it remains within a safe operating range.
- It is recommended to perform a full charge and discharge cycle on the battery every six months to calibrate SOC accuracy.
- Due to product version upgrades or other reasons, document content is updated periodically. For the compatibility relationship between inverters and IoT products, please refer to:
https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW_Compatibility-list-of-GoodWe-inverters-and-IoT-products-EN.pdf
- For detailed networking and wiring schemes for each scenario, please refer to:
[5.2.Detailed System Wiring Diagram\(Page 92\)](#).

When the energy storage system is in off-grid state, it can normally supply the following loads:

BACK-UP Port Off-Grid Load Capacity Specification


| | | | | |
|---|--|--|----------------------|------------------|
| Inverter Model | GW5K-ETA-G20 GW6K-ETA-G20 GW8K-ETA-G20 GW9.999K-ETA-G20 GW10K-ETA-G20 GW12K-ETA-G20 GW15K-ETA-G20 GW20K-ETA-G20 GW5K-BTA-G20 GW6K-BTA-G20 GW8K-BTA-G20 GW9.999K-BTA-G20 GW10K-BTA-G20 GW12K-BTA-G20 GW15K-BTA-G20 GW20K-BTA-G20 | GW25K-ETA-G20 GW29.999K-ETA-G20 GW30K-ETA-G20 GW25K-BTA-G20 GW29.999K-BTA-G20 GW30K-BTA-G20 | | |
| Load Type | Single-Phase | Three-Phase | Single-Phase | Three-Phase |
| Single Inductive Load Rated Power (kVA) | 1.1 | 3.3 | 2.2 | 6.6 |
| Total Rated Power of Multiple Inductive Loads (kVA) | $0.4 \cdot P_n / 3$ | $0.4 \cdot P_n$ | $0.4 \cdot P_n / 3$ | $0.4 \cdot P_n$ |
| Capacitive Load (kVA) | $0.33 \cdot P_n / 3$ | $0.33 \cdot P_n$ | $0.33 \cdot P_n / 3$ | $0.33 \cdot P_n$ |
| Half-Wave Load (kW) | 2 | - | 3 | - |

BACK-UP Port Off-Grid Load Capacity Specification

Note:

- P_n : Inverter rated output power.
- Half-wave load: Some old or non-EMC compliant household appliances (e.g., hair dryers, small heaters using half-wave rectification).
- If the total power of multiple inductive loads calculated based on the rated power is less than the rated power of a single inductive load, then Total Rated Power of Multiple Inductive Loads = Single Inductive Load Rated Power.
- If inductive loads are to be used, it is recommended to use them with a frequency converter.
- For 2 or more units in parallel, the allowed total inductive load rated power = Single Inductive Load Rated Power * Number of Parallel Units * 80%.

General Scenario



| Device Type | model | Description |
|-----------------|--|---|
| hybrid inverter | GW5K-ETA-G20 GW6K-ETA-G20 GW8K-ETA-G20 GW9.999K-ETA-G20 GW10K-ETA-G20 GW12K-ETA-G20 GW15K-ETA-G20 GW20K-ETA-G20 GW25K-ETA-G20 GW29.999K-ETA-G20 GW30K-ETA-G20 GW5K-BTA-G20 GW6K-BTA-G20 GW8K-BTA-G20 GW9.999K-BTA-G20 GW10K-BTA-G20 GW12K-BTA-G20 GW15K-BTA-G20 GW20K-BTA-G20 GW25K-BTA-G20 GW29.999K-BTA-G20 GW30K-BTA-G20 | <ul style="list-style-type: none"> • Connection to GoodWe AC charging piles is only supported in single-unit scenarios. • The system supports a maximum of 10 inverters to form a parallel system, supporting hybrid on-grid/off-grid parallel connection of inverters with different power ratings. When mixing, it is recommended to use a high-power inverter as the master unit. Microgrid functionality is not supported in parallel systems. • Supports generator control and generator charging of the battery. If connecting a generator, please use the GMK330 or GM330 Smart Meter. • In a parallel system, each inverter requires the installation of a WiFi/LAN Kit-20. • The following version requirements must be met for system networking: <ul style="list-style-type: none"> ◦ Inverter ARM software version must be 03.138 or higher. ◦ Inverter DSP software version must be 01.1025 or higher. |


| Device Type | model | Description |
|----------------|--|--|
| Battery system | GW5.1-BAT-D-G20 GW5.1-BAT-D-G21 GW8.3-BAT-D-G20 GW8.3-BAT-D-G21 GW6.0-BAT-D-G20 GW9.0-BAT-D-G20 | <ul style="list-style-type: none"> • Different models of battery modules can be mixed. • The system supports 5-108kWh, meeting various power and energy matching requirements. • Battery heating film is optional. The "Battery Heating" function can only be enabled on models configured with the heating film. Batteries without the heating film should not be used in low-temperature environments, as this may prevent the device from operating. • The battery heating function is unavailable when GW5.1-BAT-D-G20, GW8.3-BAT-D-G20, GW5.1-BAT-D-G21, GW8.3-BAT-D-G21, GW6.0-BAT-D-G20, GW9.0-BAT-D-G20 are mixed. • If the system requires mixed battery use or split-type capacity expansion, ensure the BMS software version is V06 or higher and the DCDC version is V05 or higher. |
| Smart Meter | Inverter Built-in Meter GMK330 (purchased from GoodWe) | |

| Device Type | model | Description |
|--------------|-------------------------------|---|
| | GM330 (purchased from GoodWe) | <ul style="list-style-type: none"> • Built-in Meter: Please use the CT shipped with the inverter for connection. <ul style="list-style-type: none"> ◦ CT ratio is 120A:40mA. ◦ If the inverter's built-in meter is insufficient, contact your dealer to purchase a GMK330 or GM330 Smart Meter. • GMK330: CT cannot be replaced; CT ratio is 120A:40mA • GM330: CT can be purchased from GoodWe or separately; CT ratio requirement: nA/5A <ul style="list-style-type: none"> ◦ nA: CT primary side input current, where n ranges from 200 to 5000 ◦ 5A: CT secondary side output current • If the number of parallel inverters exceeds 2, or if the wire gauge or range of the standard CT does not meet the total current requirement of the on-site parallel system, please use the GM330 Smart Meter. |
| Smart dongle | WiFi/LAN Kit-20 | <ul style="list-style-type: none"> • Suitable for single inverter and parallel inverter system networking scenarios. • Uses Bluetooth signal for local configuration of device parameters and viewing device operation information; uploads system operation information to the monitoring platform via WiFi or LAN. • Please ensure the Smart dongle firmware version is 07 or higher. |

| Device Type | model | Description |
|-------------|------------|---|
| | 4G Kit-G20 | <ul style="list-style-type: none"> • Suitable for single inverter system networking scenarios. • Uses Bluetooth signal for local configuration of device parameters and viewing device operation information; uploads system operation information to the monitoring platform via 4G. |

Microgrid Scenario

When the grid-tied inverter is connected to the hybrid inverter's BACK-UP port, it is a microgrid scenario.



| Device Type | model | Description |
|-----------------|--|--|
| hybrid inverter | GW5K-ETA-G20 GW6K-ETA-G20 GW8K-ETA-G20 GW9.999K-ETA-G20 GW10K-ETA-G20 GW12K-ETA-G20 GW15K-ETA-G20 GW20K-ETA-G20 GW25K-ETA-G20 GW29.999K-ETA-G20 GW30K-ETA-G20 GW5K-BTA-G20 GW6K-BTA-G20 GW8K-BTA-G20 GW9.999K-BTA-G20 GW10K-BTA-G20 GW12K-BTA-G20 GW15K-BTA-G20 GW20K-BTA-G20 GW25K-BTA-G20 GW29.999K-BTA-G20 GW30K-BTA-G20 | <ul style="list-style-type: none"> • In a microgrid scenario, only one hybrid inverter is supported in the system. • In a microgrid scenario, connecting a generator is not supported. |

| Device Type | model | Description |
|----------------|--|--|
| Battery system | GW5.1-BAT-D-G20 GW5.1-BAT-D-G21 GW8.3-BAT-D-G20 GW8.3-BAT-D-G21 GW6.0-BAT-D-G20 GW9.0-BAT-D-G20 | <ul style="list-style-type: none"> • Different models of battery modules can be mixed and used. • The system supports 5-108kWh, meeting usage with different power and energy matching requirements. • The battery heating film is optional. The "Battery Heating" function can only be enabled for models configured with the heating film. Batteries without the heating film should not be used in low-temperature environments, as this may prevent the device from operating. • When GW5.1-BAT-D-G20, GW8.3-BAT-D-G20, GW5.1-BAT-D-G21, GW8.3-BAT-D-G21, GW6.0-BAT-D-G20 , GW9.0-BAT-D-G20 are mixed, the battery heating function is unavailable. • If the system requires mixed battery use or split-type expansion, ensure the BMS software version is V06 or above and the DCDC version is V05 or above. |
| Smart Meter | Inverter Built-in Meter | <ul style="list-style-type: none"> • Built-in Meter: Please use the CT shipped with the inverter to connect to the inverter. <ul style="list-style-type: none"> ◦ CT ratio is 120A:40mA ◦ If the inverter's built-in meter is insufficient, contact your dealer to purchase a GMK330 or GM330 Smart Meter. • GMK330: CT cannot be replaced; CT ratio is 120A:40mA • GM330: CT can be purchased from GoodWe or separately; CT ratio is nA:5A |
| | GMK330 (Purchase from GoodWe) | |
| | GM330 (Purchase from GoodWe) | |

| Device Type | model | Description |
|--------------|-----------------|---|
| Smart dongle | WiFi/LAN Kit-20 | <ul style="list-style-type: none"> • Uses Bluetooth signal for local configuration of device parameters and viewing device operation information; uploads system operation information to the monitoring platform via WiFi or LAN. • Ensure the Smart dongle's firmware version is 07 or above. |
| | 4G Kit-G20 | <ul style="list-style-type: none"> • Uses Bluetooth signal for local configuration of device parameters and viewing device operation information; uploads system operation information to the monitoring platform via 4G. |


| Device Type | model | Description |
|-----------------------|-------|---|
| grid-tied PV inverter | - | <ul style="list-style-type: none"> • GoodWe brand grid-tied PV inverters are recommended; third-party grid-tied PV inverters are supported. • In a microgrid scenario, ensure the grid-tied PV inverter's rated output power \leq the hybrid inverter's rated output power. • When the microgrid system is in grid-connected state, if power limitation is required, ensure: <ul style="list-style-type: none"> ◦ For the hybrid inverter, set it in the Grid Power Limit interface of the SEMS+ App. For the grid-tied PV inverter, set it according to the actual tool used. ◦ To ensure the grid-tied PV inverter can continue generating power, adjust the hybrid inverter's output power in the Microgrid Mode interface of the SEMS+ App. <p>Note: Different grid-tied PV inverters have different output power control precision. Set the grid power limit parameter value according to the actual situation.</p> |

Coupling Scenario

When the grid-tied inverter is connected to the hybrid inverter's GRID port, it is a coupling scenario.

Coupling Scenario

When the grid-tied inverter is connected to the hybrid inverter's GRID port, it is a coupling scenario.



| Device Type | model | Description |
|-----------------|--|---|
| hybrid inverter | GW5K-ETA-G20 GW6K-ETA-G20 GW8K-ETA-G20 GW9.999K-ETA-G20 GW10K-ETA-G20 GW12K-ETA-G20 GW15K-ETA-G20 GW20K-ETA-G20 GW25K-ETA-G20 GW29.999K-ETA-G20 GW30K-ETA-G20 GW5K-BTA-G20 GW6K-BTA-G20 GW8K-BTA-G20 GW9.999K-BTA-G20 GW10K-BTA-G20 GW12K-BTA-G20 GW15K-BTA-G20 GW20K-BTA-G20 GW25K-BTA-G20 GW29.999K-BTA-G20 GW30K-BTA-G20 | <ul style="list-style-type: none"> • Only supports connection to GoodWe AC charging piles in single-unit scenarios. • The system supports up to 10 inverters to form a parallel system, and supports hybrid parallel connection of inverters with different power ratings in on-grid/off-grid modes. When mixing, it is recommended to use a high-power inverter as the master; the microgrid function is not supported during parallel operation. • Supports generator control and generator charging of the battery. If a generator needs to be connected, please use the GMK330 or GM330 Smart Meter. • In a parallel system, each inverter needs to be installed with a WiFi/LAN Kit-20. • The following version requirements must be met during system networking: <ul style="list-style-type: none"> ◦ The Inverter ARM software version is 03.138 or higher. ◦ The Inverter DSP software version is 01.1025 or higher. |

| Device Type | model | Description |
|----------------|--|--|
| Battery system | GW5.1-BAT-D-G20 GW5.1-BAT-D-G21 GW8.3-BAT-D-G20 GW8.3-BAT-D-G21 GW6.0-BAT-D-G20 GW9.0-BAT-D-G20 | <ul style="list-style-type: none"> • Different models of battery modules can be mixed. • The system supports 5-108kWh, meeting usage with different power and energy matching requirements. • The battery heating pad is optional. The "Battery Heating" function can only be enabled on models configured with the heating pad. Batteries without the heating pad should not be used in low-temperature environments, as this may cause the device to fail to operate. • The battery heating function is unavailable when GW5.1-BAT-D-G20, GW8.3-BAT-D-G20, GW5.1-BAT-D-G21, GW8.3-BAT-D-G21, GW6.0-BAT-D-G20 , GW9.0-BAT-D-G20 are mixed. • If the system requires mixed battery use or split-type expansion, ensure the BMS software version is V06 or higher and the DCDC version is V05 or higher. |
| Smart Meter | Inverter Built-in Meter GMK330 (Purchase from GoodWe) | |

| Device Type | model | Description |
|--------------|------------------------------|--|
| | GM330 (Purchase from GoodWe) | <ul style="list-style-type: none"> • Built-in Meter: Please use the CT shipped with the unit to connect to the inverter. <ul style="list-style-type: none"> ◦ The CT ratio is 120A:40mA. ◦ If the inverter's built-in meter does not meet the usage requirements, contact the dealer or others to purchase a GMK330 or GM330 Smart Meter. • GMK330: CT cannot be replaced; CT ratio is 120A:40mA • GM330: CT can be purchased from GoodWe or separately; CT ratio requirement: nA/5A <ul style="list-style-type: none"> ◦ nA: CT primary side input current, where n ranges from 200 to 5000 ◦ 5A: CT secondary side output current • If the number of parallel inverters exceeds 2, or if the wire gauge or range of the standard CT does not meet the total current requirements of the on-site parallel system, please use the GM330 Smart Meter. |
| Smart dongle | WiFi/LAN Kit-20 | <ul style="list-style-type: none"> • Uses Bluetooth signals for local configuration of device parameters and viewing device operation information; uploads system operation information to the monitoring platform via WiFi or LAN. • Ensure the firmware version of the Smart dongle is 07 or higher. |
| | 4G Kit-G20 | Uses Bluetooth signals for local configuration of device parameters and viewing device operation information; uploads system operation information to the monitoring platform via 4G. |


| Device Type | model | Description |
|-----------------------|-------|---|
| grid-tied PV inverter | - | <ul style="list-style-type: none"> • It is recommended to use GoodWe brand grid-tied PV inverters; third-party grid-tied PV inverters are supported. • In coupling scenarios, ensure the rated output power of the grid-tied PV inverter \leq the rated output power of the hybrid inverter. • When the coupling system is in grid-connected status, if power limitation is required, ensure: The hybrid inverter needs to be set via the grid power limitation interface in the SEMS+ App; set the grid-tied PV inverter according to the actual tool used. <p>Note: The output power control accuracy varies for different grid-tied PV inverters; please set the grid power limitation parameter values according to the actual situation.</p> |

2.2 Product Overview

2.2.1 Residential Three-Phase All-in-One Unit

Residential Three-Phase All-in-One Unit:

The Residential Three-Phase All-in-One Unit adopts a blind plug stacking connection method and integrates the Inverter and Battery units through modular design.



ESA20DSC0007

The energy storage system supports Battery capacity expansion. The total Battery capacity is determined by the number and specifications of Battery modules. Configuration must strictly adhere to the limitations specified in this section. Overall system configuration description:


A: GW5.1-BAT-D-G20, GW5.1-BAT-D-G21, GW6.0-BAT-D-G20

B: GW8.3-BAT-D-G20, GW8.3-BAT-D-G21, GW9.0-BAT-D-G20

| Mounting Method | Expansion Groups | Single Group Stacking | Total Batteries |
|------------------------------------|------------------|---|-----------------|
| Floor Installation | ≤3 groups | Wall-spaced: ≤4 units Wall-mounted: ≤6 units | ≤12 units |
| Wall-mounted Installation (A) | ≤3 groups | ≤3 units | ≤9 units |
| Wall-mounted Installation(A/B/A+B) | ≤3 groups | ≤2 units | ≤6 units |

| Mounting Method | Expansion Groups | Single Group Stacking | Total Batteries |
|--|------------------|-----------------------|-----------------|
| Note: Expansion Groups × Single Group Stacking Quantity ≤ Total System Battery Count | | | |


Wall-mounted Installation




Installation

Floor-mounted Installation

- Installation against the wall




- Installation away from the wall




Cluster Expansion Installation

- Floor-mounted installation




- Wall-mounted installation



Inverter:

The Inverter in the photovoltaic system controls and optimizes the energy flow through the integrated energy management system. It can supply the electricity generated in the photovoltaic system for load use, store it in the Battery, output it to the grid, etc.




ESA20DSC0010

| No. | Component/Silkscreen | Description |
|-----|---|--|
| 1 | indicator | Indicates the operating status of the inverter. |
| 2 | heat sink | Dissipates heat for the inverter. |
| 3 | Connector | The power and communication port connecting the inverter to the battery. |
| 4 | Smart Communication Stick Connection Port | <ul style="list-style-type: none"> • Can connect to smart communication sticks, such as WiFi/LAN communication modules. Please select the module type based on actual requirements. • Supports connecting a USB flash drive for local inverter software version upgrades. |
| 5 | Ventilation valve | - |
| 6 | STS Communication Interface | Reserved |
| 7 | PV Input Terminals | <p>For ETA models only. BTA models do not have PV input terminals.</p> <ul style="list-style-type: none"> • Can connect to DC input cables from PV modules. • The number of PV input terminals is as follows: <ul style="list-style-type: none"> ◦ GW5K-ETA-G20, GW6K-ETA-G20, GW8K-ETA-G20, GW6K-EHA-G20: 3 ◦ GW9.999K-ETA-G20, GW10K-ETA-G20, GW12K-ETA-G20, GW15K-ETA-G20, GW20K-ETA-G20, GW25K-ETA-G20, GW29.999K-ETA-G20, GW30K-ETA-G20: 4 |
| 8 | BACK-UP Port | Connects to AC lines, connecting to critical loads or grid-tied inverters. |
| 9 | Battery Mounting Holes | Secures the inverter and the battery. |

| No. | Component/Silkscreen | Description |
|-----|--------------------------------|---|
| 10 | Communication Port | Can connect communication cables for load control, CT, RS485, Remote Shutdown/Rapid Shutdown, DRED (Australia)/RCR (Europe), etc. |
| 11 | Carrying Handle Mounting Holes | Used for installing the carrying handle. Used when moving the inverter. |
| 12 | DC Switch | For ETA models only. BTA models do not have a DC switch. Controls the connection or disconnection of the DC input. |
| 13 | GRID Port | Connects to AC lines, connecting the inverter to the grid. |
| 14 | Grounding terminal | Connects to the chassis protective ground wire. |

Battery:

The Battery system can store and release electricity according to the requirements of the photovoltaic energy storage system. The input and output ports of this energy storage system are high-voltage direct current.




| No. | Component | Description |
|-----|------------------------------|--|
| 1 | Connector | Power and Communication Port for connecting battery to battery, and battery to inverter. |
| 2 | Anti-tip bracket fixing hole | Used for fixing the battery to the wall. |

| No. | Component | Description |
|-----|---------------------------------------|--|
| 3 | Multi-function button indicator light | <ul style="list-style-type: none"> Indicates the battery operating status. Battery black start function: When there is no PV power generation in the photovoltaic system and the grid is abnormal, the inverter cannot operate normally. In this case, press and hold the multi-function button for 2 seconds to start the battery system, activate the inverter, putting the inverter into off-grid operation mode, and the battery discharges to power the load. Battery shutdown function: Press and hold the multi-function button for >5 seconds to shut down the battery system. |
| 4 | Battery isolation switch | Battery power input/output switch. |
| 5 | Inter-battery fixing hole | Used for fixing between two batteries. |
| 6 | heat sink | Battery heat dissipation |
| 7 | Battery lifting hole | Used for lifting the battery. When stacking more than three batteries, lifting tools must be used for installation. |
| 8 | Battery or inverter fixing hole | Used for fixing between batteries or between the inverter and battery. |
| 9 | Carrying bar mounting hole | Used for installing the carrying bar. Used during manual battery handling. |

2.2.2 Smart Meter

The Smart Meter measures and monitors electrical data in the photovoltaic energy storage system, such as: voltage, current, frequency, Power Factor, power, etc.


GM330&GMK330&CT



| No. | model | Applicable Scenarios |
|-----|--------|---|
| 1 | GM330 | <p>CT can be purchased from GoodWe or separately. CT ratio requirement: nA: 5A</p> <ul style="list-style-type: none"> nA: CT primary side input current, n range is 200-5000 5A: CT secondary side output current |
| 2 | GMK330 | <p>CT is shipped with the meter. CT ratio:</p> <ul style="list-style-type: none"> 120A: 40mA |


2.2.3 smart dongle

The smart dongle is mainly used for real-time transmission of various power generation data from inverters to remote monitoring platforms, and for connecting the smart dongle via an App for local device debugging.



| No. | model | Signal Type | Applicable Scenarios |
|-----|-----------------|----------------------|---|
| 1 | WiFi/LAN Kit-20 | WiFi, LAN, Bluetooth | Single-unit and multi-unit inverter scenarios |
| 2 | 4G Kit-G20 | 4G, Bluetooth | Single-unit inverter scenarios. |

2.3 Supported Grid Types




TNNET0003

2.4 System Working Mode

Self-consumption

- The basic operating mode of the system.
- PV generation first supplies power to the loads, excess energy charges the battery, and any remaining energy is sold to the grid. When PV generation cannot meet the load demand, the battery supplies power to the loads; when the battery power is also insufficient to meet the load demand, the grid supplies power to the loads.




SLG00NET0009


Backup Mode

- Recommended for use in areas with unstable grids.
- When the grid fails, the inverter switches to off-grid working mode, and the battery discharges to supply power to the loads, ensuring uninterrupted power for the BACK-UP Loads. When the grid is restored, the inverter switches its working mode back to grid-connected operation.
- To ensure the battery SOC is sufficient to maintain normal system operation during

off-grid periods, the system will charge the battery using PV or by purchasing electricity from the grid to the backup power SOC during grid-connected operation. If purchasing electricity from the grid to charge the battery, please ensure compliance with local grid laws and regulations.



SLG00NET0002




TOU Mode


In compliance with local laws and regulations, buy and sell electricity during different time periods based on the difference between peak and valley grid electricity prices. For example: During valley price periods, set the battery to charging mode to purchase electricity from the grid for charging; during peak price periods, set the battery to discharging mode to supply power to the loads via the battery.

TOU Mode①

PV: Charge battery in priority



SLG00NET0004




SLG00NET0005

Delayed Charging Mode

- Suitable for areas with grid-connected power output limits.
- Setting a peak power limit can use PV generation exceeding the grid connection limit to charge the battery; or setting a PV charging period to utilize PV generation for charging the battery during that period.

Smart Charging ①




SLG00NET0006


Smart Charging ②

PV < Peak Limit

Switch to Charge: enabled




SLG00NET0007



Demand Control Mode

- Primarily applicable to commercial and industrial scenarios.
- When the total load power consumption exceeds the electricity quota within a short period, battery discharge can be used to reduce the portion of consumption exceeding the quota.
- When the battery SOC is lower than the reserved SOC for demand control, the system purchases electricity from the grid based on the time period, load consumption, and peak purchase power limit.



SLG00NET0012

2.5 Features

NOTICE

Please refer to the actual product configuration for specific functional features.

AFCI

The inverter integrates an AFCI circuit protection device to detect arc faults and quickly cut off the circuit when detected, thereby preventing electrical fires.

Causes of arc generation:

- Damage to connector connections in the PV system.
- Incorrect or damaged cable connections.
- Aging of connectors or cables.

Fault handling methods:

1. When the inverter detects an arc, you can view the fault type via the App.
2. If the inverter triggers a fault <5 times within 24 hours, it will automatically restore grid connection after a 5-minute wait. After the 5th arc fault, the fault must be cleared before the inverter can resume normal operation. For specific operations, please refer to the *SEMS+ App User Manual*.

| model | Label | Description |
|--|------------------------|--|
| GW5K-ETA-G20 GW6K-ETA-G20 GW8K-ETA-G20 | AFCI: F-I-AFPE-1-2/1-2 | F (Full coverage) : Full coverage of inverter PV input ports I (Integrated) : Integrated within the inverter AFPE (arc fault protection equipment) : Combines both AFD and AFI arc detection functions 1: One pair of PV input ports (PV+, PV-) connects to one PV input string 2/1: One arc detection channel has 2 MPPT inputs; One arc detection channel has 1 MPPT input; 2: Has 2 arc detection channels |
| GW9.999K-ETA-G20 GW10K-ETA-G20 GW12K-ETA-G20 GW15K-ETA-G20 GW20K-ETA-G20 | AFCI: F-I-AFPE-1-2/2-2 | F (Full coverage) : Full coverage of inverter PV input ports I (Integrated) : Integrated within the inverter AFPE (arc fault protection equipment) : Combines both AFD and AFI arc detection functions 1: One pair of PV input ports (PV+, PV-) connects to one PV input string 2/2: Each arc detection channel has 2 MPPT inputs; 2: Has 2 arc detection channels |

| model | Label | Description |
|---|------------------------|--|
| GW25K-ETA-G20 GW29.999K-ETA-G20 GW30K-ETA-G20 | AFCI: F-I-AFPE-1-2/4-2 | <p>F (Full coverage) : Full coverage of inverter PV input ports</p> <p>I (Integrated) : Integrated within the inverter</p> <p>AFPE (arc fault protection equipment) : Combines both AFD and AFI arc detection functions</p> <p>1: One pair of PV input ports (PV+, PV-) connects to one PV input string</p> <p>2/4: One arc detection channel has 2 MPPT inputs; One arc detection channel has 4 MPPT inputs;</p> <p>2: Has 2 arc detection channels</p> |

Three-Phase Unbalanced Output

Both the grid-tie side and the BACK-UP side of the inverter support three-phase unbalanced output, allowing connection of loads with different power ratings to each phase. The maximum output power per phase for different models is shown in the table below:

| No. | model | Single-Phase Maximum Output Power |
|-----|--------------------------------------|-----------------------------------|
| 1 | GW5K-ETA-G20 GW5K-BTA-G20 | 2.5kW |
| 2 | GW6K-ETA-G20 GW6K-BTA-G20 | 3kW |
| 3 | GW8K-ETA-G20 GW8K-BTA-G20 | 4kW |
| 4 | GW9.999K-ETA-G20 GW9.999K-BTA-G20 | 5kW |
| 5 | GW10K-ETA-G20 GW10K-BTA-G20 | 5kW |
| 6 | GW12K-ETA-G20 GW12K-BTA-G20 | 6kW |

| No. | model | Single-Phase Maximum Output Power |
|-----|--|-----------------------------------|
| 7 | GW15K-ETA-G20 GW15K-BTA-G20 | 7.3kW |
| 8 | GW20K-ETA-G20 GW20K-BTA-G20 | 7.3kW |
| 9 | GW25K-ETA-G20 GW25K-BTA-G20 | 11kW |
| 10 | GW29.999K-ETA-G20 GW29.999K-BTA-G20 | 11kW |
| 11 | GW30K-ETA-G20 GW30K-BTA-G20 | 11kW |

Rapid Shutdown (RSD) Rapid Shutdown

In a rapid shutdown system, the rapid shutdown transmitter and receiver work together to achieve rapid system shutdown. The receiver maintains module output by receiving signals from the transmitter. The transmitter can be external or built into the inverter. In case of an emergency, the transmitter can be deactivated by enabling an external trigger device, thereby shutting down the modules.

- External Transmitter
 - Transmitter models: GTP-F2L-20, GTP-F2M-20
<https://en.goodwe.com/Ftp/Installation-instructions/RSD2.0-transmitter.pdf>
 - Receiver models: GR-B1F-20, GR-B2F-20
https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW_RSD-20_Quick-Installation-Guide-POLY.pdf
- Built-in Transmitter
 - External trigger device: External switch
 - Receiver models: GR-B1F-20, GR-B2F-20
https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW_RSD-20_Quick-Installation-Guide-POLY.pdf

3 Check and Storage

3.1 Check Before Receiving

Before receiving the product, please carefully check the following:




1. Check if the outer packaging is damaged, such as deformation, holes, cracks, or other signs that could cause damage to the equipment inside the box. If damaged, do not open the packaging and contact your dealer.
2. Check if the device model is correct. If it does not match, do not open the packaging and contact your dealer.







3.2 deliverables







 **WARNING**


Check if the type and quantity of the delivered items are correct, and if there is any damage to the appearance. If there is any damage, please contact your dealer. After removing the delivered items from the packaging, do not place them on rough, uneven, or sharp surfaces to avoid paint chipping.



3.2.1 Inverter Deliverables

| Part | Description | Part | Description |
|---|---------------------------|--|----------------------------|
|  | Inverter x 1 |  | Top decorative cover x 1 |
|  | Left decorative cover x 1 |  | Right decorative cover x 1 |


| Part | Description | Part | Description |
|---|--|--|--|
|  <p>or</p> | <p>AC terminal kit x 2</p> <ul style="list-style-type: none"> • AC wiring terminal x 2 • PIN terminal x N <ul style="list-style-type: none"> ◦ 5-20kW: <ul style="list-style-type: none"> ▪ 4mm² x 5 ▪ 6mm² x 5 ▪ 10mm² x 5 ▪ 16mm² x 5 ◦ 25-30kW: <ul style="list-style-type: none"> ▪ 10mm² x 5 ▪ 16mm² x 5 ▪ 25mm² x 5 |  | <p>Handle x 2</p> |
|  | <p>OT grounding terminal x 1</p> |  | <p>6PIN communication terminal x 2</p> |
|  | <p>2PIN communication terminal x 2</p> |  | <p>PIN terminal x 16</p> |
|  | <p>CT connection cable x 1</p> |  | <p>CT x 1</p> |

| Part | Description | Part | Description |
|---|---------------------------|---|--|
|  | Battery base x 1 |  | Adjustable feet x 4 |
|  | Anti-tip bracket x 4 |  | M5*16 screw x 9 |
|  | M5*60 expansion screw x 4 |  | Drilling template paper x 2 |
|  | |  | PV terminal unlocking tool x N N: China region x 0; other regions x 1. |



| Part | Description | Part | Description |
|------|--|--|-------------------------|
| | <p>PV terminal and PV terminal anti-removal cover</p> <ul style="list-style-type: none"> • GW5K-ETA-G20, GW6K-ETA-G20, GW8K-ETA-G20, GW6K-EHA-G20: 3 • GW9.999K-ETA-G20, GW10K-ETA-G20, GW12K-ETA-G20, GW15K-ETA-G20, GW20K-ETA-G20, GW25K-ETA-G20, GW29.999K-ETA-G20, GW30K-ETA-G20: 4 • GW5K-BTA-G20, GW6K-BTA-G20, GW8K-BTA-G20, GW9.999K-BTA-G20, GW10K-BTA-G20, GW12K-BTA-G20, GW15K-BTA-G20, GW20K-BTA-G20, GW25-BTA-G20, GW29.999K-BTA-G20, GW30K-BTA-G20: 0 |  | <p>Smart dongle x 1</p> |

| Part | Description | Part | Description |
|---|---|---|---|
|  | <ul style="list-style-type: none"> • (Australia only) Manual transfer switch x1 • Manual transfer switch lock x N <p>Note: For single-unit scenarios only</p> |  | <p>Cable cover x N</p> <p>N: Standard in Australia region; optional in Europe region.</p> |
|  | <p>Product documentation x 1</p> | - | - |

(Europe only) Manual transfer switch


| Part | Description |
|---|---|
|  | <ul style="list-style-type: none"> • Manual transfer switch x1 • Manual transfer switch latch x1 <p>Note: For use in single-unit scenarios only. If needed, please contact the distributor to purchase.</p> |

3.2.2 Batteries Deliverables

| Component | Instructions | Component | Description |
|---|--------------------|---|------------------------|
|  | <p>Battery x 1</p> |  | <p>M5*16 screw x 2</p> |

| Component | Instructions | Component | Description |
|---|--------------------|-----------|-------------|
|  | silica gel cap x 2 | - | - |



Bracket (Optional)








| Component | Instructions | Component | Instructions |
|--|----------------------|---|--------------|
|  | mounting bracket x 2 |  | M10x 6 |
|  | M10x 4 | - | - |


3.2.2.1 Battery Expansion Kit deliverables (Optional)

NOTICE




The system supports 5-108kWh. A single string can stack up to 6 Battery units. If more energy is required, or if the stacking height per string needs to be reduced due to Installation conditions or other expansion scenarios, please contact GoodWe or a distributor to purchase the Battery expansion kit.

| Component | Instructions | Component | Instructions |
|---|--------------|---|---------------------|
|  | Base x 1 |  | locking bracket x 4 |

| Component | Instructions | Component | Instructions |
|---|---|--|---|
|  | M5 x 7 |  | M6 x 4 |
|  | Adjustable feet x 4 |  | OT Grounding terminal x 1 |
|  | Terminal resistor x 1 |  | Decorative cover x 1 |
|  | Punching mark paper x 2 |  | Expansion cluster harness x 1 |
|  | PIN terminal x 8 |  | Expansion cluster connection positive harness x 1 |
|  | Expansion cluster connection negative harness x 1 |  | Expansion cluster network cable x 1 |






| Component | Instructions | Component | Instructions |
|---|--------------------|--|---------------------------|
|  | silica gel cap x 2 |  | Handle x 2 |
|  | Hex key wrench x 1 |  | Product Documentation x 1 |

3.2.2.2 Wall-Mounted Bracket (Optional)

| Component | Instructions | Component | Instructions |
|---|--------------------------|--|--------------|
|  | Wall-mounted bracket x 2 |  | M6 x 4 |
|  | M5 fixing screw x 4 | - | - |

3.2.3 Smart Meter Delivery Set GM330&GMK330

3.2.3.1 Attachment List

| Component | Instructions | Component | Instructions |
|---|--|---|--|
|  | Smart Meterx1 GMK330:CT×3; GMK360: CT×6; GM330: CT x 0。 |  | 2PIN connector x1 Applicable to GM330. |
|  | 6PIN communication terminal x1 Applicable to GM330. |  | 7PINcommunication terminal x1 Applicable to GM330. |
|  | Electricity meter Applicable to GMK330/GMK360. |  | RS485communication terminal x 1 |
|  | 2PINterminal andRJ45terminal adapter cable x 1 |  | screwdriver x1 |
|  | PIN terminal GMK330/GMK360: x 5 ; GM330: x 6。 |  | Product Documentation x 1 |

3.3 Storage

- If the inverter has been stored for more than two years or has not been operated for more than six months after installation, it is recommended to have it inspected and tested by a professional before putting it into use.
- To ensure the good electrical performance of the internal electronic components of the inverter, it is recommended to power it on once every six months during storage. If it has not been powered on for more than six months, it is recommended to have it inspected and tested by a professional before use.
- To ensure battery performance and service life, it is recommended to avoid long-term idle storage. Prolonged storage may cause the battery to deep discharge, leading to irreversible chemical degradation, resulting in capacity decay or even complete failure, timely use is advised. If the battery needs to be stored for a long

period, please perform maintenance according to the following requirements:

NOTICE

[1] The storage time is calculated from the SN date on the battery's outer packaging. After exceeding the storage cycle, charge-discharge maintenance is required. (Battery maintenance time = SN date + charge-discharge maintenance cycle). For how to view the SN date, refer to: [10.3.Battery SN Code Meaning\(Page 305\)](#).

[2] After the charge-discharge maintenance is qualified, if there is a Maintaining Label on the outer box, please update the maintenance information on the Maintaining Label. If there is no Maintaining Label, please record the maintenance time and battery SOC yourself and keep the data properly for maintaining maintenance records.

| Battery Model | Initial SOC Range for Battery Storage | Recommended Storage Temperature | Charge/Discharge Maintenance Cycle ^[1] | Battery Maintenance Method ^[2] |
|-----------------|---------------------------------------|---------------------------------|--|--|
| GW5.1-BAT-D-G20 | 30~40% | 0~35°C | -20~35°C, 12 months 35~45°C, 6 months | For maintenance methods, please consult the distributor or after-sales service center. |
| GW8.3-BAT-D-G20 | | | | |
| GW5.1-BAT-D-G21 | | | | |
| GW8.3-BAT-D-G21 | | | | |
| GW6.0-BAT-D-G20 | 30~40% | 0~35°C | -20~35°C, 12 months 35~45°C, 6 months 45~55°C, 1 month | |
| GW9.0-BAT-D-G20 | | | | |

Packaging Requirements:

Ensure the outer packaging box is not removed and the desiccant inside the box is not missing.

Environmental Requirements:

1. Ensure the device is stored in a cool place, avoiding direct sunlight.
2. Ensure the storage environment is clean, with appropriate temperature and humidity ranges, and no condensation. If condensation is observed on the device ports, do not install the device.
 - GW5.1-BAT-D-G20, GW8.3-BAT-D-G20, GW5.1-BAT-D-G21, GW8.3-BAT-D-G21 battery storage humidity range: 5%-95%.
 - GW6.0-BAT-D-G20, GW9.0-BAT-D-G20 battery storage humidity range: 4%-100%.
3. Ensure the device is stored away from flammable, explosive, corrosive, and other hazardous materials.
4. Stacking Requirements:
 - Ensure the stacking height and orientation of the device are arranged according to the instructions on the packaging box label.
 - Ensure there is no risk of toppling after the devices are stacked.

4 Installation

DANGER

When performing equipment installation and electrical connections, please use the delivery items shipped with the box. Otherwise, any resulting equipment damage will not be covered under warranty.

4.1 Installation Requirements

4.1.1 Installation Environment Requirements


NOTICE

- Inverter Operating Temperature Range: -35°C to 60°C .
- GW5.1-BAT-D-G20, GW8.3-BAT-D-G20: Charge Temperature range: -18°C - 55°C Discharge Temperature Range: -20°C - 55°C If Installation is in -18°C in the following environment, Battery will be unable to continue Charge energy recovery after venting, resulting in Battery Undervoltage.
- GW5.1-BAT-D-G21, GW8.3-BAT-D-G21: Charge Temperature range: 2°C - 55°C Temperature range: -20°C - 55°C If Installation is in 2°C in the following environment, Battery will be unable to continue Charge energy recovery after venting, resulting in Battery Undervoltage.
- GW6.0-BAT-D-G20, GW9.0-BAT-D-G20: Charge Temperature range: -20°C - 55°C Temperature range: -20°C - 55°C If Installation is at -20°C Under the following conditions, Battery will be unable to continue Charge energy recovery after venting, resulting in Battery Undervoltage.

1. The equipment must not be operated in flammable, explosive, or corrosive environments.
2. The ambient temperature of the equipment must be within the appropriate range.
3. Installation Location should be kept out of reach of children, and avoid placing Installation in easily accessible locations.
4. The equipment surface may become hot during operation to prevent burns.
5. The equipment should be protected from exposure to sunlight, rain, snow, and

other Installation conditions. It is recommended to Installation in a shaded Installation Location. If necessary, a sunshade canopy can be constructed.

6. The space must meet the ventilation and heat dissipation requirements of the equipment as well as the operational space requirements.
7. The environment must meet the equipment's Ingress Protection Rating, Inverter, Battery, and smart dongle requirements for both indoor and outdoor Installation; the electricity meter must comply with indoor Installation.
8. The height of the equipment Installation should facilitate operation and maintenance, ensuring that the equipment indicator and all labels are easily visible, and the wiring terminal is easy to operate.
9. Equipment Installation Altitude is below Max. Operating Altitude.
10. Before installing salt affected area outdoor Installation equipment, consult the manufacturer. salt affected area mainly refers to areas within 500m of the coast. The affected zone is related to factors such as sea breeze, precipitation, and terrain.
11. The equipment will generate noise during operation. Installation Location should be kept away from noise-sensitive areas such as residential zones, schools, and hospitals to prevent disturbance caused by operational noise to nearby residents.
12. Keep away from strong magnetic fields to avoid electromagnetic interference. If there is a radio station or wireless communication equipment below 30MHz near the Installation Location, please Installation the equipment according to the following requirements:
 - Inverter: Add ferrite cores with multiple turns on the Inverter DC input or AC output lines, or incorporate low-pass EMI Filter; or maintain a distance of over 30m between the Inverter and radio frequency interference equipment.
 - Other Equipment: The distance between the equipment and the wireless electromagnetic interference device exceeds 30m.




ESA20INT0011

4.1.2 Installation Space Requirements

When installing devices in the system, sufficient space should be reserved around the devices to ensure adequate installation and heat dissipation space.


- When using CAT 7E communication cables between inverters, the cable distance should not exceed 10 meters; when using CAT 5E or CAT 6E communication cables, the cable distance should not exceed 5 meters. Do not exceed 10m for communication cables, otherwise it may cause communication abnormalities.
- For installing CT, use CAT 5E or above shielded network cables, with a cable distance not exceeding 30 meters.
- For RS485 twisted-pair shielded cables used for communication between the inverter and the meter, the cable distance should not exceed 100 meters.

Communication Cable Length



ESA20INT0012

Installation Space



ESA20INT0018



4.1.3 Tool Requirements

NOTICE


During installation, it is recommended to use the following installation tools. If necessary, other auxiliary tools may be used on-site.

Installation Tools

| Tool Type | Description | Tool Type | Description |
|---|----------------|--|------------------------------|
|  | diagonal plier |  | RJ45 connector crimping tool |

| Tool Type | Description | Tool Type | Description |
|---|-----------------------------------|--|---|
|  | wire stripper |  | Level bar |
|  | open-end wrench |  | PV terminal crimping tool PV-CZM-61100 |
|  | hammer drill (drill bit Φ12mm) |  | torque wrench M4, M5, M6, M10 |
|  | rubber hammer |  | socket wrench |
|  | marker pen |  | multimeter Range ≤ 1000V |
|  | heat shrink tubing |  | heat gun |
|  | cable tie |  | vacuum cleaner |

Personal Protective Equipment

| Tool Type | Description | Tool Type | Description |
|---|-------------------------------------|---|-------------|
|  | Insulated gloves, protective gloves |  | Dust mask |

| Tool Type | Description | Tool Type | Description |
|---|-------------|---|--------------|
|  | goggle |  | Safety shoes |

4.2 Equipment Handling

CAUTION

- During transportation, handling, Installation, and other operations, it must comply with the laws, regulations, and relevant standards of the country or region where it is located.
- Before Installation, it is necessary to move Equipment Handling to Installation. To prevent personal injury or equipment damage during the transportation process, please NOTICE the following matters:
 1. Please equip the corresponding personnel according to the Weight to prevent the equipment from exceeding the Weight range that can be manually handled, thereby avoiding injury to personnel.
 2. Please wear safety gloves to avoid injury.
 3. Please ensure the equipment remains balanced during transportation to avoid falling.
 4. Battery system can be transported by hoisting to the Installation location.
 5. When lifting and moving equipment using a hoisting method, please use flexible slings or straps. The load-bearing capacity of a single strap must meet the following requirements:
 - GW5.1-BAT-D-G20, GW5.1-BAT-D-G21, GW6.0-BAT-D-G20 \geq 185KG
 - GW8.3-BAT-D-G20, GW8.3-BAT-D-G21, GW9.0-BAT-D-G20 \geq 240KG

NOTICE

- Battery needs to be installed on Base, and Base can be placed on the ground Installation or mounted on the bracket Installation.
- When placed on the ground Installation, a maximum of 4 Battery units can be stacked away from the wall, while a maximum of 6 Battery units can be stacked against the wall.
- The maximum stacking quantity when using the bracket Installation is specified as follows:
 - Same energy stacking
 - GW5.1-BAT-D-G20 , GW5.1-BAT-D-G21Maximum 3 Block.
 - GW8.3-BAT-D-G20 , GW8.3-BAT-D-G21Maximum 2 Block.
 - GW6.0-BAT-D-G20: Maximum 3 units.
 - GW9.0-BAT-D-G20: Maximum of 2 units.
 - Different energy aliasing
 - When GW5.1-BAT-D-G20, GW5.1-BAT-D-G21, and GW6.0-BAT-D-G20 are mixed in stacking, the system supports a maximum of 3 blocks per single group.
 - GW8.3-BAT-D-G20, GW8.3-BAT-D-G21, GW9.0-BAT-D-G20, and models compatible for hybrid stacking with themThe system supports a maximum of single group 2 Block.
- When mounted against a wall, the bracket and the topmost Battery must be secured to the wall surface using locking bracket.
- BracketInstallationWhen marking the drilling positions, have one person hold the Base steady while another uses a marker to mark the drilling locations.
- When Installing the Battery System and Inverter, remove the protective cover from the blind-mate connector before stacking.

Wall-mounted Installation

Step 1:Mount the Base Installation on the bracket.


Step 2:The bracket should be tightly attached to the wall. Ensure the bracket is securely placed and observe the level bubble in the center of the Base.

Step 3:After adjusting the position and levelness of the mounting bracket, use a marker to mark the drilling positions. Once marked, remove the bracket. (A: PACKfixing hole position; B: Bracketfixing hole position.)

Step 4:Punch holes and InstallationExpansion screw.

1. Use a hammer drill for punching holes.
2. Clean the holes.
3. Use rubber hammer to insert Expansion screw Installation into the hole.
4. Use a hex wrench to tighten nut clockwise, causing screw to expand.
5. Rotate the nut counterclockwise to remove.
6. Use torque screwdriver to fasten locking bracket to the wall.

Step 5: Use a hex wrench to secure the bracket to the wall.



ground-mounted Installation

Wall-mounted Installation


Step 1: Adjust the adjustable feet Installation at the bottom of Base, and secure the locking bracket onto the Base.

Step 2: Place the Base at a distance of 50-60 cm from the wall. Place it parallel to the wall. Observe the level bubble in the center of the Base. If the bubble is not centered, use the adjustable feet to level it.


Step 3: After adjusting the position and level of Base, use a drilling template to mark the drilling positions. Once marked, remove the Base. (A: PACK fixing hole position; B: Bracket fixing hole position.)

Step 4: Use hammer drill for drilling and clean the holes.

Step 5: Secure the locking bracket to the wall using cross screwdriver fasteners.



a: Fixed surface with Base; b: Fixed surface with wall.



ESA20INT0004

Off-wall Installation


Step 1: Place the adjustable feet Installation at the bottom of Base. Observe the level bubble in the center of Base. If the bubble is not centered, use the adjustable feet to level it.

Step 2: After adjusting the position and level of the Base, secure the wall-mounted Installation bracket to the Base. Select an appropriate location to mark the drilling positions, then remove the Base once marking is complete.

Step 3: Drill holes and Installation Expansion screw.

1. Use hammer drill for punching.
2. Clean the holes.
3. Use rubber hammer to insert Expansion screw Installation into the hole.
4. Use a hex wrench to tighten nut clockwise to expand screw.
5. Rotate the nut counterclockwise to remove.
6. Use torque screwdriver to secure the anti-wall bracket to the ground.

Step 4: Use a hex wrench to secure the Base to the ground.



ESA20INT0015

Installing the Battery System and Inverter

NOTICE

When installed against a wall, the topmost Battery must be secured to the wall using locking bracket.

Step 1: dismantle Inverter or the protective cover on the bottom blind-mate connector of Battery.

Step 2: Installation Handle (optional), stack Battery onto Base.


If the number of Installation exceeds 3 Battery, lifting equipment must be used.

Step 3: Tighten the screw between Battery and Base, or between Battery and Battery. If multiple Battery are required for Installation, please repeat **Step 1**、**Step 2** Complete all Battery Installation, Battery stacking quantities follow "[2.2.1. System Overall Configuration Description \(Page 39\)](#)".


Step 4: (Optional) The topmost Battery is secured to the wall using locking bracket.

Step 5: Installing the Inverter or Battery decorative cover.

- Integrated Installation: Lift the Inverter, align it, and stack it on top of the Battery, then fasten the screw between the Inverter and Battery. If the system is in an integrated configuration, the Installation is now complete.
- Split-type expansion: Repeat the steps of Installing the Battery System. After completing the electrical connections, place the Battery decorative cover on top of the Battery and secure the side screw.



a: Fixed surface with PACK; b: Fixed surface with wall.




4.4 Installing the Smart Meter

⚠ WARNING

In areas with lightning DANGER, if the meter cable length exceeds 10m and the cable is not routed with grounding Steel conduit, it is recommended to install external lightning protection devices.

GM330&GMK330



Step 1: Pull out the buckle at the bottom of the electricity meter.

Step 2: Place the meter on the positioning track and reinstall the buckle onto the meter.

5 System Wirings

DANGER

- The installation, routing, and connection of cables must comply with local laws, regulations, and code requirements.
- All operations during electrical connection, as well as the specifications of cables and components used, must meet local legal and regulatory requirements.
- Before performing electrical connections, disconnect the DC switch and AC output switch of the equipment to ensure it is powered off. Live working is strictly prohibited, as it may lead to hazards such as electric shock.
- Cables of the same type should be bundled together and arranged separately from different types of cables. Intertwining or cross-routing is prohibited.
- If cables are subjected to excessive tension, poor connections may result. During wiring, leave a certain length of cable slack before connecting to the inverter terminals.
- When crimping terminals, ensure the conductor part of the cable makes full contact with the terminal. Do not crimp the cable insulation together with the terminal, as this may cause the equipment to malfunction, or lead to overheating and damage to the inverter terminal block due to unreliable connections during operation.
- The inverter is not tested to AS/NZS 4777.2:2020 for combinations and/or multiple phase inverter combinations so that combinations should not be used.
- Unused cable entry holes and ports (including communication ports) must be reliably sealed using the dedicated terminal blocks or plugs provided in the accessory kit. Failure to do so may result in the following risks:
 - Electric Shock Hazard: Open electrical ports may allow direct contact with live parts, leading to electric shock accidents.
 - Protection Failure: Open ports can allow dust, moisture, or foreign objects to enter, potentially causing short circuits, fires, or equipment failure.

NOTICE

- When performing electrical connections, wear personal protective equipment such as safety shoes, protective gloves, and insulating gloves as required.
- Only qualified personnel are permitted to perform electrical connection operations.
- The cable colors shown in the graphics in this document are for reference only. Actual cable specifications must comply with local regulations.

5.1 System Wiring Electrical Block Diagram

NOTICE


- According to the regulatory requirements of different regions, the wiring methods for the N and PE lines of the inverter GRID and BACK-UP ports are different. Please refer to local regulations for specifics.
- The inverter has a built-in meter and can be directly connected to the CT for use. The CT network cable shipped with the box is 10 meters. If a longer distance is required, it can be extended to 30 meters using shielded network cable of CAT5E or above.
- When the connection length between the CT and the inverter exceeds 30m, accuracy will decrease. If high precision is required, an external smart meter can be connected.
- The inverter GRID AC port has a built-in relay. When the inverter is in off-grid mode, the built-in GRID relay is in the open state; when the inverter is in grid-connected operation mode, the built-in GRID relay is in the closed state.
- After the inverter is powered on, the BACK-UP AC port is live. If maintenance is required on the BACK-UP Loads, please power off the inverter; otherwise, it may cause electric shock.
- In whole-house backup scenarios, if the total power of the connected loads exceeds 1.1 times the rated power of the inverter, after a grid power outage, the inverter will stop output due to overload protection. At this time, please turn off some non-essential loads to ensure that the total load power is less than 1.1 times the rated power of the inverter.

N and PE wires are connected together in the distribution box.


NOTICE

- To maintain neutral integrity, the neutral wires on the grid side and the off-grid side must be connected together; otherwise, the off-grid function will not operate correctly.
- The diagram below illustrates the grid system for regions such as Australia and New Zealand:

Whole house backup power



Partial backup power




N and PE wires are separately wired in the distribution box.


NOTICE

- Ensure the protective ground wire for the BACK-UP is correctly and securely connected; otherwise, the BACK-UP function may operate abnormally in the event of a grid fault.
- In a parallel system, do not install Residual Current Devices (RCDs) on the grid-connected branch of each inverter. RCDs should be installed uniformly at the grid aggregation point.
- The following wiring method applies to regions other than Australia, New Zealand, etc.:

Whole house backup power



Partial backup power



5.2 Detailed System Wiring Diagram

When all loads in the photovoltaic system cannot consume the electricity generated by the system, the surplus electricity is fed into the grid. At this time, it can be paired with a smart meter or CT to monitor the system's power generation and control the amount of electricity fed into the grid.

- Connecting a smart meter enables output power limiting and load monitoring functions.
- After connecting the smart meter, please enable the 'Export power limit' function via the SEMS+ App.

The detailed system wiring diagram only shows wiring examples for some model devices. Please refer to the corresponding wiring guidance chapter based on the actual devices used for wiring.


!WARNING

The common contact of the manual transfer switch must be connected to the BACK-UP load side of the Inverter, and must not be connected to the GRID utility side. If connected to the GRID utility side, the Inverter's off-grid mode and bypass mode will run simultaneously. When a utility power outage occurs, the distribution cabinet connected to the Inverter's GRID port will still have high voltage, posing a risk of electric shock.

Australia Region

NOTICE


In Australia, a 3-pole manual transfer switch is included in the product shipping box. If required for use, please wire it according to the 3-pole manual transfer switch wiring method shown in the wiring diagram below.



ESA20ELC0019

NOTICE

In the European region, if a manual transfer switch is required, please purchase a 4-pole manual transfer switch through a distributor or procure it yourself. After obtaining this switch, please wire it according to the 4-pole manual transfer switch wiring method shown in the following wiring diagram.



ESA20ELC0035

NOTICE

- For microgrid and coupling scenarios, if grid-tied inverter power generation monitoring and load monitoring functions are required, a dual-meter networking setup must be used.
 - Meter 1 or the built-in meter is used to monitor the system's grid-connected power.
 - Meter 2 is used to monitor the grid-tied inverter's power generation.
 - By integrating data from Meter 1 and Meter 2, the monitoring platform can achieve real-time monitoring of the load's power consumption.
- If output power limitation is required for the grid-tied inverter, please connect separate devices such as a meter or CT.
- For microgrid and coupling scenarios with dual meters, the meter wiring method is the same.
- When not using the inverter's built-in meter, do not connect to the inverter's CT port.
- Parallel operation of energy storage inverters is not supported in microgrid scenarios.
- The manual transfer switch is only supported for use in single-unit scenarios. Please decide whether to install it based on the actual usage scenario; if using a self-provided ATS or STS switch, this switch must have an interlock function.

Dual Meter Configuration Scenarios


| Meter 1 (Grid Side) | Meter 2 (Grid-tied Inverter AC Side) |
|---------------------|--------------------------------------|
| Built-in Meter | GMK330 |
| Built-in Meter | GM330 |
| GMK330 | GMK330 |
| GM330 | GM330 |
| GMK330 | GM330 |
| GM330 | GMK330 |

5.2.1 Detailed System Wiring Diagram for Single Inverter


Common Scenarios

Scenario with Built-in Meter

Scenarios with a built-in meter do not support connection to a generator.




Scenario with GM330 Meter



ES420NET0020


Scenario with GMK330 Meter




Microgrid Scenario Network Diagram

- Microgrid scenarios do not support connection to a generator.
- Manual transfer switch is optional. Please decide whether to install it based on the actual usage scenario.

Network Diagram with Built-in Meter + GM330 Meter




GMK330 + GMK330



Microgrid Scenario, Grid-tied Inverter Grid Power Limitation Network Diagram

In a Microgrid Scenario, if the grid-tied inverter requires output power limitation, please connect a separate meter or CT device.


GM330 + GMK330



Coupling Scenario Dual Meter Network Diagram

- Manual transfer switch is optional. Please decide whether to install it based on the actual usage scenario.
- Scenarios with a built-in meter do not support connection to a generator.


GM330 + GM330 Network Diagram



Coupling Scenario, Grid-tied Inverter Grid Power Limitation Network Diagram

In a Coupling Scenario, if the grid-tied inverter requires output power limitation, please connect a separate meter or CT device.

GMK330 + GM330



5.2.2 Detailed System Wiring Diagram for Parallel System

NOTICE


- If the system requires connection to DRED devices, RCR devices, remote shutdown devices, NS Protection, SG Ready heat pumps, etc., please connect them to the master inverter.
- Remote shutdown function: Please connect the communication cable to the master inverter. Rapid shutdown function: Please connect communication cables to each inverter separately. If you need to use both rapid shutdown and remote shutdown functions simultaneously, please contact the after-sales service center.
- In a parallel system, each inverter requires the installation of a WiFi/LAN Kit-20.
- The built-in meter of the inverter supports system parallel networking. During parallel operation, the total system current must not exceed the rated primary current of the standard CT.
- The parallel system supports generator connection. If connecting a generator, please ensure:
 - The generator power must be greater than the total power of all loads connected to the BACKUP port.
 - The current capacity of the accompanying ATS can meet the total current demand when all inverters output at rated power simultaneously.
- In a parallel system, if you need to disconnect the circuit breaker for any port of an inverter, please simultaneously disconnect the circuit breakers for the other ports of that inverter; otherwise, it may cause abnormal system operation.
- In a parallel system, set the DIP switches of the first and last inverters to the ON position, and set the DIP switches of the other inverters to the OFF position.
- If the number of parallel inverters exceeds 2, or if the wire gauge or range of the standard CT does not meet the total current requirements for the on-site parallel system, please use the GM330 smart meter.
- The following diagram focuses on wiring related to parallel connection. For wiring requirements of other ports, please refer to the single-unit system.

In a parallel system, the inverter connected to the meter is the master inverter, and the others are slave inverters.

The master inverter must be set as the host via the "Parallel System Settings" in the App.


General Scenarios

Scenario with Built-in Meter




ESA20NET0028

Scenario with GM330



ESA20NET0030


Scenario with GMK330



ES420NET0031

Coupling Scenarios

GM330 + GM330 Networking



For system coupling scenarios where parallel operation is combined with other meter wiring methods, please refer to the general parallel scenarios. For grid-tied inverter wiring methods, please refer to the single-unit coupling scenario for wiring.

5.3 Preparing Materials



- Do not connect loads between the inverter and the AC switch directly connected to the inverter.
- Each inverter must be equipped with an AC output circuit breaker. Multiple inverters cannot be connected to one AC circuit breaker simultaneously.
- To ensure that the inverter can safely disconnect from the grid in case of abnormalities, please connect an AC circuit breaker on the AC side of the inverter. Select a suitable AC circuit breaker according to local regulations.
- When the inverter is powered on, the BACK-UP AC port is live. If maintenance is required on the BACK-UP Loads, please power off the inverter; otherwise, it may cause electric shock.
- For cables used in the same system, it is recommended that the following cable conductor material, cross-sectional area, length, etc., be consistent.
 - Inverter's BACK-UP AC cable
 - Inverter's GRID AC cable
- The inverter supports connecting to a generator via an ATS switch to achieve switching between grid and generator power supply. The ATS switch is by default connected to the grid.

5.3.1 Preparing Breakers

| No. | breaker | Recommended Specifications | Obtaining Method | Remarks |
|-----|---------------------------------|--|------------------|---|
| 1 | GRID breaker BACK-UP breaker | <p>For partial backup scenarios, the recommendations are as follows:</p> <ul style="list-style-type: none"> • Nominal Voltage $\geq 230V_{ac}$ • Rated current requirements are as follows: <ul style="list-style-type: none"> ◦ GW5K-ETA-G20: 20A ◦ GW6K-ETA-G20: 20A ◦ GW8K-ETA-G20: 20A ◦ GW9.999K-ETA-G20: 32A | Self-provided | During actual selection, you can also choose a breaker that meets local installation regulations based on the actual operating current. |

| No. | breaker | Recommended Specifications | Obtaining Method | Remarks |
|-----|---------|---|------------------|---------|
| | | <ul style="list-style-type: none"> ◦ GW10K-ETA-G20: 32A ◦ GW12K-ETA-G20: 40A ◦ GW15K-ETA-G20: 50A ◦ GW20K-ETA-G20: 50A ◦ GW25K-ETA-G20: 63A ◦ GW29.999K-ETA-G20: 80A ◦ GW30K-ETA-G20: 80A ◦ GW5K-BTA-G20: 20A ◦ GW6K-BTA-G20: 20A ◦ GW8K-BTA-G20: 20A ◦ GW9.999K-BTA-G20: 32A ◦ GW10K-BTA-G20: 32A ◦ GW12K-BTA-G20: 40A ◦ GW15K-BTA-G20: 50A ◦ GW20K-BTA-G20: 50A ◦ GW25K-BTA-G20: 63A ◦ GW29.999K-BTA-G20: 80A ◦ GW30K-BTA-G20: 80A <p>For whole-house backup scenarios, the recommendations are as follows:</p> <ul style="list-style-type: none"> • Nominal Voltage $\geq 230\text{Vac}$ • Rated current requirements are as follows: <ul style="list-style-type: none"> ◦ GW5K-ETA-G20: 63A ◦ GW6K-ETA-G20: 63A | | |

| No. | breaker | Recommended Specifications | Obtaining Method | Remarks |
|-----|---------|---|------------------|---------|
| | | <ul style="list-style-type: none"> ◦ GW8K-ETA-G20: 63A ◦ GW9.999K-ETA-G20: 80A ◦ GW10K-ETA-G20: 80A ◦ GW12K-ETA-G20: 80A ◦ GW15K-ETA-G20: 100A ◦ GW20K-ETA-G20: 100A ◦ GW25K-ETA-G20: 125A ◦ GW29.999K-ETA-G20: 125A ◦ GW30K-ETA-G20: 125A ◦ GW5K-BTA-G20: 63A ◦ GW6K-BTA-G20: 63A ◦ GW8K-BTA-G20: 63A ◦ GW9.999K-BTA-G20: 80A ◦ GW10K-BTA-G20: 80A ◦ GW12K-BTA-G20: 80A ◦ GW15K-BTA-G20: 100A ◦ GW20K-BTA-G20: 100A ◦ GW25K-BTA-G20: 125A ◦ GW29.999K-BTA-G20: 125A ◦ GW30K-BTA-G20: 125A <p>Note: If the inverter BACK-UP port is not used, the GRID breaker can be selected based on the maximum grid-connected current.</p> | | |

| No. | breaker | Recommended Specifications | Obtaining Method | Remarks |
|-----|------------|--|------------------|---------|
| 2 | ATS switch | The specifications of the ATS switch and GRID breaker for the same model are consistent. | Self-provided | |
| 3 | RCD (RCD) | RCD device installation and RCD specification selection: It is recommended to connect a Type A RCD with a residual current tripping level $\geq 300\text{mA}$ to the AC output side of the inverter (for inverter capacity $< 30\text{kVA}$, select the residual current operating level as 300mA ; for inverter capacity $\geq 30\text{kVA}$, select the residual current operating level as 10mA/kVA). Alternatively, choose an appropriate RCD specification based on local regulatory requirements. | Self-provided | - |

| No. | breaker | Recommended Specifications | Obtaining Method | Remarks |
|-----|--|--|---|--|
| 4 | (Optional) Manual Transfer Switch | <p>Nominal Voltage $\geq 230\text{Vac}$ Rated current requirements are as follows:</p> <ul style="list-style-type: none"> • GW5K-ETA-G20, GW6K-ETA-G20, GW8K-ETA-G20, GW9.999K-ETA-G20, GW10K-ETA-G20, GW12K-ETA-G20, GW15K-ETA-G20, GW20K-ETA-G20, GW5K-BTA-G20, GW6K-BTA-G20, GW8K-BTA-G20, GW9.999K-BTA-G20, GW10K-BTA-G20, GW12K-BTA-G20, GW15K-BTA-G20, GW20K-BTA-G20: 63A • GW25K-ETA-G20, GW29.999K-ETA-G20, GW30K-ETA-G20, GW25K-BTA-G20, GW29.999K-BTA-G20, GW30K-BTA-G20: 80A | <ul style="list-style-type: none"> • Self-provided • Shipped with the inverter (Australia only) | <ul style="list-style-type: none"> • For single-unit scenarios only • During actual selection, you can also choose an appropriate manual transfer switch based on local regulations. |

5.3.2 Preparing Cables

| No. | Cable | Recommended Specifications | Acquisition Method |
|-----|--|---|--------------------|
| 1 | Inverter Chassis Protective Ground Cable | <ul style="list-style-type: none"> • Single-core outdoor copper cable • Conductor cross-sectional area: <ul style="list-style-type: none"> ◦ GW5K-ETA-G20, GW6K-ETA-G20, GW8K-ETA-G20, GW5K-BTA-G20, GW6K-BTA-G20, GW8K-BTA-G20: 4-6mm² ◦ GW9.999K-ETA-G20, GW10K-ETA-G20, GW12K-ETA-G20, GW15K-ETA-G20, GW20K-ETA-G20, GW9.999K-BTA-G20, GW10K-BTA-G20, GW12K-BTA-G20, GW15K-BTA-G20, GW20K-BTA-G20: 6-10 mm² ◦ GW25K-ETA-G20, GW29.999K-ETA-G20, GW30K-ETA-G20, GW25K-BTA-G20, GW29.999K-BTA-G20, GW30K-BTA-G20: 10-16 mm² | Self-provided |
| 2 | PV DC Cable | <ul style="list-style-type: none"> • Industry-standard outdoor photovoltaic cable • Conductor cross-sectional area: 4mm²-6mm² • Cable outer diameter: 5.9mm-8.8mm | Self-provided |

| No. | Cable | Recommended Specifications | Acquisition Method |
|-----|-------------------------|---|--------------------|
| 3 | AC Cable | <ul style="list-style-type: none"> • Inverter AC input/output cable (BACK UP/GRID): • Conductor cross-sectional area: <ul style="list-style-type: none"> ◦ GW5K-ETA-G20, GW6K-ETA-G20, GW8K-ETA-G20, GW5K-BTA-G20, GW6K-BTA-G20, GW8K-BTA-G20: 4-6mm² ◦ GW9.999K-ETA-G20, GW10K-ETA-G20, GW12K-ETA-G20, GW9.999K-BTA-G20, GW10K-BTA-G20, GW12K-BTA-G20: 6-10mm² ◦ GW15K-ETA-G20, GW20K-ETA-G20, GW15K-BTA-G20, GW20K-BTA-G20: 10-16mm² ◦ GW25K-ETA-G20, GW29.999K-ETA-G20, GW30K-ETA-G20, GW25K-BTA-G20, GW29.999K-BTA-G20, GW30K-BTA-G20: 16-25mm² • Multi-core outdoor copper cable outer diameter: <ul style="list-style-type: none"> ◦ GW5K-ETA-G20, GW6K-ETA-G20, GW8K-ETA-G20, GW9.999K-ETA-G20, GW10K-ETA-G20, GW12K-ETA-G20, GW5K-BTA-G20, GW6K-BTA-G20, GW8K-BTA-G20, GW9.999K-BTA-G20, GW10K-BTA-G20, GW12K-BTA-G20: 10-26mm ◦ GW15K-ETA-G20, GW20K-ETA-G20, GW15K-BTA-G20, GW20K-BTA-G20: 18-30mm | Self-provided |
| 4 | Smart Meter Power Cable | <ul style="list-style-type: none"> • Outdoor copper cable • Conductor cross-sectional area: 1mm² | Self-provided |

| No. | Cable | Recommended Specifications | Acquisition Method |
|-----|---|--|--------------------|
| 5 | Meter RS485 Communication Cable | <ul style="list-style-type: none"> • Shielded twisted pair • Conductor cross-sectional area: 0.2mm²-0.4mm² | Self-provided |
| 6 | EMS or Charging Pile RS485 Communication Cable | | |
| 7 | Remote Shutdown | <ul style="list-style-type: none"> • Shielded cable meeting local standards • Conductor cross-sectional area: 0.2mm²-0.4mm² • Cable outer diameter: 5mm-8mm | Self-provided |
| 8 | Load Control and Generator Control DO Communication Cable | | |
| 9 | RCR/DRED/14a Signal Cable | | |
| 10 | CT Communication Cable | Standard network cable: CAT 5E or above standard shielded network cable and RJ45 connector | Self-provided |


5.4 Connecting the PE cable




WARNING

- The protective grounding of the chassis cannot replace the protective ground wire of the AC output port. When wiring, ensure the protective ground wires at both locations are reliably connected.
- To improve the corrosion resistance of the terminal, it is recommended to apply silicone or paint over the external part of the grounding terminal for protection after the protective ground wire connection installation is completed.
- When installing the equipment, the protective ground wire must be installed first; when removing the equipment, the protective ground wire must be removed last.
- The battery grounding is integrated into the blind-mating connector connected to the inverter. The system is uniformly grounded through the inverter, so no separate grounding operation is required for the battery during installation. If there is a requirement for split expansion, please separately ground the expansion battery pack.

Energy storage system grounding:



Expansion battery pack grounding:



5.5 Connecting the PV Cable

⚠ DANGER


- Do not connect the same PV string to multiple inverters, as this may cause inverter damage.
- Before connecting the PV string to the inverter, confirm the following information. Failure to do so may cause permanent damage to the inverter, and in severe cases, may lead to fire, resulting in personal injury and property loss.
 1. Ensure the maximum short-circuit current and Max. Input Voltage for each MPPT are within the inverter's allowable range.
 2. Ensure the positive pole of the PV string is connected to the inverter's PV+ terminal, and the negative pole is connected to the inverter's PV- terminal.

 **WARNING**

- PV string output does not support grounding. Before connecting the PV string to the inverter, ensure the minimum insulation resistance to ground of the PV string meets the minimum insulation impedance requirement ($R = \text{Max. Input Voltage} / 30\text{mA}$).
- After completing the DC cable connection, ensure the cable connections are tight and secure, with no looseness.
- Use a multimeter to measure the positive and negative poles of the DC cable to ensure correct polarity (no reverse connection) and that the voltage is within the allowable range.


NOTICE

- The two PV strings within each MPPT should use the same model, the same number of panels, and the same tilt and azimuth angles to ensure maximum efficiency.
- Connecting PV cables applies only to the ETA model; the BTA model does not have PV connection ports.



ESA20ELC0030

To disassemble the PV terminal, please refer to the following steps:




5.6 Expansion line connection for Battery




- Do not connect any load between Inverter and Battery.
- When Connecting the Battery Cable, use insulated tools to prevent accidental electric shock or Battery Short Circuit.
- Please ensure that Battery open-circuit voltage is within the allowable range of Inverter.
- Between Battery and Battery, please configure DC Switch according to local laws and regulations.
- Inverter heat sink surface and surrounding areas are prohibited from wiring to prevent overheating damage to the wire harness.

energy storage system Expansion Overview


A1: Base shipped with Inverter
 A2: Installation Base with parallel port



Battery system Expansion Harness Manufacturing Method



Battery Expansion Harness Disassembly Method



BAT20INT0007

5.7 Connecting the AC Cable

WARNING

- The inverter has an integrated Residual Current Monitoring Unit (RCMU) to prevent residual current from exceeding the specified limit. When the inverter detects a leakage current greater than the permitted value, it will quickly disconnect from the grid.
- During wiring, ensure the AC cables are correctly matched to the "BACKUP" and "GRID" ground terminals of the AC terminal block. Incorrect cable connection may cause equipment damage.
- Ensure the wire cores are fully inserted into the terminal connection holes with no exposed part.
- Ensure the insulation plate at the AC terminal block is securely fastened and not loose.
- Ensure all cable connections are tight. Otherwise, overheating of the terminals during operation may cause equipment damage.

NOTICE

- When crimping AC cables, it is recommended to use a crimping tool with a hexagonal (or more sides) crimp shape.
- After system installation is complete and wiring is confirmed correct, under normal operation, the home's critical loads should be powered by the energy storage inverter's BACK-UP port.
- After AC wiring is completed, please set the manual transfer switch to the "BACK-UP" position to engage. The fixed lock bracket supplied with the manual transfer switch can be installed as needed. If installation is required, to facilitate the installation and removal of the padlock accessory, reserve at least 35mm of space on each side of the switch.

1

5-20kW Φ , 10-26mm
25-30kW: Φ , 18-30mm

5-20kW: 50mm
25-30kW: 70mm

5-8kW: Cu, 4-6mm², 9,999-12kW: Cu, 6-10mm²
15-20kW: Cu, 10-16mm², 25-30kW: Cu, 16-25mm²

① $n \leq 11$: Do not use PIN terminals / 不使用管状端子
② $n > 11$:

2

| | | | | |
|---------|-----------|---------|---------|---------|
| 5-20kW | D 14-17mm | 17-20mm | 20-23mm | 23-26mm |
| | ① 1+2+3+4 | 2+3+4 | 3+4 | 4 |
| 25-30kW | D 18-21mm | 21-24mm | 24-27mm | 27-30mm |
| | ① 1+2+3+4 | 2+3+4 | 3+4 | 4 |

5-20kW M5 \odot 3.5N·m
25-30kW M8 \odot 6.5N·m

3

5-20kW 38mm \odot 5N·m
25-30kW 50mm \odot 6N·m

4

90°

5

5-20kW
25-30kW

BACK-UP GRID

6

M6 \odot 3N·m

AU


BACK-UP Port Supply

EU

BACK-UP Port Supply


ESA20ELC0027

(Optional) Install the manual transfer switch lock




ESA20ELC0033

If you need to disassemble the AC terminal, please refer to the following steps:




ESA20MTN0007




ESA20MTN0008

5.8 Connecting the Meter Cable


GMK330 Meter Wiring




Wiring Steps



Install CT (Type One)



Install CT (Type Two)




5.9 Connecting the Inverter Communication Cable

NOTICE

- To ensure the meter and CT function properly, please ensure the following: the CT must be connected to the matching phase line, with CT1 connected to L1, CT2 connected to L2, and CT3 connected to L3.
- When using the Inverter's built-in meter, please use the CTs shipped with the unit.
- If you need to use the DRED, RCR, or remote shutdown function, please enable this function in the SEMS+ App after completing the wiring.
- If the Inverter is not connected to a DRED device or a remote shutdown device, do not enable this function in the SEMS+ App, otherwise the Inverter will be unable to operate in grid-tied mode.
- In a parallel system, to implement the DRED or RCR function, only connect the DRED or RCR communication cable to the master Inverter.
- To maintain the Inverter's waterproof rating, do not remove the waterproof plugs from unused communication ports on the Inverter.
- For the Inverter's DO signal communication port, the dry contact signal specifications are: $\text{Max} \leq 24\text{Vdc}$, 1A.
- The Inverter's communication functions are optional; please select them according to your actual usage scenario.
- The Inverter supports connecting via Bluetooth, WiFi, or LAN to a mobile phone or WEB interface to set device parameters, view device operation information and error messages, and stay informed of the system status.
- In a single-unit system, the installation of a WiFi/LAN Kit-20 or 4G Kit-CN smart communication stick is supported.
- In a parallel system, both the master and slave Inverters need to have a WiFi/LAN Kit-20 smart communication stick installed for networking.
- In a parallel system, the DIP switches on the first and last Inverters must be set to the ON position, while the switches on all other Inverters should be set to the OFF position.

Communication Function Description




| Port (Silkscreen) | | Function | Description |
|-------------------|------|-------------------------------|--|
| A | PAR1 | Parallel Communication Port 1 | Parallel Communication Port. Please use CAT 5E or above standard network cable and RJ45 connector. |
| B | PAR2 | Parallel Communication Port 2 | |
| C | CT | CT Connection Port | Only when using the inverter's built-in meter, connect the CT communication cable. |

| Port (Silkscreen) | | Function | Description |
|-------------------|---------|--|--|
| D | DRM/RCR | RCR, DRED or EnWG 14a Function Connection Port | <ul style="list-style-type: none"> • RCR (Ripple Control Receiver): Provides RCR signal control port to meet the grid dispatch requirements in Europe. • DRED (Demand Response Enabling Device): Provides DRED signal control port to meet DERD certification requirements in regions like Australia. • EnWG (Energy Industry Act) 14a: All controllable loads need to accept grid emergency dimming. Grid operators can temporarily reduce the maximum grid power purchase of controllable loads to 4.2kW. |
| E | METER | Meter Connection Port | Use RS485 communication to connect external smart meter. |
| F | DI | Remote Shutdown / Rapid Shutdown | <ul style="list-style-type: none"> • External Remote Shutdown device, default is off. • In a Rapid Shutdown system, the Rapid Shutdown transmitter and receiver work together to achieve rapid system shutdown. The receiver maintains component output by receiving signals from the transmitter. The transmitter can be external or built into the inverter. In case of emergency, by enabling an external trigger device, the transmitter stops working, thereby shutting down the components. |

| Port (Silkscreen) | | Function | Description |
|-------------------|------|--------------------------------------|--|
| | LOAD | load control | <ul style="list-style-type: none"> • Supports connection to dry contact signals to achieve functions such as load control. DO contact capacity is 24V DC@1A, NO/COM normally open contacts. • Supports SG Ready heat pump access, controlling the heat pump via dry contact signals. |
| | GEN | Generator Control Port | Supports connecting generator control signals to control generator start/stop. In microgrid scenarios, connecting generators is not supported. |
| G | EMS | EMS/Charging Pile Communication Port | <ul style="list-style-type: none"> • Connect third-party EMS devices for energy control • Only in standalone scenarios, supports connecting GoodWe charging piles. |
| H | SW1 | - | - |
| I | SW2 | - | - |

Method for Connecting the Communication Cable



6 System Commissioning

6.1 Check Before Power ON

| No. | Inspection items |
|-----|---|
| 1 | The equipment is firmly installed, easy to operate and maintain, with sufficient space for ventilation and heat dissipation, and the environment is clean and tidy. |
| 2 | PE cable, DC cables, AC cables, and Communication cable are correctly and securely connected. |
| 3 | The cable ties meet the wiring requirements, are reasonably distributed, and show no signs of damage. |
| 4 | Unused through-holes and port must be reliably connected using the provided terminal accessories and properly sealed. |
| 5 | Ensure that all used wire feed-through holes are properly sealed. |
| 6 | The voltage and Frequency of the Inverter on-grid access point comply with the on-grid requirements. |

6.2 Power ON

WARNING


- Battery black start: When there is no PV power generation in the photovoltaic system and the grid is abnormal, if the inverter cannot work normally, the battery black start function can be used to force battery discharge to start the inverter. The inverter can enter off-grid mode operation, and the battery supplies power to the load.
- After the battery system is started, please ensure that the inverter and battery system communicate normally within 15 minutes. If the inverter and battery system cannot communicate normally, the battery system switch will automatically disconnect, and the battery system will be powered off.
- When the inverter is working normally, please set the manual transfer switch to the BACK-UP position to engage, and power the load from the inverter BACK-UP port.
- PV strings and “5” are only applicable to the ETA series.

NOTICE

During the initial system power-on, it is recommended to perform a battery black start once. Close the battery power switch and briefly press the multifunction button on one of the batteries. Observe whether the inverter SOC indicator light illuminates. If the indicator light is on, it indicates the battery is connected properly, and you can proceed to close the DC switch of the inverter.

power on


Single System Scenario:



ESA20PWR0003

1. Close the battery power switch and briefly press the battery's multifunction button. When there are multiple batteries in the system, close the power switches of all batteries. Briefly pressing the multifunction button on any one battery will start all batteries.
2. Close the inverter's DC switch.
3. Close the breaker between the PV components and the inverter.
4. In a parallel system, close the GRID breaker.
5. Set the manual transfer switch to the BACK-UP position to engage it, supplying power to the loads from the BACK-UP port. Close the BACK-UP breaker.

parallel system:




1. Close the battery power switch and briefly press the battery's multifunction button. When there are multiple batteries in the system, close the power switches of all batteries. Briefly pressing the multifunction button on any one battery will start all batteries.
2. Close the inverter's DC switch.
3. (Optional) Close the breaker between the PV components and the inverter.
4. Close the GRID breaker from the inverter.
5. Close the main inverter GRID breaker.
6. Close the BACK-UP breaker.

Battery Black Start

1. Close the battery power switch. When there are multiple batteries in the system, close the power switches of all batteries.
2. Close the inverter's DC switch.
3. (Optional) Close the breaker between the PV components and the inverter.
4. Close the GRID breaker.
5. Close the BACK-UP breaker.
6. After all batteries are powered on separately, wait for 15 seconds, then press and hold the multifunction button on any one battery for 2 seconds to force the battery to discharge and activate the inverter.

6.3 Installing the Protective Cover




Step 1: Install the inverter top cover. Align the cover with the installation slot on the top of the inverter and slide it forward.

Step 2: Install the side cover. Place the side cover into the slot on the side of the battery and push it forward.

Step 3: (Optional) If using side cable routing, install the cable cover.

6.4 Indicators



6.4.1 Inverter Indicators








Breathing Light:

- When the system is upgrading: The breathing light is a green running light; the head of the running light is the brightest and the tail is the dimmest. The length of the running light and the upgrade percentage are influenced by the SEMS+ App settings and the device's operational status.
- Except for inverter upgrade, system fault, and inverter power-off states, the breathing light status is influenced by the App settings in the SEMS+ App. For setup instructions, please refer to the SEMS+ App User Manual.

| indicator | indicator status | breathing light status | description |
|---|---|---|---|
|  |  | <ul style="list-style-type: none"> • 3min/always on: blue-purple chasing light stays on | The inverter is powered on and in standby mode |
| |  | <ul style="list-style-type: none"> • always off: not lit | The inverter is starting up and in self-test mode |
| |  | <ul style="list-style-type: none"> • 3min: blue-purple breathing for 3min then off • Always on in App: blue-purple breathing stays on • Always off in App: not lit | The inverter is operating normally in grid-tied power generation or off-grid mode |

| indicator | indicator status | breathing light status | description |
|---|---|---|---|
| |  | red flashing | system fault |
| |  | off | The inverter is powered off |
|  |  | / | Inverter monitoring module is resetting |
| |  | | Inverter and communication terminal have not established a connection |
| |  | | Communication fault between communication terminal and cloud server |
| |  | | Inverter monitoring is normal |
| |  | | Inverter monitoring module is not started |
| |  |  | |
|  | | | Grid normal, inverter BACK-UP port power supply is normal |
|  | | | BACK-UP port has no power supply |
|  | | | system upgrade |
|  | | | system fault |

| indicator | indicator status | breathing light status | description |
|--|---|------------------------|---|
| |  | | system overload |
|  |  | | battery has no power |
| |  | | constantly lit: Charge flashing: Discharge battery SOC: $0\% < SOC \leq 25\%$ |
| |  | | constantly lit: Charge flashing: Discharge battery SOC: $25\% < SOC \leq 50\%$ |
| |  | | constantly lit: Charge flashing: Discharge battery SOC: $50\% < SOC \leq 75\%$ |
| |  | | constantly lit: Charge flashing: Discharge battery SOC: $75\% < SOC \leq 100\%$ |

6.4.2 Battery Indicators

Button Indicator Light

| No. |  Green Light |  Red Light | Battery System Status | Description |
|-----|--|--|---------------------------|---|
| 1 | Steady On | -- | System operating normally | Run |
| 2 | Blinking 1 time/S | | System ready | Standby |
| | Blinking 3 times/S | -- | PCS communication lost | -- |
| 3 | Blinking 1 time/2S | -- | System alarm | Includes Level 2 faults from the fault list, where under-voltage fault is at Level 2, 3, or 4 |
| 4 | -- | Steady On | System fault | Level 3 and above faults in the fault list (steady on when under-voltage fault is Level 5) |

6.4.3 Smart Meter Indicator Lights GM330&GMK330

6.4.3.1 Indicator Light Description

| Type | Status | Description |
|--|-----------|--|
|  Power Light | Steady On | The meter is powered on, with no RS485 communication. |
| | Blinking | The meter is powered on, with normal RS485 communication. |
| | Off | The meter is powered off. |
|  Comm Light | Off | Reserved. |
| | Blinking | Press and hold the Reset button for ≥5s, and the Power Light and Buy/Sell Power Light blink: The meter is resetting. |
| | Steady On | buy power from the grid. |

| Type | Status | Description |
|--|-----------|------------------------------|
|  Buy/Sell Power Light | Blinking | Selling power to the grid. |
| | Off | Not buying or selling power. |
|  Buy/Sell Power Light (GMK360 only) | Steady On | buy power from the grid. |
| | Blinking | Selling power to the grid. |
| | Off | Not buying or selling power. |

6.4.4 Smart Dongle Indicator


- WiFi/LAN Kit-20

NOTICE

- After double-clicking the Reload button to turn on Bluetooth, the communication indicator light will switch to a single-blink state. Please connect to the SEMS+ App within 5 minutes, otherwise Bluetooth will automatically turn off.
- The communication indicator light's single-blink state only appears after double-clicking the Reload button to turn on Bluetooth.

| Indicator | Status | Description |
|--|---|---|
| Power indicator  |  | Steady on: The Smart Communication Stick is powered on. |
| |  | Off: The Smart Communication Stick is not powered on. |
| Communi- cation indicator  |  | Steady on: Communication is normal in WiFi mode or LAN mode. |
| |  | Single blink: The Smart Communication Stick's Bluetooth signal is enabled, waiting to connect to the SEMS+ App. |

| Indicator | Status | Description |
|-----------|---|---|
| |  | Two blinks: The Smart Communication Stick has not connected to the router. |
| |  | Four blinks: The Smart Communication Stick communicates normally with the router but has not connected to the server. |
| |  | Six blinks: The Smart Communication Stick is identifying connected devices. |
| |  | Off: The Smart Communication Stick is undergoing a software reset or is not powered on. |

| Indicator | Color | Status | Description |
|---|--------|-----------|--|
| LAN port communication indicator  | Green | Steady on | 100Mbps wired network connection is normal. |
| | | Off | <ul style="list-style-type: none"> • Network cable is not connected. • 100Mbps wired network connection is abnormal. • 10Mbps wired network connection is normal. |
| | Yellow | Steady on | 10/100Mbps wired network connection is normal, with no communication data being transmitted or received. |
| | | Flashing | Communication data is being transmitted or received. |
| | | Off | Network cable is not connected. |

| Button | Description |
|--------|--|
| Reload | Hold for 0.5 to 3 seconds to reset the Smart Communication Stick. |
| | Hold for 6 to 20 seconds to restore the Smart Communication Stick to factory settings. |
| | Double-click quickly to enable Bluetooth signal (maintained for only 5 minutes). |

7 System Commissioning

7.1 Setting Inverter Parameters via App

SEMS+ App is a software used for remote power plant monitoring or local device debugging. It supports installers or owners to:

- Remotely monitor the operation status of the power plant and set operation parameters for the plant and devices.
- Locally connect to devices to view their operation status and set device parameters.

For detailed functions, please refer to the "[SEMS+ App User Manual](#)". The user manual can be obtained from the official website or by scanning the QR code below.



SEMS+ App User Manual

7.1.1 Download and Install SEMS+ App

Phone Requirements:

- Operating System: Android 7.0 or above, iOS 15.1 or above.
- Phone must support a web browser and connect to the Internet.
- Phone must support WLAN/Bluetooth functionality.

Download Methods:

Method 1:

Search for "SEMS+" in Google Play, App Store, Huawei, Honor, Xiaomi, OPPO, or vivo app stores to download and install.



Method 2:

Scan the QR code below to download and install.



7.2 Monitoring power stations via SEM+ WEB

SEM+ WEB is a monitoring platform that can communicate via WiFi or LAN. The following are the common functions of SEM+ WEB:

- 1. Manage organization or user information, etc.
- 2. Add and monitor power station information, etc.
- 3. Maintain equipment.

For detailed functions, please refer to the [SEM+ WEB User Manual](#).



SEM+ WEB User Manual

8 Maintenance

8.1 Power OFF the System

DANGER

- When performing operation and maintenance on equipment in the system, please power off the system. Operating equipment with power on may cause equipment damage or electric shock DANGER.
- After the equipment is powered off, internal components require some time to discharge. Please wait until the equipment is completely discharged according to the label time requirements.
- Restarting the battery should be done using the air switch power-on method.
- When shutting down the battery system, strictly adhere to the battery system power-off requirements to prevent damage to the battery system.

WARNING


During inverter power-off maintenance or in case of a fault, to ensure normal operation of the load, please switch the manual transfer switch to the grid side to engage, allowing the grid to supply power to the load.

NOTICE

- To ensure effective protection of the battery system, keep the cover plate of the battery system switch closed. If the battery system switch will not be used for an extended period, secure it with screws.
- PV strings and "5" are only applicable to the ETA series.

Power off


Single system scenario:



ESA20PWR0003

1. Disconnect the BACK-UP circuit breaker.
2. Disconnect the GRID circuit breaker.
3. Press and hold any battery multi-function button for 5 seconds to power off the battery system. If the system contains multiple batteries, this operation will power off all batteries; there is no need to operate them one by one. Finally, disconnect the battery system switch.
4. (Optional) Disconnect the circuit breaker between the PV components and the inverter.
5. Disconnect the DC switch of the inverter. Set the manual transfer switch to the grid side to engage, allowing the grid to supply power to the loads.

Parallel system:



1. Disconnect the BACK-UP circuit breaker.
2. Disconnect the GRID circuit breaker from the inverter.
3. Disconnect the main inverter GRID circuit breaker.
4. Press and hold any battery multi-function button for 5 seconds to power off the battery system. If the system contains multiple batteries, this operation will power off all batteries; there is no need to operate them one by one. Finally, disconnect the battery system switch.
5. (Optional) Disconnect the circuit breaker between the PV components and the inverter.
6. Disconnect the DC switch of the inverter.

8.2 Removing the Equipment



- Ensure the device is powered off.
- When operating the device, please wear personal protective equipment.
- When removing wiring terminals, use standard disassembly tools to avoid damaging the terminals or device.
- Unless otherwise specified, the device disassembly method is the reverse order of the installation method, and this document will not elaborate further.

1. Power down the system.
2. Label the cables connected in the system to indicate their types.
3. Disconnect the cables from the Inverter, Battery, and smart meter in the system, such as DC cables, AC cables, Communication cable, and PE cable.
4. Remove equipment such as the smart communication stick, Inverter, Battery, and smart meter.
5. Store the equipment properly. If it will be put into use again later, ensure the storage conditions meet the requirements.

8.3 Disposing of the Equipment

When the equipment can no longer be used and needs to be disposed of, please handle it according to the electrical waste disposal requirements of the regulations in the country/region where the equipment is located. The equipment must not be disposed of as general household waste.

8.4 Routine Maintenance



- If any issues that may affect the Battery or hybrid inverter system are discovered, please contact after-sales personnel. Unauthorized disassembly is strictly prohibited.
- If exposed copper wires are found inside the conductive line, do not touch them. High voltage DANGER, please contact after-sales personnel. Unauthorized disassembly is prohibited.
- In case of any other emergencies, please contact the after-sales personnel immediately. Follow their instructions for operation or wait for on-site assistance from the after-sales team.


| Maintenance Content | Maintenance method | Maintenance cycle | Maintenance purpose |
|-----------------------|---|--------------------------------------|---|
| System cleaning | <p>Check for any foreign objects or dust in the heat sink and air inlet/outlet.</p> <p>Check if the Installation space meets the requirements, and inspect whether there is any debris accumulation around the equipment.</p> | Once every six months | Prevent heat dissipation. |
| System Installation | <p>Check whether the equipment Installation is secure and whether the fasteners screw are loose.</p> <p>Inspect the equipment for any damage or deformation on the exterior.</p> | Once every six months to once a year | Verify the stability of the Installation equipment. |
| Electrical connection | Check for loose electrical connections, damaged cable insulation, or exposed copper conductors. | Once every six months to once a year | Verify the reliability of electrical connections. |

| Maintenance Content | Maintenance method | Maintenance cycle | Maintenance purpose |
|---------------------|---|-------------------|--|
| fan | Check if the fan has any abnormal noise; Check the fan blades for cracks; Check if the fan has abnormal blockage or stalling; | 1 time/half year | Prevent fan fault. |
| Sealing | Check whether the cable entry hole Sealing of the equipment meets the requirements. If the gap is too large or unsealed, resealing is required. | Once per year | Verify that the machine's sealing and waterproof performance are intact. |
| Battery maintenance | If the Battery has not been used or fully charged for a long time, it is recommended to perform Charge on the Battery regularly. | Once/15 days | Protection Battery service life. |


Fan maintenance can be specifically referred to the following steps:

There is a fan module on the exterior of Inverter. To clean the fan module more effectively, remove it from the machine before cleaning. The specific steps are as follows:

1. Inverter power off, refer to [8.1. Power OFF the System \(Page 145\)](#).
2. Wait for the residual voltage in the system to be fully discharged and the fan module to completely stop operating.
3. Use screwdriver dismantle module to lock screw, and remove the entire fan module.
4. Clean the fan using a soft brush, cloth, or vacuum cleaner.



After cleaning, reinstall the fan module back into the machine.



8.5 fault

8.5.1 Viewing Fault/Alarms Information

Detailed information for all faults and alarms in the energy storage system is displayed in the **SEMS+ App and SEMS+ WEB**. If your product experiences an abnormality and no related fault information is seen in the **SEMS+ App or SEMS+ WEB**, please contact the after-sales service center.

- In SEMS+ App

1. Open the SEMS+ App and log in with any account.
2. On the homepage, click "Alarms" to view alarm information for all power plants under the account.

- SEMS+ WEB

1. Open the SEMS+ WEB and log in with any account.
2. On the power plant details interface, click "Alarms" to view all alarm information for the current power plant.

8.5.2 Fault Information and Troubleshooting

Please perform troubleshooting according to the following methods. If the troubleshooting methods cannot help you, please contact the after-sales service center.

When contacting the after-sales service center, please collect the following information to facilitate a quick resolution.

1. Product information, such as: serial number, software version, device installation time, fault occurrence time, fault frequency, etc.
2. Device installation environment, such as: weather conditions, whether components are blocked, have shadows, etc. It is recommended to provide photos, videos, and other files to assist in problem analysis.
3. Grid conditions.

If the system experiences a problem not listed, or if following the instructions still cannot prevent the problem or abnormality, immediately stop system operation and contact your dealer immediately.

| No. | fault | Resolution |
|-----|--|---|
| 1 | Unable to search for the Smart Communication Stick's wireless signal | <ol style="list-style-type: none"> 1. Ensure no other devices are connected to the Smart Communication Stick's wireless signal. 2. Ensure the Smart Communication Stick is powered normally, with the blue signal light flashing or steady on. 3. Ensure the smart device is within the communication range of the Smart Communication Stick. 4. Refresh the App device list again. 5. Restart the inverter. |

| No. | fault | Resolution |
|-----|---|---|
| 2 | Unable to connect to the Smart Communication Stick's wireless signal | <ol style="list-style-type: none"> 1. Ensure no other devices are connected to the Smart Communication Stick's wireless signal. 2. Restart the inverter or the communication stick, then try connecting to the Smart Communication Stick's wireless signal again. 3. Ensure Bluetooth pairing and encryption were successful. |
| 3 | Unable to find the router's SSID | <ol style="list-style-type: none"> 1. Place the router closer to the Smart Communication Stick, or add a WiFi repeater to enhance the WiFi signal. 2. Reduce the number of devices connected to the router. |
| 4 | After all configuration is complete, the Smart Communication Stick fails to connect to the router | <ol style="list-style-type: none"> 1. Restart the inverter. 2. Check if the network name, encryption method, and password in the WiFi configuration match those of the router. 3. Restart the router. 4. Place the router closer to the Smart Communication Stick, or add a WiFi repeater to enhance the WiFi signal. |
| 5 | After all configuration is complete, the Smart Communication Stick fails to connect to the server | Restart the router and the inverter. |

8.5.2.1 Inverter Fault

8.5.2.1.1 Troubleshooting (Fault Codes F01-F40)

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|-----------------------------|---|---|
| F01 | Grid Power Outage | <ol style="list-style-type: none"> 1. Grid power outage. 2. AC line or AC switch is disconnected. | <ol style="list-style-type: none"> 1. The alarm will disappear automatically after grid power is restored. 2. Check if the AC line or AC switch is disconnected. |
| F02 | Grid Overvoltage Protection | Grid voltage exceeds the allowable range, or the high-voltage duration exceeds the HVRT setting value. | <ol style="list-style-type: none"> 1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention. 2. If it occurs frequently, check if the grid voltage is within the allowable range. If not, contact the local power operator. If it is, you also need to modify the grid overvoltage protection point after obtaining consent from the local power operator. 3. If it cannot be restored for a long time, check if the AC side circuit breaker and output cables are properly connected. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|------------------------------|--|--|
| F03 | Grid Undervoltage Protection | Grid voltage is below the allowable range, or the low-voltage duration exceeds the LVRT setting value. | <ol style="list-style-type: none"> 1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention. 2. If it occurs frequently, check if the grid voltage is within the allowable range. If not, contact the local power operator. If it is, you also need to modify the grid undervoltage protection point after obtaining consent from the local power operator. 3. If it cannot be restored for a long time, check if the AC side circuit breaker and output cables are properly connected. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|-----------------------------------|--|---|
| F04 | Grid Rapid Overvoltage Protection | Abnormal grid voltage detection or ultra-high voltage triggers the fault. | <p>1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, check if the grid voltage is within the allowable range. If not, contact the local power operator. If it is, you also need to modify the grid undervoltage protection point after obtaining consent from the local power operator.</p> <p>3. If it cannot be restored for a long time, check if the AC side circuit breaker and output cables are properly connected.</p> |
| F05 | 10min Overvoltage Protection | The moving average of grid voltage within 10min exceeds the safety regulation specified range. | Check if the grid voltage has been operating at a high level for a long time. If it occurs frequently, check if the grid frequency is within the allowable range. If not, contact the local power operator. If it is, you also need to modify the grid 10min overvoltage protection point after obtaining consent from the local power operator. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|---------------------|--|---|
| F06 | Grid Overfrequency | Grid anomaly: The actual grid frequency is higher than the local grid standard requirements. | <p>1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, check if the grid frequency is within the allowable range. If not, contact the local power operator. If it is, you also need to modify the grid overfrequency protection point after obtaining consent from the local power operator.</p> |
| F07 | Grid Underfrequency | Grid anomaly: The actual grid frequency is lower than the local grid standard requirements. | <p>1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, check if the grid frequency is within the allowable range. If not, contact the local power operator. If it is, you also need to modify the grid overfrequency protection point after obtaining consent from the local power operator.</p> |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|----------------------------|--|--|
| F08 | Grid Frequency Instability | Grid anomaly: The rate of change of the actual grid frequency does not comply with local grid standards. | <p>1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, check if the grid frequency is within the allowable range. If not, contact the local power operator.</p> |
| F09 | Anti-islanding Protection | The grid has been disconnected, but grid voltage is maintained due to the presence of loads. Grid connection is stopped according to safety protection requirements. | <p>1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, check if the grid frequency is within the allowable range. If not, contact the local power operator.</p> |
| F10 | LVRT Undervoltage Fault | Grid anomaly: The duration of abnormal grid voltage exceeds the time specified by the HVRT/LVRT. | <p>1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, check if the grid voltage and frequency are within the allowable range and stable. If not, contact the local power operator.</p> |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|----------------------|--|--|
| F11 | HVRT Overvoltage | Grid anomaly: The duration of abnormal grid voltage exceeds the time specified by the HVRT/LVRT. | <p>1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, check if the grid voltage and frequency are within the allowable range and stable. If not, contact the local power operator.</p> |
| F12 | 30mA GFCI Protection | The input-to-ground insulation impedance becomes low during inverter operation. | <p>1. If it occurs occasionally, it may be caused by occasional external line anomalies. It will resume normal operation after the fault is cleared, requiring no manual intervention.</p> <p>2. If it occurs frequently or cannot be restored for a long time, check if the PV string's impedance to ground is too low.</p> |
| F13 | 60mA GFCI Protection | The input-to-ground insulation impedance becomes low during inverter operation. | <p>1. If it occurs occasionally, it may be caused by occasional external line anomalies. It will resume normal operation after the fault is cleared, requiring no manual intervention.</p> <p>2. If it occurs frequently or cannot be restored for a long time, check if the PV string's impedance to ground is too low.</p> |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|--------------------------------|--|---|
| F14 | 150mA GFCI Protection | The input-to-ground insulation impedance becomes low during inverter operation. | <p>1. If it occurs occasionally, it may be caused by occasional external line anomalies. It will resume normal operation after the fault is cleared, requiring no manual intervention.</p> <p>2. If it occurs frequently or cannot be restored for a long time, check if the PV string's impedance to ground is too low.</p> |
| F15 | GFCI Gradual Change Protection | The input-to-ground insulation impedance becomes low during inverter operation. | <p>1. If it occurs occasionally, it may be caused by occasional external line anomalies. It will resume normal operation after the fault is cleared, requiring no manual intervention.</p> <p>2. If it occurs frequently or cannot be restored for a long time, check if the PV string's impedance to ground is too low.</p> |
| F16 | DCI Level 1 Protection | The DC component of the inverter output current is higher than the safety regulation or the machine's default allowable range. | <p>1. If it is caused by an external fault, the inverter will automatically resume normal operation after the fault disappears, requiring no manual intervention.</p> <p>2. If this alarm occurs frequently, affecting the normal power generation of the power station, contact the distributor or after-sales service center.</p> |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|------------------------|--|--|
| F17 | DCI Level 2 Protection | The DC component of the inverter output current is higher than the safety regulation or the machine's default allowable range. | <ol style="list-style-type: none"> 1. If it is caused by an external fault, the inverter will automatically resume normal operation after the fault disappears, requiring no manual intervention. 2. If this alarm occurs frequently, affecting the normal power generation of the power station, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|---------------------------|--|---|
| F18 | Low Insulation Resistance | <ol style="list-style-type: none"> 1. PV string shorted to protective earth. 2. The PV string installation environment is long-term humid and the line has poor insulation to ground. 3. Battery port line has low impedance to ground. | <ol style="list-style-type: none"> 1. Check the impedance of the PV string/battery port to protective earth. A value greater than 80kΩ is normal. If the checked value is less than 80kΩ, locate and rectify the short-circuit point. 2. Check if the inverter's protective earth wire is correctly connected. 3. If it is confirmed that the impedance is indeed lower than the default value in rainy/overcast environments, reset the inverter's "Insulation Impedance Protection Point" via the App. <p>For inverters in the Australian and New Zealand markets, the following additional alarm methods apply when an insulation impedance fault occurs:</p> <ol style="list-style-type: none"> 1. The inverter is equipped with a buzzer. When a fault occurs, the buzzer sounds continuously for 1 minute; if the fault is not resolved, the buzzer sounds again every 30 minutes. 2. If the inverter is added to the monitoring platform and alarm notification methods are set, alarm information can be sent to the customer via email. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|-----------------------------------|---|--|
| F19 | Grounding Abnormal | <ol style="list-style-type: none"> 1. The inverter's protective earth wire is not connected. 2. When the PV string output is grounded, the inverter output side is not connected to an isolation transformer. | <ol style="list-style-type: none"> 1. Confirm if the inverter's protective earth wire is not properly connected. 2. In scenarios where the PV string output is grounded, confirm if the inverter output side is connected to an isolation transformer. |
| F20 | Hardware Anti-backfeed Protection | Load abnormal fluctuation | <ol style="list-style-type: none"> 1. If it is caused by an external fault, the inverter will automatically resume normal operation after the fault disappears, requiring no manual intervention. 2. If this alarm occurs frequently, affecting the normal power generation of the power station, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|--------------------|---|---|
| F21 | Internal Comm Loss | Sub DSP1 communication timeout - Main DSP, Sub DSP2 communication timeout - Main DSP, Sub DSP2 communication timeout - Sub DSP1, Main DSP communication timeout - Sub DSP1, Main DSP communication timeout - Sub DSP2 or Sub DSP1 communication timeout - Sub DSP2: 1. Chip not powered on 2. Chip program version error | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|------------------------------------|--|-----------------------------|
| | | Main DSP can module error, Sub DSP1 can module error or Sub DSP2 can module error: 1. Frame format error 2. Parity check error 3. can bus offline 4. Hardware CRC check error 5. Control bit is receive (transmit) during transmission (reception) 6. Transmission to an unauthorized unit | |
| F22 | Generator Waveform Detection Fault | 1. This fault will be displayed continuously when the generator is not connected; 2. When the generator is operating, failure to meet generator safety regulations will trigger this fault. | |
| F23 | Generator Abnormal Connection | | |
| F24 | Generator Voltage Low | | |
| F25 | Generator Voltage High | | |
| F26 | Generator Frequency Low | | |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|----------------------------------|---|---|
| F27 | Generator Frequency High | | <p>1. Ignore this fault when the generator is not connected;</p> <p>2. When this fault occurs due to a generator fault, it is normal. Wait for a period after the generator recovers, and the fault will clear automatically;</p> <p>3. This fault does not affect the normal operation of off-grid mode.</p> <p>4. When both the generator and grid are connected and meet safety requirements, the grid has priority for grid connection, and the system will operate in grid-connected status.</p> |
| F28 | Parallel I/O Self-check Abnormal | Parallel communication cable is not securely connected or parallel IO chip is damaged | Check if the parallel communication cable is securely connected, then check if the IO chip is damaged. If yes, replace the IO chip. |
| F29 | Paralell Grid Line Reversed | Some machines' grid lines are connected in reverse with others | Reconnect the grid lines correctly. |
| F30 | AC HCT check Abnormal | AC sensor has sampling abnormality | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|---------------------------|--|---|
| F31 | GFCI HCT Check Abnormal | Leakage current sensor has sampling abnormality | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |
| F32 | Inverter Internal Failure | Inverter has a fault | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |
| F33 | Flash Read/Write Error | Possible causes: flash content changed; flash lifespan exhausted; | <ol style="list-style-type: none"> 1. Upgrade to the latest program version. 2. Contact the distributor or after-sales service center. |
| F34 | AFCI Check Failure | During the arc self-check process, the arc detection module did not detect an arc fault as expected. | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|-------------------------|--|--|
| F35 | Cabinet Overtemperature | Cabinet temperature is too high, possible causes: 1. Inverter installation location is not ventilated. 2. Ambient temperature is too high. 3. Internal fan operation is abnormal. | 1. Check if the ventilation at the inverter installation location is good and if the ambient temperature exceeds the maximum allowable ambient temperature range. 2. If ventilation is poor or ambient temperature is too high, improve its ventilation and heat dissipation conditions. 3. If ventilation and ambient temperature are both normal, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|-----------------|---|---|
| F36 | Bus Overvoltage | BUS overvoltage, possible causes: 1. PV voltage is too high; 2. Inverter BUS voltage sampling is abnormal; 3. The isolation effect of the dual-split transformer at the inverter rear end is poor, causing mutual influence when two inverters are connected in parallel, with one inverter reporting DC overvoltage during grid connection; | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|------------------------------------|---|---|
| F37 | PV Input Overvoltage | PV input voltage is too high, possible cause: PV array configuration error, too many PV panels connected in series per string, causing the string's open-circuit voltage to be higher than the inverter's maximum operating voltage. | Check the series configuration of the corresponding PV array string to ensure the string's open-circuit voltage is not higher than the inverter's maximum operating voltage. After the PV array is correctly configured, the inverter alarm will disappear automatically. |
| F38 | PV Continuous Hardware Overcurrent | 1. Module configuration unreasonable. 2. Hardware damaged. | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |
| F39 | PV Continuous Software Overcurrent | 1. Module configuration unreasonable. 2. Hardware damaged. | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|-------------------|---|------------------------------|---|
| F40, F98 | String Reverse Connection (String 1-n) n: Determined based on the actual number of inverter strings. | PV string reverse connection | Check if the string is reversely connected. |

8.5.2.1.2 Troubleshooting (Fault Codes F41-F80)

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|-------------------------|---|--|
| F41 | Generator Port Overload | <ol style="list-style-type: none"> 1. Off-grid side output exceeds specification requirements. 2. Off-grid side short circuit. 3. Off-grid terminal voltage is too low. 4. When used as a heavy load port, the heavy load exceeds specification requirements. | <ol style="list-style-type: none"> 1. Confirm the off-grid side output voltage, current, power and other data to identify the cause of the problem. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|--|---|--|
| F42 | DC Arcing Failure (String 1-n) n: Determined by the actual number of inverter strings. | <ol style="list-style-type: none"> 1. Loose DC side connection terminals. 2. Poor contact at DC side connection terminals. 3. Damaged DC cable cores causing poor contact. | <ol style="list-style-type: none"> 1. After the unit reconnects to the grid, check if the voltage and current of each string abnormally decrease or become zero. 2. Check if the DC side terminals are securely connected. |
| F43 | Grid Waveform Abnormal | Utility grid abnormality: Abnormal grid voltage detection triggers the fault. | <ol style="list-style-type: none"> 1. If it occurs occasionally, it may be due to a short-term grid abnormality. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention. 2. If it occurs frequently, please check if the grid voltage and frequency are within the allowable range and stable. If not, please contact the local power operator. |
| F44 | Grid Phase Loss | Utility grid abnormality: Single-phase voltage dip on the grid. | <ol style="list-style-type: none"> 1. If it occurs occasionally, it may be due to a short-term grid abnormality. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention. 2. If it occurs frequently, please check if the grid voltage and frequency are within the allowable range and stable. If not, please contact the local power operator. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|---|---|---|
| F45 | Grid Voltage Imbalance | Excessive difference in grid phase voltages. | <p>1. If it occurs occasionally, it may be due to a short-term grid abnormality. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, please check if the grid voltage and frequency are within the allowable range and stable. If not, please contact the local power operator.</p> |
| F46 | Grid Phase Sequence Failure | Inverter and grid wiring abnormality: Wiring is not in positive sequence. | <p>1. Check if the inverter and grid wiring are in positive sequence. The fault will automatically disappear after correct wiring (e.g., swapping any two live wires).</p> <p>2. If the fault persists despite correct wiring, please contact the dealer or after-sales service center.</p> |
| F47 | Grid Rapid Shutdown Protection | Quickly shuts down output after detecting a grid power outage condition. | The fault automatically disappears after grid power supply is restored. |
| F48 | Grid Neutral Wire Loss (Split-phase Grid) | Loss of neutral wire in a split-phase grid. | <p>1. The alarm automatically disappears after grid power supply is restored.</p> <p>2. Check if the AC line or AC switch is disconnected.</p> |
| F49 | L-PE Short Circuit | Low impedance or short circuit between output phase line and PE. | Measure the impedance between the output phase line and PE, locate the position with low impedance and repair it. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|--|--|---|
| F50 | DCV Level 1 Protection | Abnormal load fluctuation. | <p>1. If it is caused by an external fault, the inverter will automatically resume normal operation after the fault disappears, requiring no manual intervention.</p> <p>2. If this alarm occurs frequently, affecting normal power generation of the plant, please contact the dealer or after-sales service center.</p> |
| F51 | DCV Level 2 Protection | Abnormal load fluctuation. | |
| F52 | Leakage Current (GFCI) Multiple Fault Shutdown | North American safety regulations require manual reset or waiting 24h for recovery after multiple faults, no automatic recovery. | Please check if the PV string-to-ground impedance is too low. |
| F53 | DC Arcing (AFCI) Multiple Fault Shutdown | North American safety regulations require manual reset or waiting 24h for recovery after multiple faults, no automatic recovery. | <p>1. After the unit reconnects to the grid, check if the voltage and current of each string abnormally decrease or become zero.</p> <p>2. Check if the DC side terminals are securely connected.</p> |
| F54 | External Communication Link Failure | External device communication loss for the inverter. Possible causes: peripheral power issue, communication protocol mismatch, corresponding peripheral not configured, etc. | Determine based on the actual model and enabled detection bits. Peripherals not supported by certain models will not be detected. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|--|--|---|
| F55 | Back-up Port Overload Fault | Prevents the inverter from continuously outputting overload. | Turn off some off-grid loads to reduce the inverter's off-grid output power. |
| F56 | Back-up Port Overvoltage Fault | Prevents inverter output overvoltage from damaging loads. | 1. If it occurs occasionally, it may be caused by load switching and requires no manual intervention. 2. If it occurs frequently, please contact the dealer or after-sales service center. |
| F57 | External Box Fault | Waiting too long for Box relay switching during grid-to-off-grid transition. | 1. Check if the Box is working normally. 2. Check if the Box communication wiring is correct. |
| F58 | CT Loss Fault | CT connection wire disconnected (Japanese safety regulation requirement). | Check if the CT wiring is correct. |
| F59 | Parallel CAN Communication Abnormality | Parallel communication cable not securely connected or some units are offline. | Check if all units are powered on and if the parallel communication cables are securely connected. |
| F60 | Parallel Back-up Connection Reversed | Backup wiring of some units is reversed with others. | Reconnect the backup wiring. |
| F61 | Inverter Soft Start Failure | Inverter soft start failure during off-grid cold start. | Check if the inverter module is damaged. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|-----------------------------|--|--|
| F62 | AC HCT Failure | HCT sensor abnormality exists. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F63 | GFCI HCT Failure | Leakage current sensor abnormality exists. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F64 | Inverter Internal Failure | Inverter fault exists. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F65 | AC Terminal Overtemperature | AC terminal temperature is too high. Possible causes: 1. Inverter installation location lacks ventilation. 2. Ambient temperature is too high. 3. Internal fan operation is abnormal. | 1. Check if the ventilation at the inverter installation location is adequate and if the ambient temperature exceeds the maximum allowable range. 2. If ventilation is poor or ambient temperature is too high, improve its ventilation and heat dissipation conditions. 3. If both ventilation and ambient temperature are normal, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|------------------------------|--|--|
| F66 | INV Module Overtemperature | Inverter module temperature is too high. Possible causes: 1. Inverter installation location lacks ventilation. 2. Ambient temperature is too high. 3. Internal fan operation is abnormal. | 1. Check if the ventilation at the inverter installation location is adequate and if the ambient temperature exceeds the maximum allowable range. 2. If ventilation is poor or ambient temperature is too high, improve its ventilation and heat dissipation conditions. 3. If both ventilation and ambient temperature are normal, please contact the dealer or after-sales service center. |
| F67 | Boost Module Overtemperature | Boost module temperature is too high. Possible causes: 1. Inverter installation location lacks ventilation. 2. Ambient temperature is too high. 3. Internal fan operation is abnormal. | 1. Check if the ventilation at the inverter installation location is adequate and if the ambient temperature exceeds the maximum allowable range. 2. If ventilation is poor or ambient temperature is too high, improve its ventilation and heat dissipation conditions. 3. If both ventilation and ambient temperature are normal, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|------------------------------|--|--|
| F68 | AC Capacitor Overtemperature | Output filter capacitor temperature is too high. Possible causes: 1. Inverter installation location lacks ventilation. 2. Ambient temperature is too high. 3. Internal fan operation is abnormal. | 1. Check if the ventilation at the inverter installation location is adequate and if the ambient temperature exceeds the maximum allowable range. 2. If ventilation is poor or ambient temperature is too high, improve its ventilation and heat dissipation conditions. 3. If both ventilation and ambient temperature are normal, please contact the dealer or after-sales service center. |
| F69 | PV IGBT Short Circuit Fault | Possible causes: 1. IGBT short circuit. 2. Inverter sampling circuit abnormality. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F70 | PV IGBT Open Circuit Fault | 1. Software issue causing no PWM generation. 2. Drive circuit abnormality. 3. IGBT open circuit. | |
| F71 | NTC Abnormality | NTC temperature sensor abnormality. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|----------------------------|--|---|
| F72 | PWM Abnormal | Abnormal PWM waveform detected. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F73 | CPU Interrupt Abnormality | CPU interrupt abnormality occurred. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F74 | Microelectronics Fault | Functional safety detection detected an abnormality. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F75 | PV HCT Fault | Boost current sensor abnormality. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F76 | 1.5V Reference Abnormality | Reference circuit fault. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F77 | 0.3V Reference Abnormality | Reference circuit fault. | |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|--------------------------------|--|---|
| F78 | CPLD Version Recognition Error | CPLD version recognition error. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F79 | CPLD Communication Fault | CPLD and DSP communication content error or timeout. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F80 | Model Identification Fault | Fault related to model identification error. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |

8.5.2.1.3 Troubleshooting (Fault Codes F81-F121)

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|-------------------|--------------------|---|
| F81 | P-Bus Overvoltage | | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|------------------------------|---|---|
| F82 | N-Bus Overvoltage | BUS overvoltage, possible causes: 1. PV voltage is too high; 2. Inverter BUS voltage sampling is abnormal; 3. Poor isolation effect of the split-phase transformer at the inverter output, causing mutual interference when two inverters are grid-connected, with one inverter reporting DC overvoltage during grid connection; | |
| F83 | Bus Overvoltage (Sub CPU1) | | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F84 | P-Bus Overvoltage (Sub CPU1) | | |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|------------------------------|---|---|
| F85 | N-Bus Overvoltage (Sub CPU1) | BUS overvoltage, possible causes: 1. PV voltage is too high; 2. Inverter BUS voltage sampling is abnormal; 3. Poor isolation effect of the split-phase transformer at the inverter output, causing mutual interference when two inverters are grid-connected, with one inverter reporting DC overvoltage during grid connection; | |
| F86 | Bus Overvoltage (Sub CPU2) | | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F87 | P-Bus Overvoltage (Sub CPU2) | | |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|------------------------------|---|---|
| F88 | N-Bus Overvoltage (Sub CPU2) | BUS overvoltage, possible causes: 1. PV voltage is too high; 2. Inverter BUS voltage sampling is abnormal; 3. Poor isolation effect of the split-phase transformer at the inverter output, causing mutual interference when two inverters are grid-connected, with one inverter reporting DC overvoltage during grid connection; | |
| F89 | P-Bus Overvoltage (CPLD) | | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|-----------------------------|---|---|
| F90 | N-Bus Overvoltage(CPLD) | BUS overvoltage, possible causes: 1. PV voltage is too high; 2. Inverter BUS voltage sampling is abnormal; 3. Poor isolation effect of the split-phase transformer at the inverter output, causing mutual interference when two inverters are grid-connected, with one inverter reporting DC overvoltage during grid connection; | |
| F91 | FlyCap Software Overvoltage | FlyCap overvoltage, possible causes: 1. PV voltage is too high; 2. Inverter FlyCap voltage sampling is abnormal; | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F92 | FlyCap Hardware Overvoltage | | |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|---------------------------|---|--|
| F93 | FlyCap Undervoltage | FlyCap undervoltage, possible causes: 1. PV energy is insufficient; 2. Inverter FlyCap voltage sampling is abnormal; | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center |
| F94 | FlyCap Precharge Failure | FlyCap precharge failure, possible causes: 1. PV energy is insufficient; 2. Inverter FlyCap voltage sampling is abnormal; | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center |
| F95 | FlyCap Precharge Abnormal | 1. Control loop parameters are unreasonable 2. Hardware damage | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|--|--|--|
| F96, F97 | String Overcurrent(String1-n) n: Determined based on the actual number of inverter strings | Possible causes: 1. String overcurrent; 2. String current sensor is abnormal | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center |
| F99, F100 | String Missing(String1-n) n: Determined based on the actual number of inverter strings | String fuse is open (if present) | Check if the fuse is open. |
| F101 | Battery 1 Precharge fault | Battery 1 precharge circuit fault (precharge resistor burned out, etc.) | Check if the precharge circuit is in good condition, and whether the battery voltage matches the bus voltage after the battery is powered on. If not, please contact the dealer or after-sales service center. |
| F102 | Battery 1 Relay Failure | Battery 1 relay cannot operate normally | After the battery is powered on, check if the battery relay is working, and if a closing sound is heard. If it does not operate, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|----------------------------------|---|---|
| F103 | Battery 1 Connection Overvoltage | Battery 1 connection voltage exceeds the machine's rated range | Confirm if the battery voltage is within the machine's rated range. |
| F104 | Battery 2 Precharge fault | Battery 2 precharge circuit fault (precharge resistor burned out, etc.) | Check if the precharge circuit is in good condition, and whether the battery voltage matches the bus voltage after the battery is powered on. If not, please contact the dealer or after-sales service center. |
| F105 | Battery 2 Relay Failure | Battery 2 relay cannot operate normally | After the battery is powered on, check if the battery relay is working, and if a closing sound is heard. If it does not operate, please contact the dealer or after-sales service center. |
| F106 | Battery 2 Connection Overvoltage | Battery 2 connection voltage exceeds the machine's rated range | Confirm if the battery voltage is within the machine's rated range. |
| F107 | On-grid PWM Sync Failure | Abnormalities occurred during carrier synchronization grid connection | <ol style="list-style-type: none"> 1. Check if the synchronization cable connection is normal 2. Check if the master/slave settings are normal; 3. Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F108 | DSP Communication fault | - | - |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|--------------------------|---|--|
| F109 | External STS fault | Abnormal cable connection between the inverter and the STS | Check if the wiring sequence of the harness between the inverter and the STS corresponds correctly one by one. |
| F110 | Export Limit Protection | <ol style="list-style-type: none"> 1. Inverter reports error and disconnects from grid 2. meter communication is unstable 3. Reverse power flow condition occurs | <ol style="list-style-type: none"> 1. Check if the inverter has other error messages. If yes, perform targeted troubleshooting; 2. Check if the meter connection is reliable; 3.If this alarm occurs frequently, affecting normal power generation of the power station, please contact the dealer or after-sales service center. |
| F111 | Bypass Overload | - | - |
| F112 | Black Start Failure | - | - |
| F113 | Offgrid AC Ins Volt High | - | - |
| F114 | Relay Failure2 | <p>Relay abnormality, causes:</p> <ol style="list-style-type: none"> 1. Relay abnormality (relay short circuit) 2. Relay sampling circuit is abnormal. 3. AC side wiring is abnormal (there may be poor connection or short circuit) | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|------------------------------------|--|---|
| F115 | SVG Precharge Disabled | SVG precharge hardware failure | Contact the dealer or after-sales service center. |
| F116 | Nighttime SVG PID Prevention fault | PID prevention hardware abnormality | |
| F117 | DSP Version Recognition Error | DSP software version recognition error | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F118 | MOS Continuous Overvoltage | <ol style="list-style-type: none"> 1. Software issue causing inverter drive to turn off earlier than flyback drive; 2. Inverter drive circuit abnormal causing failure to turn on; 3. PV voltage is too high; 4. Mos voltage sampling is abnormal; | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F119 | Bus Short Circuit fault | Hardware damage | If the inverter remains offline after a BUS short circuit fault occurs, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|------------------------------|---|---|
| F120 | Bus Sampling Abnormality | 1. BUS voltage sampling hardware fault | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F121 | DC Side Sampling Abnormality | 1. BUS voltage sampling hardware fault 2. Battery voltage sampling hardware fault 3. Dcrlly relay fault | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|------------------------------|--|--|
| F122 | PV Access Mode Setting Error | <p>There are three PV access modes, taking four MPPT channels as an example:</p> <ol style="list-style-type: none"> 1. Parallel mode: i.e., AAAA mode (same source mode), PV1-PV4 are from the same source, all 4 PV channels are connected to the same solar panel 2. Partial parallel mode: i.e., AACC mode, PV1 and PV2 are connected from the same source, PV3 and PV4 are connected from the same source 3. Independent mode: i.e., ABCD mode (different sources), PV1, PV2, PV3, PV4 are connected independently, each of the 4 PV channels is connected to one solar panel <p>If the actual PV</p> | <p>Check if the PV access mode is set correctly (ABCD, AACC, AAAA), reset the PV access mode correctly.</p> <ol style="list-style-type: none"> 1. Confirm that the actual connected PV channels are correctly wired; 2. If the PV is correctly connected, check the currently set "PV Access Mode" via the APP or screen to see if it corresponds to the actual access mode; 3. If the currently set "PV Access Mode" does not match the actual access mode, use the APP or screen to set the "PV Access Mode" to the mode consistent with the actual situation. After setting, disconnect the PV and AC power supply and restart; 4. After setting, if the current "PV Access Mode" matches the actual access mode, but this fault still occurs, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|------------|--|--------------------------------|
| | | access mode does not match the PV access mode set on the device, this fault will be reported | |

8.5.2.1.4 Troubleshooting (Fault Codes F122-F163)

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|------------|------------------------------------|--|---|
| F123 | Multi-channel PV Phase Error | PV Input Mode Setting Error | <p>Check if the PV Access Mode is set correctly (ABCD, AACC, AAAA). Reset the PV Access Mode correctly.</p> <ol style="list-style-type: none"> 1. Confirm that each actual PV channel is correctly connected. 2. If the PV is correctly connected, check via APP or screen whether the currently set "PV Access Mode" corresponds to the actual connection mode. 3. If the currently set "PV Access Mode" does not match the actual connection mode, use the APP or screen to set the "PV Access Mode" to the mode consistent with the actual situation. After setting, disconnect and restart the PV and AC power supply. 4. After setting, if the current "PV Access Mode" matches the actual connection mode but this fault still occurs, please contact the dealer or after-sales service center. |
| F124 | Battery 1 Reverse Connection fault | Battery 1 Positive and Negative Poles Reversed | Check if the polarities of the Battery and the machine terminals are consistent. |
| F125 | Battery 2 Reverse Connection fault | Battery 2 Positive and Negative Poles Reversed | Check if the polarities of the Battery and the machine terminals are consistent. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|-------------------|-----------------------------|--|---|
| F126 | Abnormal Battery Connection | Abnormal Battery Connection | Check if the Battery is working normally. |
| F127 | BAT Overtemperature | Battery temperature is too high. Possible causes: 1. Poor ventilation at the inverter installation location. 2. Ambient temperature is too high. 3. Internal fan operation is abnormal. | Disconnect the AC output side switch and DC input side switch. After 5 minutes, close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F128 | Ref Voltage Abnormal | Reference circuit fault | Disconnect the AC output side switch and DC input side switch. After 5 minutes, close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F129 | Cabinet Under Temperature | Cabinet temperature is too low. Possible cause: Ambient temperature is too low. | Disconnect the AC output side switch and DC input side switch. After 5 minutes, close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F130 | AC Side SPD fault | AC Side Surge Protective Device Failure | Replace the AC side surge protective device. |
| F131 | DC Side SPD fault | DC Side Surge Protective Device Failure | Replace the DC side surge protective device. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|------------|------------------------|---|---|
| F132 | Internal Fan Abnormal | Internal fan abnormal. Possible causes: 1. Abnormal fan power supply. 2. Mechanical fault (stall). 3. Fan aging or damage. | Disconnect the AC output side switch and DC input side switch. After 5 minutes, close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F133 | External Fan Abnormal | External fan abnormal. Possible causes: 1. Abnormal fan power supply. 2. Mechanical fault (stall). 3. Fan aging or damage. | Disconnect the AC output side switch and DC input side switch. After 5 minutes, close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F134 | PID Diagnosis Abnormal | PID hardware fault or PID paused due to high PV voltage. | No action required for PID pause warning caused by high PV voltage. For PID hardware fault, clear the PID fault by turning the PID switch off and then on, and replace the PID device. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|------------|--|--|--|
| F135 | Trip-Switch Trip Warning | Possible causes: Overcurrent or PV reverse connection caused the trip-switch to trip. | Contact the dealer or after-sales service center. The tripping reason was due to PV short circuit or reverse connection. Check if there is a history of PV short circuit warning or PV reverse connection warning. If present, maintenance personnel need to check the corresponding PV condition. After checking and confirming no fault, you can manually close the trip-switch and clear this warning via the APP interface's clear historical fault operation. |
| F136 | Historical PV IGBT Short Circuit Warning | Possible causes: Overcurrent caused the trip-switch to trip. | Contact the dealer or after-sales service center. Maintenance personnel need to check the Boost hardware and external string for faults according to the historical PV short circuit warning subcode. After checking and confirming no fault, this warning can be cleared via the APP interface's clear historical fault operation. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|-------------|--|---|---|
| F137 , F138 | Historical PV Reverse Connection Warning (String 1-n) (n: determined by the actual number of inverter strings) | Possible causes: PV reverse connection caused the trip-switch to trip. | Contact the dealer or after-sales service center. Maintenance personnel need to check if the corresponding string has a reverse connection according to the historical PV reverse connection warning subcode, and check if there is a voltage difference in the PV panel configuration. After checking and confirming no fault, this warning can be cleared via the APP interface's clear historical fault operation. |
| F139 | Flash Read/Write Error Warning | Possible causes: 1. Flash content changed. 2. Flash end of life reached. | 1. Upgrade to the latest firmware. 2. Contact the dealer or after-sales service center. |
| F140 | Meter Comm Loss | This warning may only occur after enabling anti-backflow function. Possible causes: 1. Meter not connected. 2. Incorrect wiring of the communication cable between the meter and the inverter. | Check the meter wiring and connect the meter correctly. After checking, if the fault persists, please contact the dealer or after-sales service center. |
| F141 | PV Panel Type Identification Failure | PV panel identification hardware abnormal | Contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|-------------------|---|---|---|
| F142 | PV String Mismatch | PV string mismatch. Two strings under the same MPPT have different open-circuit voltage configurations. | Check the open-circuit voltage of the two strings. Configure strings with the same open-circuit voltage under the same MPPT. Prolonged string mismatch poses a safety hazard. |
| F143 | CT Not Connected | CT not connected | Check CT wiring. |
| F144 | CT Reverse Connection | CT reverse connection | Check CT wiring. |
| F145 | PE Loss | Ground wire not connected | Check the ground wire. |
| F146 | String Terminal High Temperature (String 1~8) | Register 37176 PV terminal temperature warning subcode 1 is set. | - |
| F147 | String Terminal High Temperature (String 9~16) | Register 37177 PV terminal temperature warning subcode 2 is set. | - |
| F148 | String Terminal High Temperature (String 17~20) | Register 37178 PV terminal temperature warning subcode 3 is set. | - |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|-------------------|---|---|---|
| F149 | Historical PV Reverse Connection Warning (String 33~48) | Possible causes: PV reverse connection caused the trip-switch to trip. | Contact the dealer or after-sales service center. Maintenance personnel need to check if the corresponding string has a reverse connection according to the historical PV reverse connection warning subcode, and check if there is a voltage difference in the PV panel configuration. After checking and confirming no fault, this warning can be cleared via the APP interface's clear historical fault operation. |
| F150 | Battery 1 Low Voltage | Battery voltage is below the set value. | - |
| F151 | Battery 2 Low Voltage | Battery voltage is below the set value. | - |
| F152 | Low Voltage of Battery Power | Battery not in charging mode, voltage below shutdown voltage. | - |
| F153 | Battery 1 High Voltage | - | - |
| F154 | Battery 2 High Voltage | - | - |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|-------------------|---|--|--|
| F155 | Online Low Insulation Resistance | <p>1. Photovoltaic string short circuit to protective earth.</p> <p>2. The photovoltaic string installation environment is humid for a long time and the line has poor insulation to ground.</p> | <p>1. Check the impedance of the photovoltaic string to the protective earth. If a short circuit is found, please rectify the short circuit point.</p> <p>2. Check if the inverter's protective earth wire is correctly connected.</p> <p>3. If it is confirmed that the impedance is indeed below the default value in rainy conditions, please reset the "Insulation Resistance Protection Point".</p> |
| F156 | Micro-grid Overload Warning | backup terminal input current is too high. | Occasional occurrence requires no action. If this warning occurs frequently, please contact the dealer or after-sales service center. |
| F157 | Manual Reset | - | - |
| F158 | Generator Phase Sequence Abnormal | - | - |
| F159 | Multiplexed Port Configuration Abnormal | Multiplexed (generator) port is configured for micro-grid or large load, but a generator is actually connected. | Use the APP to change the multiplexed (generator) port configuration. |
| F160 | EMS Forced Off-grid | EMS issued forced off-grid command, but off-grid function is not enabled. | Enable the off-grid function. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|-------------------|-----------------------------------|--|---|
| F161 | Passive Anti-islanding Protection | - | - |
| F162 | Grid Type Fault | Actual grid type (two-phase or split-phase) does not match the set safety standard. | Switch to the corresponding safety standard according to the actual grid type. |
| F163 | Grid Phase Instability | Grid abnormal: The rate of change of grid voltage phase does not comply with local grid standards. | <p>1. If it occurs occasionally, it may be a temporary grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, please check if the grid frequency is within the allowable range. If not, please contact the local power operator.</p> |

8.5.2.1.5 Fault Symptom Handling

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------------|---|---|
| Generator Failure | <ol style="list-style-type: none"> 1. This fault will persist if no generator is connected. 2. Triggered when the generator's operation does not meet safety regulations. | <ol style="list-style-type: none"> 1. If no generator is connected, ignore this fault. 2. It is normal for this fault to appear when the generator malfunctions. Wait for a period after the generator recovers, and the fault will clear automatically. 3. This fault does not affect the normal operation of off-grid mode. 4. When both generator and grid are connected and meet safety requirements, grid connection takes priority, and the system will operate in grid-connected mode. |
| BMS Status Bit Error | BMS module failure | Disconnect the AC output side switch and DC input side switch. After 5 minutes, reconnect the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| Ambient Overtemperature | <ol style="list-style-type: none"> 1. Poor machine ventilation 2. Hot air flows back to the ambient temperature sampling point | Disconnect the AC output side switch and DC input side switch. After 5 minutes, reconnect the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------------------------|---|---|
| PV Terminal Overtemperature | PV terminal overtemperature, possible causes: 1. Poor ventilation at the inverter installation location. 2. Ambient temperature is too high. 3. Internal fan abnormal operation. | 1. Check if the ventilation at the inverter installation location is adequate and if the ambient temperature exceeds the maximum allowable range. 2. If ventilation is poor or ambient temperature is too high, please improve ventilation and heat dissipation conditions. 3. If both ventilation and ambient temperature are normal, please contact the dealer or after-sales service center. |
| BAT Terminal Overtemperature | BAT terminal overtemperature, possible causes: 1. Poor ventilation at the inverter installation location. 2. Ambient temperature is too high. | 1. Check if the ventilation at the inverter installation location is adequate and if the ambient temperature exceeds the maximum allowable range. |
| AC Terminal Overtemperature Warning | AC terminal overtemperature, possible causes: 1. Poor ventilation at the inverter installation location. 2. Ambient temperature is too high. 3. Internal fan abnormal operation. | 2. If ventilation is poor or ambient temperature is too high, please improve ventilation and heat dissipation conditions. 3. If both ventilation and ambient temperature are normal, please contact the dealer or after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|--------------------------------------|---|---|
| BAT Terminal Overtemperature Warning | BAT terminal overtemperature, possible causes: 1. Poor ventilation at the inverter installation location. 2. Ambient temperature is too high. | 1. Check if the ventilation at the inverter installation location is adequate and if the ambient temperature exceeds the maximum allowable range. 2. If ventilation is poor or ambient temperature is too high, please improve ventilation and heat dissipation conditions. 3. If both ventilation and ambient temperature are normal, please contact the dealer or after-sales service center. |
| Three-phase on-grid fault | Incorrect three-phase external wiring | Re-wire the connections. |
| External STS Failure | Abnormal cable connection between inverter and STS | Check if the wiring sequence of the harness between the inverter and the STS corresponds correctly one by one. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|---------------------------------------|--|---|
| Parallel Comm Timeout Shutdown | In parallel mode, if a slave unit fails to communicate with the master unit for more than 400 seconds. | Check if the parallel communication harness is securely connected. Check if slave addresses are duplicated. |
| Three-phase off-grid phase loss fault | Phase loss in a three-phase system group. | 1. Check if all inverters are powered on. 2. Check if each phase of the three-phase group is connected to an inverter. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|--|---|---|
| EPO | External hardware EPO button triggered or remote EPO command triggered. | <ol style="list-style-type: none"> 1. If it was actively triggered via remote shutdown, it can be ignored. 2. If not actively triggered, please contact the dealer or after-sales service center. |
| High Combustible Gas Concentration | Automatically triggered when the combustible gas device detects a concentration of 20% LEL or higher. | <ol style="list-style-type: none"> 1. After the fault occurs, the unit will automatically open the air damper to exhaust and reduce the concentration. The fault will clear automatically after the concentration remains below 5% LEL for 15 minutes. 2. If a cluster-level fire protection fault is triggered after this fault occurs, the air damper will automatically close. Confirm the damper status within 30s to ensure cluster-level fire protection operates in a sealed space. 3. Please contact the dealer or after-sales service center. |
| Combustible Gas Device Air Damper Open Signal Mismatch with Feedback | The control signal to open the air damper does not match the feedback signal. | <ol style="list-style-type: none"> 1. Check the harness signal connection for issues. 2. Please contact the dealer or after-sales service center. |
| One-Touch Shutdown | Check via the App if the one-touch shutdown function is enabled. | Disable the one-touch shutdown. |
| Offline Shutdown | - | - |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|----------------------------------|---|---|
| Remote Shutdown | - | - |
| On-Grid SPD Fault | - | <ol style="list-style-type: none"> 1. Try restarting the unit and observe if the fault clears; 2. If the fault persists after restart, please contact the dealer or after-sales service center. |
| Off-Grid SPD Fault | - | <ol style="list-style-type: none"> 1. Try restarting the unit and observe if the fault clears; 2. If the fault persists after restart, please contact the dealer or after-sales service center. |
| Child Node Communication Failure | Internal Comm Abnormal | <ol style="list-style-type: none"> 1. Try restarting the unit and observe if the fault clears; 2. If the fault persists after restart, please contact the dealer or after-sales service center. |
| Dehumidifier Communication Fault | Communication link abnormality between the dehumidifier and the LC control box. | <ol style="list-style-type: none"> 1. Check the communication harness link, observe if the fault clears; 2. Try restarting the unit, observe if the fault clears; 3. If the fault persists after restart, please contact the dealer or after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|--|---|---|
| Combustible Gas Detection Device Communication Fault | <ol style="list-style-type: none"> The combustible gas device left the factory without the 485 address correctly configured as 2. Communication link abnormality between the combustible gas device and the LC control box. | <ol style="list-style-type: none"> Check the communication harness link, observe if the fault clears; Try restarting the unit, observe if the fault clears; Use the method provided by the combustible gas manufacturer to check if the device address is 2. If not, modify it; If the fault persists after restart, please contact the dealer or after-sales service center. |
| DG Communication Failure | Communication link abnormality between the control board and the diesel generator. | <ol style="list-style-type: none"> Check the communication harness link, observe if the fault clears; Try restarting the unit, observe if the fault clears; If the fault persists after restart, please contact the dealer or after-sales service center. |
| Battery Over Voltage | <ol style="list-style-type: none"> Single cell voltage too high. Voltage sensing line abnormality. | Record the fault phenomenon, restart the battery, wait a few minutes, confirm if the fault disappears. If the problem persists after restart, please contact the after-sales service center. |
| Battery Undervoltage | <ol style="list-style-type: none"> Total battery voltage too high. Voltage sensing line abnormality. | |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|----------------------------------|---|--------------------------------|
| | <ol style="list-style-type: none"> 1. Total battery voltage too low. 2. Voltage sensing line abnormality. | |
| Battery Overcurrent | <ol style="list-style-type: none"> 1. Charging current too high, battery current limiting abnormality: temperature and voltage values change abruptly. 2. Inverter response abnormal. | |
| | Battery discharge current too high. | |
| Battery Overtemperature | <ol style="list-style-type: none"> 1. Ambient Overtemperature. 2. Temperature sensor abnormality. | |
| Battery Undertemperature | <ol style="list-style-type: none"> 1. Ambient temperature too low. 2. Temperature sensor abnormality. | |
| Battery Terminal Overtemperature | Terminal temperature too high. | |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|--|--------------------------------|
| Battery Imbalance | <ol style="list-style-type: none"> 1. Excessive temperature difference. At different stages, the battery will limit its power, i.e., limit charge/discharge current. Therefore, this issue is generally difficult to occur. 2. Cell capacity degradation leads to high internal resistance, causing large temperature rise and thus large temperature difference during overcurrent. 3. Poor welding of cell tabs leads to rapid cell temperature rise during overcurrent. 4. Temperature sampling issue; 5. Power line connection loose. | |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|-----------------------|--|--|
| | 1. Inconsistent cell aging. 2. Slave board chip issues can also cause excessive cell voltage difference; 3. Slave board balancing issues can also cause excessive cell voltage difference. 4. Harness issues. | |
| Insulation Resistance | Insulation resistance damaged. | Check if the ground wire is properly connected, restart the battery. If the problem persists after restart, please contact the after-sales service center. |
| Pre-charging Failure | Pre-charging failure. | Indicates that during pre-charging, the voltage across the pre-charge MOS always exceeds the specified threshold. Power off and restart to observe if the fault persists. Check if wiring is correct and if the pre-charge MOS is damaged. |
| Sensing Line Fault | Battery sensing line poor contact or disconnected. | Check wiring, restart the battery. If the problem persists after restart, please contact the after-sales service center. |
| | Cell voltage sensing line poor contact or disconnected. | Check wiring, restart the battery. If the problem persists after restart, please contact the after-sales service center. |
| | Cell temperature sensing line poor contact or disconnected. | |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------------------------|--|--|
| | Dual-channel current comparison error too large, or current sensing line loop abnormal. | |
| | Dual-channel voltage comparison error too large or MCU vs AFE voltage comparison error too large, or voltage sensing line loop abnormal. | |
| | Temperature sensing line loop abnormal or poor contact/disconnected. | |
| | Overvoltage level 5 or overtemperature level 5, tripped three-terminal fuse. | |
| Relay or MOS Overtemperature | Relay or MOS overtemperature. | This fault indicates the MOS transistor temperature exceeds the specified threshold. Power off and let it sit for 2h for temperature recovery. |
| Shunt Overtemperature | Shunt overtemperature. | This fault indicates the shunt temperature exceeds the specified threshold. Power off and let it sit for 2h for temperature recovery. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|--|--|---|
| BMS1 Other Fault 1 (Residential Storage) | Relay or MOS open circuit. | <ol style="list-style-type: none"> 1. Upgrade software, power off and let it sit for 5 minutes, restart and see if the fault persists; 2. If it persists, replace the battery pack. |
| | Relay or MOS short circuit. | <ol style="list-style-type: none"> 1. Upgrade software, power off and let it sit for 5 minutes, restart and see if the fault persists; 2. If it persists, replace the battery pack. |
| | Communication abnormal between master and slave racks or cell inconsistency between racks. | <ol style="list-style-type: none"> 1. Check the slave battery information and software version, and if the communication cable connection to the master is normal. 2. Upgrade software. |
| | Battery system loop harness abnormal, causing interlock signal not forming a loop. | Check if the terminal resistor is installed correctly. |
| | BMS and PCS communication abnormal. | <ol style="list-style-type: none"> 1. Confirm if the communication cable interface definitions between the inverter and the connected battery are correct; 2. Please contact the after-sales service center to check backend data and observe if the inverter and battery software match correctly. |
| | BMS master and slave control communication harness abnormal. | <ol style="list-style-type: none"> 1. Check wiring, restart the battery; 2. Upgrade battery firmware, if the problem persists after restart, please contact the after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|---|---|
| | Communication loss between main negative chips. | |
| | Circuit breaker, shunt trip abnormal. | <ol style="list-style-type: none"> 1. Power off and let it sit for 5 minutes, restart and see if the fault persists; 2. Observe the blind-mate connectors at the bottom of PACK and PCU, check if communication pins are loose or bent; |
| | MCU self-test failure. | Upgrade software, restart the battery. If the problem persists after restart, contact the after-sales service center. |
| | <ol style="list-style-type: none"> 1. Software version too low or BMS board damaged. 2. Large number of parallel inverters, excessive inrush current during battery pre-charge. | <ol style="list-style-type: none"> 1. Upgrade software, observe if the fault persists. 2. For parallel systems, perform a black start of the battery first, then start the inverters. |
| | MCU internal fault. | Upgrade software, restart the battery. This usually indicates MCU or external component damage. If the problem persists after restart, please contact the after-sales service center. |
| | Main control current exceeds specified threshold. | <ol style="list-style-type: none"> 1. Power off and let it sit for 5 minutes, restart and see if the fault persists; 2. Check if the inverter power setting is too high, exceeding bus load capacity; |
| | Inconsistent cells in parallel battery racks. | Confirm if the cells in the parallel battery racks are consistent. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------------------|--|---|
| | Reverse polarity connection of parallel battery racks. | Check if the positive and negative terminals of the parallel battery racks are reversed. |
| | Severe overtemperature/overvoltage etc. triggering fire protection system. | Contact the after-sales service center. |
| Air Conditioner Failure | Air conditioner abnormal failure. | Try restarting the system. If the fault is not cleared, please contact the after-sales service center. |
| | Cabinet door not closed. | Check if the cabinet door is properly closed. |
| | Supply voltage too high. | Confirm if the supply voltage meets the air conditioner input voltage requirements. Re-power on after confirmation. |
| | Insufficient supply voltage. | |
| | No voltage input. | |
| | Unstable supply voltage. | |
| | Compressor voltage unstable. | Try restarting the system. If the fault is not cleared, please contact the after-sales service center. |
| | Sensor poor contact or damaged. | |
| Air conditioner fan abnormal. | | |
| | DCDC internal voltage or current abnormal. | Refer to specific DC fault content. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|--|---|--|
| BMS1 Other Fault 2 (Residential Storage) | DCDC overload or heatsink temperature too high, etc. | |
| | Cell sensing abnormal or inconsistent aging. | Please contact the after-sales service center. |
| | Fan operation not executed normally. | Please contact the after-sales service center. |
| | Output terminal screw loose or poor contact. | <ol style="list-style-type: none"> 1. Power off the battery, check wiring and output terminal screw condition. 2. After confirmation, restart the battery, observe if the fault persists. If it persists, please contact the after-sales service center. |
| | Battery used for too long or cells severely damaged. | Please contact the after-sales service center to replace the pack. |
| | <ol style="list-style-type: none"> 1. Software version too low or BMS board damaged. 2. Large number of parallel inverters, excessive inrush current during battery pre-charge. | <ol style="list-style-type: none"> 1. Upgrade software, observe if the fault persists. 2. For parallel systems, perform a black start of the battery first, then start the inverters. |
| | Heating film damaged. | Please contact the after-sales service center. |
| | Heating film three-terminal fuse blown, heating function unavailable. | Please contact the after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|---|--|
| | Software model, Cell Type, hardware model mismatch. | Check if software model, SN, Cell Type, and hardware model are consistent. If not, please contact the after-sales service center. |
| | Thermal management board communication cable disconnected. | 1. Power off and let it sit for 5 minutes, restart and see if the fault persists; 2. If the fault does not recover, contact after-sales to replace the pack. |
| | Pack fan fault signal triggered. | |
| DCDC Fault | Output port voltage too high. | Check output port voltage. If the output port voltage is normal and the fault does not clear itself after restarting the battery, please contact the after-sales service center. |
| | DCDC module detects battery voltage exceeding maximum charging voltage. | Stop charging, discharge to SOC below 90% or let it sit for 2h. If ineffective and the fault persists after restart, please contact the after-sales service center. |
| | Heatsink temperature too high. | Let the battery sit for 1h for heatsink temperature to drop. If ineffective and the fault persists after restart, please contact the after-sales service center. |
| | Battery discharge current too high. | Check if the load exceeds the battery's discharge capability. Turn off the load or stop PCS operation for 60s. If ineffective and the fault persists after restart, please contact the after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|--|---|---|
| | Output port power harness positive/negative reversed with parallel battery rack or PCS. | Turn off the battery manual switch, check if output port wiring is correct, restart the battery. |
| | Output power relay cannot close. | Check if output port wiring is correct, if there is a short circuit. If ineffective and the fault persists after restart, please contact the after-sales service center. |
| | Power device temperature too high. | Let the battery sit for 1h for internal power device temperature to drop. If ineffective and the fault persists after restart, please contact the after-sales service center. |
| | Relay welded/stuck. | If the fault persists after restart, please contact the after-sales service center. |
| Battery Rack Circulating Current Failure | 1. Cell imbalance. 2. First power-on without full charge calibration. | Record the fault phenomenon, restart the battery, wait a few minutes, confirm if the fault disappears. If the problem persists after restart, please contact the after-sales service center. |
| BMS1 Other Fault 3 (Utility Storage) | Communication abnormal with Linux module. | 1. Check if the communication cable connection is normal. 2. Upgrade software, restart the battery and observe if the fault persists. If it persists, please contact the after-sales service center. |
| | Cell temperature rise too fast. | Cell abnormal, contact after-sales to replace the pack. |
| | SOC below 10%. | Charge the battery. |
| | SN writing does not comply with rules. | Check if the SN digit count is normal. If abnormal, please contact the after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|--------------------------------------|---|---|
| | 1. Daisy-chain communication abnormal within a battery rack. 2. Inconsistent cell aging between battery racks. | 1. Check the pack contact condition within a single rack. 2. Confirm the usage status of each rack, such as cumulative charge/discharge capacity, cycle count, etc. 3. Please contact the after-sales service center. |
| | Pack internal humidity too high. | - |
| | Fuse blown. | Contact after-sales to replace the pack. |
| | Battery low power. | Charge the battery. |
| BMS1 Other Fault 4 (Utility Storage) | Circuit breaker abnormal. | Contact after-sales to replace the pack. |
| | External device abnormal. | Contact after-sales to replace the pack. |
| Contact Failure 1 | - | - |
| Contact Failure 2 | - | - |
| Overload Protection (Ksic) | Sustained overload (exceeding 690KVA) for 10s. | Please contact the after-sales service center. |
| Overload Protection (Smart Port) | Sustained overload (exceeding 690KVA) for 10s. | Please contact the after-sales service center. |
| Overcurrent Protection (Ksic) | - | - |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------------------------|--|--|
| Overcurrent Protection (Smart Port) | - | - |
| Master AC On Meter Comm Error | <ol style="list-style-type: none"> 1. Possibly the meter is not connected to the master. 2. Possibly the meter communication cable is loose. | <ol style="list-style-type: none"> 1. Check if the meter is connected to the master. 2. Check if the meter communication cable is loose. |
| Parallel Slave Meter Error | Meter connected to a slave unit. | Set the unit with the meter as the master. |
| Slave AC On Timeout with Master | <ol style="list-style-type: none"> 1. Slave address setting error. 2. Slave communication cable loose. | <ol style="list-style-type: none"> 1. Check if slave addresses are duplicated. 2. Check if the parallel communication cable is loose. |

8.5.2.2 Batteryfault

| No. | fault name | fault cause | Troubleshooting Recommendation |
|------------|---|--|---|
| 1 | BMS1 Cluster 1 Total voltage Over WARNING /BMS1 RACK1 Total voltage is too high warning | <ol style="list-style-type: none"> 1. Battery systemvoltage too high 2. Abnormal collection line | <ol style="list-style-type: none"> 1. Perform Discharge on Battery to check if fault persists. 2. If the fault is not restored, contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|---|--|--|
| 2 | BMS1 Cluster 1 Total voltage Too Low WARNING /BMS1 RACK1 Total voltage is too low warning | 1. Battery systemvoltage too low 2. Abnormal data collection line | 1. Perform Charge on Battery, and observe whether fault persists after standing; 2. Determine the working condition of Inverter, check if it fails to supply power to Battery charge due to issues such as working mode, and attempt to supply power to Battery charge via Inverter, observing whether fault is restored. 3. If the fault is not restored, contact the after-sales service center. |
| 3 | BMS1 Cluster 1 Cell voltage Overvoltage WARNING /BMS1 RACK1 Cell voltage is too high warning | 1. Single cell voltage too high 2. Abnormal collection line | 1. Perform Discharge on Battery, and observe whether fault persists after standing. 2. If fault is not restored, contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|---|--|--|
| 4 | BMS1 Cluster 1 Cell voltage Undervoltage WARNING /BMS1 RACK1 Cell voltage is too low warning | <ol style="list-style-type: none"> 1. Single cell voltage too low 2. voltage collection line abnormality | <ol style="list-style-type: none"> 1. Perform Charge on Battery, and observe whether fault persists after standing; 2. Determine the working condition of Inverter, check if it is not supplying power to Battery charge due to issues such as working mode, and attempt to supply power to Battery charge via Inverter, observing whether fault is restored. 3. If fault is not restored, contact after-sales service. |
| 5 | BMS1 Cluster 1 Charge Over Temperature WARNING /BMS1 RACK1 Charging temperature is too high warning | <ol style="list-style-type: none"> 1. Ambient Overtemperature 2. Temperature sensor abnormality | <ol style="list-style-type: none"> 1. Stop charging and observe whether the Discharge persists during rest; 2. If the fault is not restored, contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|---|---|--|
| 6 | BMS1 Cluster 1 Discharge Over Temperature WARNING /BMS1 RACK1 Discharging temperature is too high warning | <ol style="list-style-type: none"> 1. Ambient Overtemperature 2. Temperature sensor abnormality | <ol style="list-style-type: none"> 1. Stop charging, let it stand and observe whether the fault persists; 2. If the fault is not restored, contact after-sales service. |
| 7 | BMS1 Cluster 1 Charge Temperature Too Low WARNING /BMS1 RACK1 Charging temperature is too low warning | <ol style="list-style-type: none"> 1. Ambient temperature too low 2. Temperature sensor abnormality | <ol style="list-style-type: none"> 1. Check the cell temperature in the background. If the minimum temperature is higher than -20°C, set Battery discharge to increase the cell temperature. 2. If the temperature is below -20°C, shut down the Battery and place it in a warm environment. Use it only after the battery cell temperature has recovered. 3. If none of the above works, contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|---|--|--|
| 8 | BMS1 cluster 1 Discharge temperature too low WARNING/ BMS1 RACK1 Discharging temperature is too low warning | <ol style="list-style-type: none"> 1. Ambient temperature too low 2. Temperature sensor abnormality | <ol style="list-style-type: none"> 1. Check the cell temperature in the background. If the minimum temperature is higher than -20°C, set Battery discharge to increase the cell temperature. 2. If the temperature is below -20°C, shut down the Battery and place it in a warm environment. Use it only after the battery cell temperature has recovered. 3. If none of the above works, contact the after-sales service center. |
| 9 | BMS1 Cluster 1 Overcurrent BMS1 RACK1 Charge overcurrent warning | <ol style="list-style-type: none"> 1. Charging Current is too large, Battery current limiting is abnormal: temperature and voltage value mutation 2. Inverter response anomaly | <ol style="list-style-type: none"> 1. Stop Charge and observe whether fault persists; 2. Check if the Inverter is set with an excessively large Power, causing it to exceed the rated operating current of the Battery; 3. If continuous overcurrent occurs, contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|--|---|--|
| 10 | BMS1 Cluster 1 Overcurrent BMS1 RACK1 Discharge overcurrent warning | <ol style="list-style-type: none"> 1. Discharge and current are too large, Battery current limiting is abnormal: temperature and voltage values have changed abruptly. 2. Inverter response anomaly | <ol style="list-style-type: none"> 1. Stop Discharge, let it stand and observe whether fault persists; 2. Check if the Inverter is set with an excessively large Power, causing it to exceed the rated operating current of the Battery; 3. If continuous overcurrent occurs, contact the after-sales service center. |
| 11 | BMS1 Cluster 1 Insulation Resistance Low WARNING/ BMS1 RACK1 Insulation resistance is too low warning | Insulation resistance damage or abnormal contact | Check if the ground wire is properly connected and restart the Battery. If the issue persists after restarting, please contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|---|---|--|
| 12 | BMS1 Cluster 1 Single Cell Temperature Difference Exceeds Limit WARNING BMS1 RACK1 Cell excessive temperature differentials warning | <ol style="list-style-type: none"> 1. Excessive temperature difference at different stages will result in Battery limiting the Battery Power, specifically restricting the charging Discharge current. Therefore, this issue is generally unlikely to occur. 2. Cell capacity degradation leads to excessive internal resistance, resulting in significant temperature rise and large temperature differences during Overcurrent. 3. Poor welding of the cell tabs leads to excessive heating of the Overcurrent cell. 4. Temperature sampling issue; 5. Loose connection of power cable | Shut down, restart Battery, and wait for 2 hours. If the issue persists, contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|--|---|--|
| 13 | BMS1 Cluster 1 Pole Temperature Too High WARNING BMS1 RACK1 Post temperature is too high warning | Pole temperature too high | 1. Stop charging, let it stand and observe whether the fault persists; 2. If fault is not restored, contact the after-sales service center. |
| 14 | BMS1 cluster 1 cell voltage difference too highWARNING/ BMS1 RACK1 Cell excessive voltage differentials warning | <ol style="list-style-type: none"> 1. Inconsistent aging levels of battery cells 2. Issues with the board chip can also lead to excessive voltage differences between battery cells. 3. Cell imbalance can also lead to excessive voltage differences between cells. 4. Harness issue causing | <ol style="list-style-type: none"> 1. Stop charging, let it stand and observe whether the fault persists; 2. If fault is not restored, contact the after-sales service center. |
| 15 | BMS1 Cluster 1PCS Comm LossWARNING/ BMS1 RACK1 PCS communication loss warning | BMS and PCS communication abnormality | Check whether the communication line connection between Battery and Inverter is intact. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|--|---|--|
| 16 | BMS1 Cluster 1 DCDCWARNING/ BMS1 RACK1 DCDC warning | There is an abnormality in the voltage or current inside the DCDC. | Upgrade the software and restart the Battery. If the issue persists after restarting, please contact the after-sales service center. |
| 17 | BMS1 Cluster 1 Heating Film MOS Adhesion WARNING BMS1 RACK1 Heat film MOS adhesion warning | Heating film MOS damage | Please contact the after-sales service center. |
| 18 | BMS1 Cluster 1 Heating Film MOS Open Circuit WARNING/ BMS1 RACK1 Heat film MOS open warning | Heating circuit abnormality | Please contact the after-sales service center. |
| 19 | BMS1 Cluster 1 Total voltage Over fault/ BMS1 RACK1 Total voltage is too high fault | 1. Battery systemvoltage too high 2. voltage collection line abnormality | 1. Perform Discharge on Battery to check if fault persists. 2. If fault is not restored, please contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|--|--|---|
| 20 | BMS1 Cluster 1 Total voltage Too Low fault/ BMS1 RACK1 Total voltage is too low fault | <ol style="list-style-type: none"> 1. Battery systemvoltage too low 2. voltage collection line abnormality | <ol style="list-style-type: none"> 1. Perform Charge on Battery, and observe whether fault persists after standing; 2. Determine the working condition of Inverter, check if it fails to supply power to Battery charge due to issues such as working mode, and attempt to supply power to Battery charge via Inverter, observing whether fault is restored. 3. If the fault is not restored, please contact the after-sales service center. |
| 21 | BMS1 Cluster 1 Cell voltage Overvoltage fault BMS1 RACK1 Cell voltage is too high fault | <ol style="list-style-type: none"> 1. Single cell voltage too high 2. voltage collection line abnormality | <ol style="list-style-type: none"> 1. Perform Discharge on Battery, and observe whether fault persists after standing. 2. If fault is not restored, please contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|--|---|---|
| 22 | BMS1 Cluster 1 Monomer voltage Undervoltage fault/ BMS1 RACK1 Cell voltage is too low fault | <ol style="list-style-type: none"> 1. Single cell voltage too low 2. Abnormal voltage collection line | <ol style="list-style-type: none"> 1. Perform Charge on Battery, and observe whether fault persists after standing; 2. Determine the working condition of Inverter, check if it fails to supply power to Battery charge due to issues such as working mode, and attempt to supply power to Battery charge via Inverter, observing whether fault is restored. 3. If the fault is not restored, please contact the after-sales service center. |
| 23 | BMS1 Cluster 1 Charge Over Temperature fault/ BMS1 RACK1 Charging temperature is too high fault | <ol style="list-style-type: none"> 1. Ambient Overtemperature 2. Temperature sensor abnormality | <ol style="list-style-type: none"> 1. Place the Battery in a cool place, let it shut down and rest for 30 minutes, then restart it to see if the fault persists. 2. If the fault persists, please contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|--|---|--|
| 24 | BMS1 Cluster 1 Discharge Over Temperature fault/ BMS1 RACK1 Discharging temperature is too high fault | <ol style="list-style-type: none"> 1. Ambient Overtemperature 2. Temperature sensor abnormality | <ol style="list-style-type: none"> 1. Place the Battery in a cool place, let it shut down and rest for 30 minutes, then restart it to see if the fault persists; 2. If the fault persists, please contact the after-sales service center. |
| 25 | BMS1 Cluster 1 Charge Temperature Too Low fault/ BMS1 RACK1 Charging temperature is too low fault | <ol style="list-style-type: none"> 1. Ambient temperature too low 2. Temperature sensor abnormality | <ol style="list-style-type: none"> 1. Check the cell temperature in the background. If the minimum temperature is higher than -20°C, set Battery discharge to increase the cell temperature. 2. If the temperature is below -20°C, shut down the Battery and place it in a warm environment. Use it only after the battery cell temperature has recovered. 3. If none of the above works, contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|---|--|--|
| 26 | BMS1 Cluster 1 Discharge Temperature Too Low fault BMS1 RACK1 Discharging temperature is too low fault | <ol style="list-style-type: none"> 1. Ambient temperature too low 2. Temperature sensor abnormality | <ol style="list-style-type: none"> 1. Check the cell temperature in the background. If the minimum temperature is higher than -20°C, set Battery discharge to increase the cell temperature. 2. If the temperature is below -20°C, shut down the Battery and place it in a warm environment. Use it only after the battery cell temperature has recovered. 3. If none of the above works, contact the after-sales service center. |
| 27 | BMS1 Cluster 1 Overcurrent BMS1 RACK1 Charge overcurrent fault | <ol style="list-style-type: none"> 1. Charging Current is too large, Battery current limiting is abnormal: temperature and voltage value mutation 2. Inverter response anomaly | <ol style="list-style-type: none"> Let the system stand and shut down for 5 minutes, then restart to check if fault persists. 2. Check if the Inverter is set with an excessively large Power, causing it to exceed the rated operating current of the Battery; 3. If continuous overcurrent occurs, contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|--|---|--|
| 28 | BMS1 Cluster 1 Discharge Overcurrent fault / BMS1 RACK1 Discharge overcurrent fault | <ol style="list-style-type: none"> 1. Discharge and current are too large, Battery current limiting is abnormal: temperature and voltage values have changed abruptly. 2. Inverter response anomaly | <ol style="list-style-type: none"> 1. Let the system remain powered off for 5 minutes, then restart and check if fault persists; 2. Check if the Inverter is set with an excessively large Power, causing it to exceed the rated operating current of the Battery; 3. If continuous overcurrent occurs, contact the after-sales service center. |
| 29 | BMS1 Cluster 1 Insulation Resistance Low fault BMS1 RACK1 Insulation resistance is too low fault | Insulation resistance damage or abnormal contact | <ol style="list-style-type: none"> 1. Check if the ground wire is properly connected and restart the Battery, 2. Upgrade the software. If the problem persists, please contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|--|---|---|
| 30 | BMS1 Cluster 1 Single Cell Temperature Difference Exceeds Limit fault BMS1 RACK1 Cell excessive temperature differentials fault | <ol style="list-style-type: none"> 1. Excessive temperature difference at different stages will result in Battery limiting the Battery Power, specifically restricting the charging Discharge current. Therefore, this issue is generally unlikely to occur. 2. Cell capacity degradation leads to excessive internal resistance, resulting in significant temperature rise and large temperature differences during Overcurrent. 3. Poor welding of the cell tabs leads to excessive heating of the Overcurrent cell. 4. Temperature sampling issue; 5. Loose connection of power cable | Shutdown, restart Battery, wait for 2 hours. If the issue persists, contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|--|--|--|
| 31 | BMS1 Cluster 1 Pole Temperature Too High fault BMS1 RACK1 Post temperature is too high fault | Pole temperature too high | <ol style="list-style-type: none"> 1. Let the system remain powered off and idle for 30 minutes, then restart to check if fault persists; 2. If the fault persists, please contact the after-sales service center. |
| 32 | BMS1 Cluster 1 Excessive Cell Voltage Difference fault/ BMS1 RACK1 Cell excessive voltage differentials fault | <ol style="list-style-type: none"> 1. Inconsistent aging levels of battery cells 2. Issues with the board chip can also lead to excessive voltage differences between battery cells. 3. Cell imbalance issues can also lead to excessive voltage differences between cells. 4. Harness issue causing | Shut down, restart Battery, and wait for 2 hours. If the issue persists, contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|--|--|--|
| 33 | BMS1 Cluster 1 Relay or MOS Short Circuit fault BMS1 RACK1 Relay or MOS short-circuit fault | MOS short circuit | 1. Upgrade the software, power off and let it sit for 5 minutes, then check if fault persists after restarting. 2. If the issue persists, contact the after-sales service center. |
| 34 | BMS1 Cluster 1 relay or MOS open circuit fault/ BMS1 RACK1 Relay or MOS open-circuit fault | MOS open circuit | 1. Upgrade the software, power off and let it sit for 5 minutes, then check if fault persists after restarting. 2. If the issue persists, contact the after-sales service center. |
| 35 | BMS1 Cluster 1Pre-charging Failurefault/ BMS1 RACK1 The precharge failed fault | The voltage across the precharge MOS voltage consistently exceeds the specified threshold. | 1. Upgrade the software, power off and let it stand for 5 minutes, then check if fault persists after restarting. 2. If the issue persists, contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|---|---|---|
| 36 | BMS1 Cluster 1 Acquisition Line fault/ BMS1 RACK1 Acquisition line fault | Battery acquisition line poor contact or disconnected | Power off, check the wiring, re-stack the Battery, and restart. If the issue persists, please contact the after-sales service center. |
| 37 | BMS1 Cluster 1 relay or MOS temperature too high fault BMS1 RACK1 Relay or MOS temperature is too high fault | Relay or MOSFET overtemperature | <ol style="list-style-type: none"> 1. Upgrade the software, power off and let it stand for 30 minutes, then check if fault persists after restarting. 2. If the issue persists, contact the after-sales service center. |
| 38 | BMS1 Cluster 1 Shunt Over-temperaturefault/ BMS1 RACK1 Diverter temperature is too high fault | Shunt Over-temperature | <ol style="list-style-type: none"> 1. Upgrade the software, power off and let it sit for 30 minutes, then restart to check if fault persists. 2. If the issue persists, contact the after-sales service center. |
| 39 | BMS1 Cluster 1 Communication from MCU fault BMS1 RACK1 Slave MCU communication fault | Communication loss between master and slave chips | <ol style="list-style-type: none"> Check the wiring and restart the Battery. 2. Upgrade the Battery. If the issue persists after restarting, please contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|---|---|--|
| 40 | BMS1 Cluster 1 BMU Communication fault/ BMS1 RACK1 BMU communication fault | Abnormal communication harness between BMS master and slave control | Check the wiring and restart the Battery. 2. Upgrade the Battery. If the problem persists after restarting, please contact the after-sales service center. |
| 41 | BMS1 Cluster 1 Microelectronics fault/ BMS1 RACK1 Micro-electronics fault | Internal fault of MCU | Upgrade the software and restart the Battery. If the issue persists after restarting, please contact the after-sales service center. |
| 42 | BMS1 Cluster 1 Hardware Overcurrent fault/ BMS1 RACK1 Hardware overcurrent fault | <ol style="list-style-type: none"> 1. The software version is too low or the BMS board is damaged. 2. The number of parallel units is large, and the impact during pre-charging is excessive. | <p>Upgrade the software and observe whether fault persists.</p> <ol style="list-style-type: none"> 2. In the case of parallel operation, perform a black start on Battery first, then start Inverter. |
| 43 | BMS1 Cluster 1 Application Software Failure/ BMS1 RACK1 Application software fault | MCU self-test failed | Upgrade the software and restart the Battery. If the issue persists after restarting, please contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|--|--|---|
| 44 | BMS1 parallel cluster 1 parallel cluster fault/ BMS1 RACK1 Parallel RACK fault | Communication abnormality between the master cluster and slave cluster, or inconsistency of battery cells between clusters. | <ol style="list-style-type: none"> 1. Check the Battery information and software version of the slave unit, and verify whether the communication cable connection with the master unit is normal. 2. Upgrade software |
| 45 | BMS1 Cluster 1 DCDC Failure/ BMS1 RACK1 DCDC fault | DCDCOverload or excessive heat sink temperature | Upgrade the software and restart the Battery. If the issue persists after restarting, please contact the after-sales service center. |
| 46 | BMS1 cluster 1 cell inconsistency fault BMS1 RACK1 Inconsistent cell fault | <ol style="list-style-type: none"> 1. Abnormal Cell Identification 2. Stacking of different types of battery cells | Check Cell Type |
| 47 | BMS1 Cluster 1 Output port Overtemperature fault/ BMS1 RACK1 The output port over temperature fault | Output port screw loose or poor contact | <ol style="list-style-type: none"> 1. Battery Shut down, check wiring and output port screw status 2. After confirmation, restart the Battery and observe whether the fault persists. If it does, contact the after-sales service center. |

| No. | fault name | fault cause | Troubleshooting Recommendation |
|-----|--|---|--|
| 48 | BMS1 Cluster 1 SOH Too Lowfault/ BMS1 RACK1 SOH too low fault | Battery has been used for too long or the battery cell is severely damaged. | Replace pack |
| 49 | BMS1 Cluster 1 Heating Film Three-Terminal fault BMS1 RACK1 Heating film MOS Three-terminal fault | Heating film MOS damage | Please contact the after-sales service center. |

9 technical parameter

9.1 Inverter Parameters

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 |
|---|----------------------------|----------------------------|----------------------------|
| Battery Side | | | |
| Battery Type | LFP (LiFePO ₄) | LFP (LiFePO ₄) | LFP (LiFePO ₄) |
| Nominal Voltage (V) | 750 | 750 | 750 |
| Voltage Range (V) | 700~950 | 700~950 | 700~950 |
| Start-up Voltage (V) | 720 | 720 | 720 |
| Number of Battery Input | 1 | 1 | 1 |
| Max. Continuous Charging Current (A) | 6.7 | 8.1 | 10.7 |
| Max. Continuous Discharging Current (A) | 7.4 | 8.9 | 11.8 |
| Max. Charging Power (kW) | 5 | 6 | 8 |
| Max. Discharging Power (kW) | 5.5 | 6.6 | 8.8 |
| PV Side | | | |
| Max. Input Power (kW) | 10 | 12 | 16 |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 |
|--|---------------------|---------------------|---------------------|
| Max. Input Voltage (V) ^{*1} | 1000 | 1000 | 1000 |
| MPPT Operating Voltage Range (V) ^{*2} | 120~950 | 120~950 | 120~950 |
| MPPT Voltage Range at Nominal Power (V) | 185~850 | 225~850 | 300~850 |
| Start-up Voltage (V) | 150 | 150 | 150 |
| Nominal Input Voltage (V) | 750 | 750 | 750 |
| Max. MPPT Current (A) | 21/21/21 | 21/21/21 | 21/21/21 |
| Max. MPPT Short Circuit Current (A) | 26/26/26 | 26/26/26 | 26/26/26 |
| Max. Backfeed Current to The Array (A) | 0 | 0 | 0 |
| Number of MPPTs | 3 | 3 | 3 |
| Number of Strings per MPPT | 1/1/1 | 1/1/1 | 1/1/1 |
| AC Side (Grid Port) | | | |
| Rated Power (kW) | 5 | 6 | 8 |
| Max. Power (kW) | 5 | 6 | 8 |
| Rated Apparent Power to Grid (kVA) | 5 | 6 | 8 |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 |
|---|--|--|--|
| Rated Apparent Power from Grid (kVA) | 5 | 6 | 8 |
| Max. Apparent Power to Grid (kVA) ^{*3} | 5 | 6 | 8 |
| Max. Apparent Power from Grid (kVA) | 43.5 ^{*4} | 43.5 ^{*4} | 43.5 ^{*4} |
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Voltage Range (V) | 180 ~ 260 (According to local standard) | 180 ~ 260 (According to local standard) | 180 ~ 260 (According to local standard) |
| Nominal Frequency (Hz) | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current to Grid (A) | 7.6 @380V 7.3 @400V | 9.1 @380V 8.7 @400V | 12.2 @380V 11.6 @400V |
| Rated Current from Grid (A) | 7.6 @380V 7.3 @400V | 9.1 @380V 8.7 @400V | 12.2 @380V 11.6 @400V |
| Max. Current to Grid (A) ^{*6} | 7.6 @380V 7.3 @400V | 9.1 @380V 8.7 @400V | 12.2 @380V 11.6 @400V |
| Max. Current from Grid (A) ^{*6} | 63.0 ^{*4} | 63.0 ^{*4} | 63.0 ^{*4} |
| Max. Output Fault Current (Peak and Duration) (A) | 46.7@4μs | 46.7@4μs | 46.7@4μs |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 |
|--|---|--|---|
| Inrush Current (Peak and Duration) (A) | 21.3@5ms | 21.3@5ms | 21.3@5ms |
| THDi | <3% | <3% | <3% |
| Maximum Output Overcurrent Protection (A) | 46.7 | 46.7 | 46.7 |
| Type of Voltage | a.c. | a.c. | a.c. |
| AC Side (Back-up Port) | | | |
| Rated Apparent Power (kVA) | 5 | 6 | 8 |
| Max. Apparent Power (kVA) ^{*7} | Off-grid: 5.5 (10.0, 10s), on-grid: 43.5 | Off-grid: 6.6(12, 10s), on-grid: 43.5 | Off-grid: 8.8 (16.0, 10s), on-grid: 43.5 |
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Nominal Frequency (Hz) | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current (A) | 7.6 @380V 7.3 @400V | 9.1 @380V 8.7 @400V | 12.2 @380V 11.6 @400V |
| Max. Current (A) ^{*7} | Off-grid: 11.4, on-grid: 63 | Off-grid: 13.7, on-grid:63 | Off-grid: 18.2, on-grid: 63 |
| Max. Fault Current (Peak and Duration) (A) | 46.7@4μs | 46.7@4μs | 46.7@4μs |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 |
|--|---------------------|---------------------|---------------------|
| Inrush Current (Peak and Duration) (A) | 21.3@5ms | 21.3@5ms | 21.3@5ms |
| Maximum Overcurrent Protection (A) | 46.7 | 46.7 | 46.7 |
| THDv (@Linear Load) | <3% | <3% | <3% |
| On/Off-grid Switching Time (ms) | <4 | <4 | <4 |
| Efficiency | | | |
| Max. Efficiency | 98.00% | 98.00% | 98.00% |
| European Efficiency | 96.40% | 96.90% | 97.10% |
| Max. Battery to AC Efficiency | 98.00% | 98.00% | 98.00% |
| Protection | | | |
| PV String Current Monitoring | Integrated | Integrated | Integrated |
| PV Insulation Resistance Detection | Integrated | Integrated | Integrated |
| Residual Current Monitoring | Integrated | Integrated | Integrated |
| PV Reverse Polarity Protection | Integrated | Integrated | Integrated |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 |
|-------------------------------------|-----------------------------|-----------------------------|-----------------------------|
| Battery Reverse Polarity Protection | Integrated | Integrated | Integrated |
| Anti-islanding Protection | Integrated | Integrated | Integrated |
| AC Overcurrent Protection | Integrated | Integrated | Integrated |
| AC Short Circuit Protection | Integrated | Integrated | Integrated |
| AC Overvoltage Protection | Integrated | Integrated | Integrated |
| DC Switch | Integrated | Integrated | Integrated |
| DC Surge Protection | Type II(Type I+II optional) | Type II(Type I+II optional) | Type II(Type I+II optional) |
| AC Surge Protection | Type II | Type II | Type II |
| Rapid Shutdown | Optional | Optional | Optional |
| AFCI | Optional | Optional | Optional |
| Remote Shutdown | Integrated | Integrated | Integrated |
| General Data | | | |
| Power Factor | 0.8 leading ... 0.8 lagging | 0.8 leading ... 0.8 lagging | 0.8 leading ... 0.8 lagging |
| Operating Temperature Range (°C) | -35~+60 | -35~+60 | -35~+60 |
| Operating Environment | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 |
|-------------------------------|---|---|---|
| Relative Humidity | 0~100% | 0~100% | 0~100% |
| Max. Operating Altitude (m) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) |
| Cooling Method | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling |
| User Interface | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP |
| Communication with BMS | CAN | CAN | CAN |
| Communication | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) |
| Communication Protocols | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP |
| Weight (kg) | 34 | 34 | 34 |
| Dimension (W×H×D mm) | 800*340*270 | 800*340*270 | 800*340*270 |
| Noise Emission (dB) | ≤35 | ≤35 | ≤35 |
| Topology | Non-isolated | Non-isolated | Non-isolated |
| Self-consumption at Night (W) | ≤10 | ≤10 | ≤10 |
| Ingress Protection Rating | IP66 | IP66 | IP66 |
| DC Connector | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 |
|--|--|--|--|
| AC Connector | VACONN Terminal | VACONN Terminal | VACONN Terminal |
| Environmental Category | 4K4H | 4K4H | 4K4H |
| Pollution Degree | III | III | III |
| Overvoltage Category | DC II / AC III | DC II / AC III | DC II / AC III |
| Protective Class | I | I | I |
| Storage Temperature (°C) | -40~+70 | -40~+70 | -40~+70 |
| The Decisive Voltage Class (DVC) | Battery: C PV: C AC: C Com: A | Battery: C PV: C AC: C Com: A | Battery: C PV: C AC: C Com: A |
| Mounting Method | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted |
| Active Anti-islanding Method ^{*8} | SMS(Slip-mode frequency) +AFD | SMS(Slip-mode frequency) +AFD | SMS(Slip-mode frequency) +AFD |
| Type of Electrical Supply System | three phase | three phase | three phase |
| Country of Manufacture | China | China | China |
| Certification | | | |
| Grid Standard | Please refer to the official website | | |
| Safety Regulation | | | |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 |
|----------------|--------------|--------------|--------------|
| EMC | | | |

| Technical Data | GW9.999K-ETA-G20 | GW10K-ETA-G20 | GW12K-ETA-G20 |
|---|----------------------------|----------------------------|----------------------------|
| Battery Side | | | |
| Battery Type | LFP (LiFePO ₄) | LFP (LiFePO ₄) | LFP (LiFePO ₄) |
| Nominal Voltage (V) | 750 | 750 | 750 |
| Voltage Range (V) | 700~950 | 700~950 | 700~950 |
| Start-up Voltage (V) | 720 | 720 | 720 |
| Number of Battery Input | 1 | 1 | 1 |
| Max. Continuous Charging Current (A) | 13.4 | 13.4 | 16.1 |
| Max. Continuous Discharging Current (A) | 14.7 | 14.7 | 17.7 |
| Max. Charging Power (kW) | 10 | 10 | 12 |
| Max. Discharging Power (kW) | 11 | 11 | 13.2 |
| PV Side | | | |
| Max. Input Power (kW) | 20 | 20 | 24 |

| Technical Data | GW9.999K-ETA-G20 | GW10K-ETA-G20 | GW12K-ETA-G20 |
|--|-------------------------|----------------------|----------------------|
| Max. Input Voltage (V) ^{*1} | 1000 | 1000 | 1000 |
| MPPT Operating Voltage Range (V) ^{*2} | 120~950 | 120~950 | 120~950 |
| MPPT Voltage Range at Nominal Power (V) | 250~850 | 250~850 | 300~850 |
| Start-up Voltage (V) | 150 | 150 | 150 |
| Nominal Input Voltage (V) | 750 | 750 | 750 |
| Max. MPPT Current (A) | 21/21/21/21 | 21/21/21/21 | 21/21/21/21 |
| Max. MPPT Short Circuit Current (A) | 26/26/26/26 | 26/26/26/26 | 26/26/26/26 |
| Max. Backfeed Current to The Array (A) | 0 | 0 | 0 |
| Number of MPPTs | 4 | 4 | 4 |
| Number of Strings per MPPT | 1/1/1/1 | 1/1/1/1 | 1/1/1/1 |
| AC Side (Grid Port) | | | |
| Rated Power (kW) | 9.999 | 10 | 12 |
| Max. Power (kW) | 9.999 | 10 | 12 |
| Rated Apparent Power to Grid (kVA) | 9.999 | 10 | 12 |

| Technical Data | GW9.999K-ETA-G20 | GW10K-ETA-G20 | GW12K-ETA-G20 |
|---|--|--|--|
| Rated Apparent Power from Grid (kVA) | 9.999 | 10 | 12 |
| Max. Apparent Power to Grid (kVA) ^{*3} | 9.999 | 10 | 12 |
| Max. Apparent Power from Grid (kVA) | 43.5 ^{*4} | 43.5 ^{*4} | 43.5 ^{*4} |
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Voltage Range (V) | 180 ~ 260 (According to local standard) | 180 ~ 260 (According to local standard) | 180 ~ 260 (According to local standard) |
| Nominal Frequency (Hz) | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current to Grid (A) | 15.2 @380V 14.5 @400V | 15.2 @380V 14.5 @400V | 18.2 @380V 17.4 @400V |
| Rated Current from Grid (A) | 15.2 @380V 14.5 @400V | 15.2 @380V 14.5 @400V | 18.2 @380V 17.4 @400V |
| Max. Current to Grid (A) ^{*6} | 15.2 @380V 14.5 @400V | 15.2 @380V 14.5 @400V | 18.2 @380V 17.4 @400V |
| Max. Current from Grid (A) ^{*6} | 63.0 ^{*4} | 63.0 ^{*4} | 63.0 ^{*4} |
| Max. Output Fault Current (Peak and Duration) (A) | 74.6@4μs | 74.6@4μs | 74.6@4μs |

| Technical Data | GW9.999K-ETA-G20 | GW10K-ETA-G20 | GW12K-ETA-G20 |
|--|---|---|---|
| Inrush Current (Peak and Duration) (A) | 25.4@5ms | 25.4@5ms | 25.4@5ms |
| THDi | <3% | <3% | <3% |
| Maximum Output Overcurrent Protection (A) | 74.6 | 74.6 | 74.6 |
| Type of Voltage | a.c. | a.c. | a.c. |
| AC Side (Back-up Port) | | | |
| Rated Apparent Power (kVA) | 10 | 10 | 12 |
| Max. Apparent Power (kVA) ^{*7} | Off-grid: 11(20.0, 10s), on-grid: 43.5 | Off-grid: 11(20.0, 10s), on-grid: 43.5 | Off-grid: 13.2(24, 10s), on-grid: 43.5 |
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Nominal Frequency (Hz) | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current (A) | 15.2 @380V 14.5 @400V | 15.2 @380V 14.5 @400V | 18.2 @380V 17.4 @400V |
| Max. Current (A) ^{*7} | Off-grid: 22.8, on-grid:63 | Off-grid: 22.8, on-grid: 63 | Off-grid: 27.3, on-grid: 63 |
| Max. Fault Current (Peak and Duration) (A) | 74.6@4μs | 74.6@4μs | 74.6@4μs |

| Technical Data | GW9.999K-ETA-G20 | GW10K-ETA-G20 | GW12K-ETA-G20 |
|--|-------------------------|----------------------|----------------------|
| Inrush Current (Peak and Duration) (A) | 25.4@5ms | 25.4@5ms | 25.4@5ms |
| Maximum Overcurrent Protection (A) | 74.6 | 74.6 | 74.6 |
| THDv (@Linear Load) | <3% | <3% | <3% |
| On/Off-grid Switching Time (ms) | <4 | <4 | <4 |
| Efficiency | | | |
| Max. Efficiency | 98.10% | 98.10% | 98.10% |
| European Efficiency | 97.20% | 97.20% | 97.20% |
| Max. Battery to AC Efficiency | 98.00% | 98.00% | 98.00% |
| Protection | | | |
| PV String Current Monitoring | Integrated | Integrated | Integrated |
| PV Insulation Resistance Detection | Integrated | Integrated | Integrated |
| Residual Current Monitoring | Integrated | Integrated | Integrated |
| PV Reverse Polarity Protection | Integrated | Integrated | Integrated |

| Technical Data | GW9.999K-ETA-G20 | GW10K-ETA-G20 | GW12K-ETA-G20 |
|-------------------------------------|-----------------------------|-----------------------------|-----------------------------|
| Battery Reverse Polarity Protection | Integrated | Integrated | Integrated |
| Anti-islanding Protection | Integrated | Integrated | Integrated |
| AC Overcurrent Protection | Integrated | Integrated | Integrated |
| AC Short Circuit Protection | Integrated | Integrated | Integrated |
| AC Overvoltage Protection | Integrated | Integrated | Integrated |
| DC Switch | Integrated | Integrated | Integrated |
| DC Surge Protection | Type II(Type I+II optional) | Type II(Type I+II optional) | Type II(Type I+II optional) |
| AC Surge Protection | Type II | Type II | Type II |
| Rapid Shutdown | Optional | Optional | Optional |
| AFCI | Optional | Optional | Optional |
| Remote Shutdown | Integrated | Integrated | Integrated |
| General Data | | | |
| Power Factor | 0.8 leading ... 0.8 lagging | 0.8 leading ... 0.8 lagging | 0.8 leading ... 0.8 lagging |
| Operating Temperature Range (°C) | -35~+60 | -35~+60 | -35~+60 |

| Technical Data | GW9.999K-ETA-G20 | GW10K-ETA-G20 | GW12K-ETA-G20 |
|-------------------------------|---|---|---|
| Operating Environment | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor |
| Relative Humidity | 0~100% | 0~100% | 0~100% |
| Max. Operating Altitude (m) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) |
| Cooling Method | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling |
| User Interface | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP |
| Communication with BMS | CAN | CAN | CAN |
| Communication | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) |
| Communication Protocols | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP |
| Weight (kg) | 34 | 34 | 34 |
| Dimension (W×H×D mm) | 800*340*270 | 800*340*270 | 800*340*270 |
| Noise Emission (dB) | ≤40 | ≤40 | ≤40 |
| Topology | Non-isolated | Non-isolated | Non-isolated |
| Self-consumption at Night (W) | ≤10 | ≤10 | ≤10 |
| Ingress Protection Rating | IP66 | IP66 | IP66 |

| Technical Data | GW9.999K-ETA-G20 | GW10K-ETA-G20 | GW12K-ETA-G20 |
|--|--|--|--|
| DC Connector | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal |
| AC Connector | VACONN Terminal | VACONN Terminal | VACONN Terminal |
| Environmental Category | 4K4H | 4K4H | 4K4H |
| Pollution Degree | III | III | III |
| Overvoltage Category | DC II / AC III | DC II / AC III | DC II / AC III |
| Protective Class | I | I | I |
| Storage Temperature (°C) | -40~+70 | -40~+70 | -40~+70 |
| The Decisive Voltage Class (DVC) | Battery: C PV: C AC: C Com: A | Battery: C PV: C AC: C Com: A | Battery: C PV: C AC: C Com: A |
| Mounting Method | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted |
| Active Anti-islanding Method ^{*8} | SMS(Slip-mode frequency) +AFD | SMS(Slip-mode frequency) +AFD | SMS(Slip-mode frequency) +AFD |
| Type of Electrical Supply System | three phase | three phase | three phase |
| Country of Manufacture | China | China | China |
| Certification | | | |

| Technical Data | GW9.999K-ETA-G20 | GW10K-ETA-G20 | GW12K-ETA-G20 |
|-------------------|--------------------------------------|---------------|---------------|
| Grid Standard | Please refer to the official website | | |
| Safety Regulation | | | |
| EMC | | | |

| Technical Data | GW15K-ETA-G20 | GW20K-ETA-G20 | GW25K-ETA-G20 |
|---|----------------------------|----------------------------|----------------------------|
| Battery Side | | | |
| Battery Type | LFP (LiFePO ₄) | LFP (LiFePO ₄) | LFP (LiFePO ₄) |
| Nominal Voltage (V) | 750 | 750 | 750 |
| Voltage Range (V) | 700~950 | 700~950 | 700~950 |
| Start-up Voltage (V) | 720 | 720 | 720 |
| Number of Battery Input | 1 | 1 | 1 |
| Max. Continuous Charging Current (A) | 20.1 | 26.7 | 33.3 |
| Max. Continuous Discharging Current (A) | 22.1 | 29.4 | 36.7 |
| Max. Charging Power (kW) | 15 | 20 | 25 |
| Max. Discharging Power (kW) | 16.5 | 22 | 27.5 |
| PV Side | | | |

| Technical Data | GW15K-ETA-G20 | GW20K-ETA-G20 | GW25K-ETA-G20 |
|--|----------------------|----------------------|----------------------|
| Max. Input Power (kW) | 30 | 40 | 50 |
| Max. Input Voltage (V) ^{*1} | 1000 | 1000 | 1000 |
| MPPT Operating Voltage Range (V) ^{*2} | 120~950 | 120~950 | 120~950 |
| MPPT Voltage Range at Nominal Power (V) | 360~850 | 400~850 | 400~850 |
| Start-up Voltage (V) | 150 | 150 | 150 |
| Nominal Input Voltage (V) | 750 | 750 | 750 |
| Max. MPPT Current (A) | 21/21/21/21 | 21/21/21/21 | 21/21/42/42 |
| Max. MPPT Short Circuit Current (A) | 26/26/26/26 | 26/26/26/26 | 26/26/52/52 |
| Max. Backfeed Current to The Array (A) | 0 | 0 | 0 |
| Number of MPPTs | 4 | 4 | 4 |
| Number of Strings per MPPT | 1/1/1/1 | 1/1/1/1 | 1/1/2/2 |
| AC Side (Grid Port) | | | |
| Rated Power (kW) | 15 | 20 | 25 |
| Max. Power (kW) | 15 | 20 | 25 |

| Technical Data | GW15K-ETA-G20 | GW20K-ETA-G20 | GW25K-ETA-G20 |
|---|--|--|--|
| Rated Apparent Power to Grid (kVA) | 15 | 20 | 25 |
| Rated Apparent Power from Grid (kVA) | 15 | 20 | 25 |
| Max. Apparent Power to Grid (kVA) ^{*3} | 15 | 20 | 25 |
| Max. Apparent Power from Grid (kVA) | 43.5 ^{*4} | 43.5 ^{*4} | 55.2 ^{*5} |
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Voltage Range (V) | 180 ~ 260 (According to local standard) | 180 ~ 260 (According to local standard) | 180 ~ 260 (According to local standard) |
| Nominal Frequency (Hz) | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current to Grid (A) | 22.8 @380V 21.8 @400V | 30.4 @380V 29.0 @400V | 37.9 @380V 36.3 @400V |
| Rated Current from Grid (A) | 22.8 @380V 21.8 @400V | 30.4 @380V 29.0 @400V | 37.9 @380V 36.3 @400V |
| Max. Current to Grid (A) ^{*6} | 22.8 @380V 21.8 @400V | 30.4 @380V 29.0 @400V | 37.9 @380V 36.3 @400V |
| Max. Current from Grid (A) ^{*6} | 63.0 ^{*4} | 63.0 ^{*4} | 80.0 ^{*5} |

| Technical Data | GW15K-ETA-G20 | GW20K-ETA-G20 | GW25K-ETA-G20 |
|---|--|--|--|
| Max. Output Fault Current (Peak and Duration) (A) | 83.3@4μs | 83.3@4μs | 125@4μs |
| Inrush Current (Peak and Duration) (A) | 29.1@5ms | 29.1@5ms | 32.3@5ms |
| THDi | <3% | <3% | <3% |
| Maximum Output Overcurrent Protection (A) | 83.3 | 83.3 | 125 |
| Type of Voltage | a.c. | a.c. | a.c. |
| AC Side (Back-up Port) | | | |
| Rated Apparent Power (kVA) | 15 | 20 | 25 |
| Max. Apparent Power (kVA) ^{*7} | Off-grid: 16.5(30, 10s), on-grid:43.5 | Off-grid: 22(30.0, 10s), on-grid:43.5 | Off-grid: 27.5(45.0, 10s), on-grid:55.2 |
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Nominal Frequency (Hz) | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current (A) | 22.8 @380V 21.8 @400V | 30.4 @380V 29.0 @400V | 37.9 @380V 36.3 @400V |
| Max. Current (A) ^{*7} | Off-grid: 33.4, on-grid: 63 | Off-grid: 33.4, on-grid: 63 | Off-grid: 50.0, on-grid: 80 |

| Technical Data | GW15K-ETA-G20 | GW20K-ETA-G20 | GW25K-ETA-G20 |
|--|----------------------|----------------------|----------------------|
| Max. Fault Current (Peak and Duration) (A) | 83.3@4μs | 83.3@4μs | 125@4μs |
| Inrush Current (Peak and Duration) (A) | 29.1@5ms | 29.1@5ms | 32.3@5ms |
| Maximum Overcurrent Protection (A) | 83.3 | 83.3 | 125 |
| THDv (@Linear Load) | <3% | <3% | <3% |
| On/Off-grid Switching Time (ms) | <4 | <4 | <4 |
| Efficiency | | | |
| Max. Efficiency | 98.10% | 98.10% | 98.20% |
| European Efficiency | 97.30% | 97.30% | 97.40% |
| Max. Battery to AC Efficiency | 98.00% | 98.00% | 98.00% |
| Protection | | | |
| PV String Current Monitoring | Integrated | Integrated | Integrated |
| PV Insulation Resistance Detection | Integrated | Integrated | Integrated |
| Residual Current Monitoring | Integrated | Integrated | Integrated |

| Technical Data | GW15K-ETA-G20 | GW20K-ETA-G20 | GW25K-ETA-G20 |
|-------------------------------------|-----------------------------|-----------------------------|-----------------------------|
| PV Reverse Polarity Protection | Integrated | Integrated | Integrated |
| Battery Reverse Polarity Protection | Integrated | Integrated | Integrated |
| Anti-islanding Protection | Integrated | Integrated | Integrated |
| AC Overcurrent Protection | Integrated | Integrated | Integrated |
| AC Short Circuit Protection | Integrated | Integrated | Integrated |
| AC Overvoltage Protection | Integrated | Integrated | Integrated |
| DC Switch | Integrated | Integrated | Integrated |
| DC Surge Protection | Type II(Type I+II optional) | Type II(Type I+II optional) | Type II(Type I+II optional) |
| AC Surge Protection | Type II | Type II | Type II |
| Rapid Shutdown | Optional | Optional | Optional |
| AFCI | Optional | Optional | Optional |
| Remote Shutdown | Integrated | Integrated | Integrated |
| General Data | | | |
| Power Factor | 0.8 leading ... 0.8 lagging | 0.8 leading ... 0.8 lagging | 0.8 leading ... 0.8 lagging |
| Operating Temperature Range (°C) | -35~+60 | -35~+60 | -35~+60 |

| Technical Data | GW15K-ETA-G20 | GW20K-ETA-G20 | GW25K-ETA-G20 |
|-------------------------------|---|---|---|
| Operating Environment | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor |
| Relative Humidity | 0~100% | 0~100% | 0~100% |
| Max. Operating Altitude (m) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) |
| Cooling Method | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling |
| User Interface | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP |
| Communication with BMS | CAN | CAN | CAN |
| Communication | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) |
| Communication Protocols | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP |
| Weight (kg) | 34 | 34 | 38 |
| Dimension (W×H×D mm) | 800*340*270 | 800*340*270 | 800*340*270 |
| Noise Emission (dB) | ≤40 | ≤40 | ≤45 |
| Topology | Non-isolated | Non-isolated | Non-isolated |
| Self-consumption at Night (W) | ≤10 | ≤10 | ≤10 |
| Ingress Protection Rating | IP66 | IP66 | IP66 |

| Technical Data | GW15K-ETA-G20 | GW20K-ETA-G20 | GW25K-ETA-G20 |
|----------------------------------|--|--|--|
| DC Connector | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal |
| AC Connector | VACONN Terminal | VACONN Terminal | VACONN Terminal |
| Environmental Category | 4K4H | 4K4H | 4K4H |
| Pollution Degree | III | III | III |
| Overvoltage Category | DC II / AC III | DC II / AC III | DC II / AC III |
| Protective Class | I | I | I |
| Storage Temperature (°C) | -40~+70 | -40~+70 | -40~+70 |
| The Decisive Voltage Class (DVC) | Battery: C PV: C AC: C Com: A | Battery: C PV: C AC: C Com: A | Battery: C PV: C AC: C Com: A |
| Mounting Method | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted |
| Active Anti-islanding Method*8 | SMS(Slip-mode frequency) +AFD | SMS(Slip-mode frequency) +AFD | SMS(Slip-mode frequency) +AFD |
| Type of Electrical Supply System | three phase | three phase | three phase |
| Country of Manufacture | China | China | China |
| Certification | | | |
| Grid Standard | | | |

| Technical Data | GW15K-ETA-G20 | GW20K-ETA-G20 | GW25K-ETA-G20 |
|-------------------|--------------------------------------|---------------|---------------|
| Safety Regulation | Please refer to the official website | | |
| EMC | | | |

| Technical Data | GW29.999K-ETA-G20 | GW30K-ETA-G20 |
|--|----------------------------|----------------------------|
| Battery Side | | |
| Battery Type | LFP (LiFePO ₄) | LFP (LiFePO ₄) |
| Nominal Voltage (V) | 750 | 750 |
| Voltage Range (V) | 700~950 | 700~950 |
| Start-up Voltage (V) | 720 | 720 |
| Number of Battery Input | 1 | 1 |
| Max. Continuous Charging Current (A) | 40.0 | 40.0 |
| Max. Continuous Discharging Current (A) | 44.1 | 44.1 |
| Max. Charging Power (kW) | 30 | 30 |
| Max. Discharging Power (kW) | 33 | 33 |
| PV Side | | |
| Max. Input Power (kW) | 60 | 60 |
| Max. Input Voltage (V) ^{*1} | 1000 | 1000 |
| MPPT Operating Voltage Range (V) ^{*2} | 120~950 | 120~950 |

| Technical Data | GW29.999K-ETA-G20 | GW30K-ETA-G20 |
|---|---------------------------|---------------------------|
| MPPT Voltage Range at Nominal Power (V) | 450~850 | 450~850 |
| Start-up Voltage (V) | 150 | 150 |
| Nominal Input Voltage (V) | 750 | 750 |
| Max. MPPT Current (A) | 21/21/42/42 | 21/21/42/42 |
| Max. MPPT Short Circuit Current (A) | 26/26/52/52 | 26/26/52/52 |
| Max. Backfeed Current to The Array (A) | 0 | 0 |
| Number of MPPTs | 4 | 4 |
| Number of Strings per MPPT | 1/1/2/2 | 1/1/2/2 |
| AC Side (Grid Port) | | |
| Rated Power (kW) | 29.999 | 30 |
| Max. Power (kW) | 29.999 | 30 |
| Rated Apparent Power to Grid (kVA) | 29.999 | 30 |
| Rated Apparent Power from Grid (kVA) | 29.999 | 30 |
| Max. Apparent Power to Grid (kVA) ^{*3} | 29.999 | 30 |
| Max. Apparent Power from Grid (kVA) | 55.2 ^{*5} | 55.2 ^{*5} |
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |

| Technical Data | GW29.999K-ETA-G20 | GW30K-ETA-G20 |
|---|--|--|
| Voltage Range (V) | 180 ~ 260 (According to local standard) | 180 ~ 260 (According to local standard) |
| Nominal Frequency (Hz) | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current to Grid (A) | 45.5 @380V 43.5 @400V | 45.5 @380V 43.5 @400V |
| Rated Current from Grid (A) | 45.5 @380V 43.5 @400V | 45.5 @380V 43.5 @400V |
| Max. Current to Grid (A)*6 | 45.5 @380V 43.5 @400V | 45.5 @380V 43.5 @400V |
| Max. Current from Grid (A)*6 | 80.0*5 | 80.0*5 |
| Max. Output Fault Current (Peak and Duration) (A) | 125@4μs | 125@4μs |
| Inrush Current (Peak and Duration) (A) | 32.3@5ms | 32.3@5ms |
| THDi | <3% | <3% |
| Maximum Output Overcurrent Protection (A) | 125 | 125 |
| Type of Voltage | a.c. | a.c. |
| AC Side (Back-up Port) | | |
| Rated Apparent Power (kVA) | 30 | 30 |
| Max. Apparent Power (kVA)*7 | Off-grid: 33(45.0, 10s), on-grid: 55.2 | Off-grid: 33(45.0, 10s), on-grid:55.2 |

| Technical Data | GW29.999K-ETA-G20 | GW30K-ETA-G20 |
|--|--------------------------------|--------------------------------|
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Nominal Frequency (Hz) | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current (A) | 45.5 @380V 43.5 @400V | 45.5 @380V 43.5 @400V |
| Max. Current (A)*7 | Off-grid: 50.0, on-grid: 80 | Off-grid: 50.0, on-grid: 80 |
| Max. Fault Current (Peak and Duration) (A) | 125@4 μ s | 125@4 μ s |
| Inrush Current (Peak and Duration) (A) | 32.3@5ms | 32.3@5ms |
| Maximum Overcurrent Protection (A) | 125 | 125 |
| THDv (@Linear Load) | <3% | <3% |
| On/Off-grid Switching Time (ms) | <4 | <4 |
| Efficiency | | |
| Max. Efficiency | 98.20% | 98.20% |
| European Efficiency | 97.40% | 97.40% |
| Max. Battery to AC Efficiency | 98.00% | 98.00% |
| Protection | | |
| PV String Current Monitoring | Integrated | Integrated |

| Technical Data | GW29.999K-ETA-G20 | GW30K-ETA-G20 |
|-------------------------------------|-----------------------------|-----------------------------|
| PV Insulation Resistance Detection | Integrated | Integrated |
| Residual Current Monitoring | Integrated | Integrated |
| PV Reverse Polarity Protection | Integrated | Integrated |
| Battery Reverse Polarity Protection | Integrated | Integrated |
| Anti-islanding Protection | Integrated | Integrated |
| AC Overcurrent Protection | Integrated | Integrated |
| AC Short Circuit Protection | Integrated | Integrated |
| AC Overvoltage Protection | Integrated | Integrated |
| DC Switch | Integrated | Integrated |
| DC Surge Protection | Type II(Type I+II optional) | Type II(Type I+II optional) |
| AC Surge Protection | Type II | Type II |
| Rapid Shutdown | Optional | Optional |
| AFCI | Optional | Optional |
| Remote Shutdown | Integrated | Integrated |
| General Data | | |
| Power Factor | 0.8 leading ... 0.8 lagging | 0.8 leading ... 0.8 lagging |
| Operating Temperature Range (°C) | -35~+60 | -35~+60 |

| Technical Data | GW29.999K-ETA-G20 | GW30K-ETA-G20 |
|-------------------------------|---|---|
| Operating Environment | Indoor/Outdoor | Indoor/Outdoor |
| Relative Humidity | 0~100% | 0~100% |
| Max. Operating Altitude (m) | 4000 (>2000 derating) | 4000 (>2000 derating) |
| Cooling Method | Smart Fan Cooling | Smart Fan Cooling |
| User Interface | LED, WLAN+APP | LED, WLAN+APP |
| Communication with BMS | CAN | CAN |
| Communication | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) |
| Communication Protocols | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP |
| Weight (kg) | 38 | 38 |
| Dimension (W×H×D mm) | 800*340*270 | 800*340*270 |
| Noise Emission (dB) | ≤45 | ≤45 |
| Topology | Non-isolated | Non-isolated |
| Self-consumption at Night (W) | ≤10 | ≤10 |
| Ingress Protection Rating | IP66 | IP66 |
| DC Connector | MC4, VACONN Terminal | MC4, VACONN Terminal |
| AC Connector | VACONN Terminal | VACONN Terminal |

| Technical Data | GW29.999K-ETA-G20 | GW30K-ETA-G20 |
|----------------------------------|--|--|
| Environmental Category | 4K4H | 4K4H |
| Pollution Degree | III | III |
| Overvoltage Category | DC II / AC III | DC II / AC III |
| Protective Class | I | I |
| Storage Temperature (°C) | -40~+70 | -40~+70 |
| The Decisive Voltage Class (DVC) | Battery: C PV: C AC: C Com: A | Battery: C PV: C AC: C Com: A |
| Mounting Method | Wall/Floor Mounted | Wall/Floor Mounted |
| Active Anti-islanding Method*8 | SMS(Slip-mode frequency) +AFD | SMS(Slip-mode frequency) +AFD |
| Type of Electrical Supply System | three phase | three phase |
| Country of Manufacture | China | China |
| Certification | | |
| Grid Standard | Please refer to the official website | |
| Safety Regulation | | |
| EMC | | |

*1: When the input voltage ranges from 950V to 1000V, the inverter will enter the standby mode, and the voltage returns to 950V to enter the normal operation state.

*2: Please refer to the user manual for the MPPT Voltage Range at nominal Power.

*3: According to the local grid regulation.

*4: GOODWE ESA series has internal bypass 63A passthrough ability to support whole

home backup solution. If the customer don't want to do any breaker upgrade, the main breaker size in GoodWe commissioning APP can be set as previous breaker size.

*5: GOODWE ESA series has internal bypass 80A passthrough ability to supprt whole home backup solution. If the customer don't want to do any breaker upgrade, the main breaker size in GoodWe commissioning APP can be set as previous breaker size.

*6: If the backup port is not used, select an appropriate circuit breaker based on the AC maximum output current.

*7:"Off grid"means the energy of backup output only comes from PV and battery. "On grid"means the energy of the backup output includes the energy from grid or generator(on-grid) side.

*8: AFDPF: Active Frequency Drift with Positive Feedback

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|--------------------------------------|---------------------|---------------------|---------------------|-------------------------|
| Battery Side | | | | |
| Battery Type | Li-Ion | Li-Ion | Li-Ion | Li-Ion |
| Nominal Voltage (V) | 750 | 750 | 750 | 750 |
| Voltage Range (V) | 700-950 | 700-950 | 700-950 | 700-950 |
| Start-up Voltage (V) | 720 | 720 | 720 | 720 |
| Number of Battery Inputs | 1 | 1 | 1 | 1 |
| Max. Continuous Charging Current (A) | 6.7 | 8.1 | 10.7 | 13.4 |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|---|---------------------|---------------------|---------------------|-------------------------|
| Max. Continuous Discharging Current (A) | 7.4 | 8.9 | 11.8 | 14.7 |
| Max. Charging Power (kW) | 5 | 6 | 8 | 10 |
| Max. Discharging Power (kW) | 5.5 | 6.6 | 8.8 | 11 |
| AC Side (On-Grid) | | | | |
| Rated Power (kW) | 5 | 6 | 8 | 9.999 |
| Max. Power (kW) | 5 | 6 | 8 | 9.999 |
| Rated Apparent Power to Grid (kVA) | 5 | 6 | 8 | 9.999 |
| Rated Apparent Power from Grid (kVA) | 5 | 6 | 8 | 9.999 |
| Max. Apparent Power to Grid (kVA) | 5 | 6 | 8 | 9.999 |
| Max. Apparent Power from Grid (kVA) | 43.5 | 43.5 | 43.5 | 43.5 |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|---|--|--|--|--|
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Voltage Range (V) | 180 ~ 260 (According to local standard) |
| Nominal Frequency (Hz) | 50/60 | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current to Grid (A) | 7.6 at 380V 7.3 at 400V | 9.1 at 380V 8.7 at 400V | 12.2 at 380V 11.6 at 400V | 15.2 at 380V 14.5 at 400V |
| Rated Current from Grid (A) | 7.6 at 380V 7.3 at 400V | 9.1 at 380V 8.7 at 400V | 12.2 at 380V 11.6 at 400V | 15.2 at 380V 14.5 at 400V |
| Max. Current to Grid (A) | 7.6 at 380V 7.3 at 400V | 9.1 at 380V 8.7 at 400V | 12.2 at 380V 11.6 at 400V | 15.2 at 380V 14.5 at 400V |
| Max. Current from Grid (A) | 63.0 | 63.0 | 63.0 | 63.0 |
| Max. Output Fault Current (Peak and Duration) (A) | 46.7@4μs | 46.7@4μs | 46.7@4μs | 74.6@4μs |
| Inrush Current (Peak and Duration) (A) | 21.3@5ms | 21.3@5ms | 21.3@5ms | 25.4@5ms |
| THDi | <3% | <3% | <3% | <3% |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|---|--|---------------------------------------|--|--|
| Maximum Output Overcurrent Protection (A) | 46.7 | 46.7 | 46.7 | 74.6 |
| Type of Voltage | a.c. | a.c. | a.c. | a.c. |
| Back-up Side | | | | |
| Rated Output Apparent Power (kVA) | 5 | 6 | 8 | 10 |
| Max. Output Apparent Power (kVA) | Off-grid: 5.5 (10.0, 10s), on-grid: 43.5 | Off-grid: 6.6(12, 10s), on-grid: 43.5 | Off-grid: 8.8 (16.0, 10s), on-grid: 43.5 | Off-grid: 11(20.0, 10s), on-grid: 43.5 |
| Nominal Output Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Nominal Output Frequency (Hz) | 50/60 | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Output Current (A) | 7.6 at 380V 7.3 at 400V | 9.1 at 380V 8.7 at 400V | 12.2 at 380V 11.6 at 400V | 15.2 at 380V 14.5 at 400V |
| Max. Output Current (A) ^{*3} | Off-grid: 11.4, on-grid: 63 | Off-grid: 13.7, on-grid:63 | Off-grid: 18.2, on-grid: 63 | Off-grid: 22.8, on-grid:63 |
| Max. Output Fault Current (Peak and Duration) (A) | 46.7@4μs | 46.7@4μs | 46.7@4μs | 74.6@4μs |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|--|---------------------|---------------------|---------------------|-------------------------|
| Inrush Current (Peak and Duration) (A) | 21.3@5ms | 21.3@5ms | 21.3@5ms | 25.4@5ms |
| Maximum Overcurrent Protection (A) | 46.7 | 46.7 | 46.7 | 74.6 |
| THDv (@Linear Load) | <3% | <3% | <3% | <3% |
| On/Off-grid Switching Time (ms) | <4 | <4 | <4 | <4 |
| Efficiency | | | | |
| Max. Efficiency | 98.00% | 98.00% | 98.00% | 98.10% |
| European Efficiency | 96.40% | 96.90% | 97.10% | 97.20% |
| CEC Efficiency | NA | NA | NA | NA |
| Max. Battery to AC Efficiency | 98.00% | 98.00% | 98.00% | 98.00% |
| Protection | | | | |
| Residual Current Monitoring | Integrated | Integrated | Integrated | Integrated |
| Battery Reverse Polarity Protection | Integrated | Integrated | Integrated | Integrated |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|----------------------------------|--------------------------------|--------------------------------|--------------------------------|--------------------------------|
| Anti-islanding Protection | Integrated | Integrated | Integrated | Integrated |
| AC Overcurrent Protection | Integrated | Integrated | Integrated | Integrated |
| AC Short Circuit Protection | Integrated | Integrated | Integrated | Integrated |
| AC Overvoltage Protection | Integrated | Integrated | Integrated | Integrated |
| AC Surge Protection | Type II | Type II | Type II | Type II |
| Remote Shutdown | Integrated | Integrated | Integrated | Integrated |
| General Data | | | | |
| Power Factor | 0.8 leading ... 0.8 lagging |
| Operating Temperature Range (°C) | -35~+60 | -35~+60 | -35~+60 | -35~+60 |
| Operating Environment | Indoor/Outdoor or | Indoor/Outdoor or | Indoor/Outdoor or | Indoor/Outdoor or |
| Relative Humidity | 0~100% | 0~100% | 0~100% | 0~100% |
| Max. Operating Altitude (m) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|---------------------------------------|---|---|---|---|
| Cooling Method | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling |
| User Interface | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP |
| Communication with BMS | CAN | CAN | CAN | CAN |
| Communication | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) |
| Communication Protocols | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP |
| Weight (kg) | 30 | 30 | 30 | 30 |
| Dimension (W×H×D mm) | 800*340*270 | 800*340*270 | 800*340*270 | 800*340*270 |
| Noise Emission (dB) | ≤35 | ≤35 | ≤35 | ≤35 |
| Topology | Non-isolated | Non-isolated | Non-isolated | Non-isolated |
| Self-consumption at Night (W) | ≤10 | ≤10 | ≤10 | ≤10 |
| Conditional Short-circuit Current (A) | 6000 | 6000 | 6000 | 6000 |
| Ingress Protection Rating | IP66 | IP66 | IP66 | IP66 |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|----------------------------------|---|---|---|---|
| DC Connector | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal |
| AC Connector | VACONN Terminal | VACONN Terminal | VACONN Terminal | VACONN Terminal |
| Environmental Category | 4K4H | 4K4H | 4K4H | 4K4H |
| Pollution Degree | III | III | III | III |
| Overvoltage Category | DC II / AC III |
| Protective Class | I | I | I | I |
| Storage Temperature (°C) | -40~+70 | -40~+70 | -40~+70 | -40~+70 |
| The Decisive Voltage Class (DVC) | Battery: C | Battery: C | Battery: C | Battery: C |
| | AC: C | AC: C | AC: C | AC: C |
| | Com: A | Com: A | Com: A | Com: A |
| Mounting Method | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted |
| Active Anti-islanding Method | SMS(Slip-mode frequency) +AFD ^{*4} |
| Type of Electrical Supply System | three phase | three phase | three phase | three phase |
| Country of Manufacture | China | China | China | China |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|-----------------------|--------------------------------------|---------------------|---------------------|-------------------------|
| Certification | | | | |
| Grid Standard | Please refer to the official website | | | |
| Safety Regulation | | | | |
| EMC | | | | |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|---|----------------------|----------------------|----------------------|----------------------|
| Battery Side | | | | |
| Battery Type | Li-Ion | Li-Ion | Li-Ion | Li-Ion |
| Nominal Voltage (V) | 750 | 750 | 750 | 750 |
| Voltage Range (V) | 700-950 | 700-950 | 700-950 | 700-950 |
| Start-up Voltage (V) | 720 | 720 | 720 | 720 |
| Number of Battery Inputs | 1 | 1 | 1 | 1 |
| Max. Continuous Charging Current (A) | 13.4 | 16.1 | 20.1 | 26.7 |
| Max. Continuous Discharging Current (A) | 14.7 | 17.7 | 22.1 | 29.4 |
| Max. Charging Power (kW) | 10 | 12 | 15 | 20 |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|--------------------------------------|--|--|--|--|
| Max. Discharging Power (kW) | 11 | 13.2 | 16.5 | 22 |
| AC Side (On-Grid) | | | | |
| Rated Power (kW) | 10 | 12 | 15 | 20 |
| Max. Power (kW) | 10 | 12 | 15 | 20 |
| Rated Apparent Power to Grid (kVA) | 10 | 12 | 15 | 20 |
| Rated Apparent Power from Grid (kVA) | 10 | 12 | 15 | 20 |
| Max. Apparent Power to Grid (kVA) | 10 | 12 | 15 | 20 |
| Max. Apparent Power from Grid (kVA) | 43.5 | 43.5 | 43.5 | 43.5 |
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Voltage Range (V) | 180 ~ 260 (According to local standard) |
| Nominal Frequency (Hz) | 50/60 | 50/60 | 50/60 | 50/60 |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|---|------------------------------|------------------------------|------------------------------|------------------------------|
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current to Grid (A) | 15.2 at 380V 14.5 at 400V | 18.2 at 380V 17.4 at 400V | 22.8 at 380V 21.8 at 400V | 30.4 at 380V 29.0 at 400V |
| Rated Current from Grid (A) | 15.2 at 380V 14.5 at 400V | 18.2 at 380V 17.4 at 400V | 22.8 at 380V 21.8 at 400V | 30.4 at 380V 29.0 at 400V |
| Max. Current to Grid (A) | 15.2 at 380V 14.5 at 400V | 18.2 at 380V 17.4 at 400V | 22.8 at 380V 21.8 at 400V | 30.4 at 380V 29.0 at 400V |
| Max. Current from Grid (A) | 63.0 | 63.0 | 63.0 | 63.0 |
| Max. Output Fault Current (Peak and Duration) (A) | 74.6@4μs | 74.6@4μs | 83.3@4μs | 83.3@4μs |
| Inrush Current (Peak and Duration) (A) | 25.4@5ms | 25.4@5ms | 29.1@5ms | 29.1@5ms |
| THDi | <3% | <3% | <3% | <3% |
| Maximum Output Overcurrent Protection (A) | 74.6 | 74.6 | 83.3 | 83.3 |
| Type of Voltage | a.c. | a.c. | a.c. | a.c. |
| Back-up Side | | | | |
| Rated Output Apparent Power (kVA) | 10 | 12 | 15 | 20 |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|---|--|--|--|--|
| Max. Output Apparent Power (kVA)*6 | Off-grid: 11(20.0, 10s), on-grid: 43.5 | Off-grid: 13.2(24, 10s), on-grid: 43.5 | Off-grid: 16.5(30, 10s), on-grid: 43.5 | Off-grid: 22(30.0, 10s), on-grid: 43.5 |
| Nominal Output Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Nominal Output Frequency (Hz) | 50/60 | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Output Current (A) | 15.2 at 380V 14.5 at 400V | 18.2 at 380V 17.4 at 400V | 22.8 at 380V 21.8 at 400V | 30.4 at 380V 29.0 at 400V |
| Max. Output Current (A)*3 | Off-grid: 22.8, on-grid: 63 | Off-grid: 27.3, on-grid: 63 | Off-grid: 33.4, on-grid: 63 | Off-grid: 33.4, on-grid: 63 |
| Max. Output Fault Current (Peak and Duration) (A) | 74.6@4μs | 74.6@4μs | 83.3@4μs | 83.3@4μs |
| Inrush Current (Peak and Duration) (A) | 25.4@5ms | 25.4@5ms | 29.1@5ms | 29.1@5ms |
| Maximum Overcurrent Protection (A) | 74.6 | 74.6 | 83.3 | 83.3 |
| THDv (@Linear Load) | <3% | <3% | <3% | <3% |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|-------------------------------------|----------------------|----------------------|----------------------|----------------------|
| On/Off-grid Switching Time (ms) | <4 | <4 | <4 | <4 |
| Efficiency | | | | |
| Max. Efficiency | 98.10% | 98.10% | 98.10% | 98.10% |
| European Efficiency | 97.20% | 97.20% | 97.30% | 97.30% |
| CEC Efficiency | NA | NA | NA | NA |
| Max. Battery to AC Efficiency | 98.00% | 98.00% | 98.00% | 98.00% |
| MPPT Efficiency | NA | NA | NA | NA |
| Protection | | | | |
| Residual Current Monitoring | Integrated | Integrated | Integrated | Integrated |
| Battery Reverse Polarity Protection | Integrated | Integrated | Integrated | Integrated |
| Anti-islanding Protection | Integrated | Integrated | Integrated | Integrated |
| AC Overcurrent Protection | Integrated | Integrated | Integrated | Integrated |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|----------------------------------|--------------------------------|--------------------------------|--------------------------------|--------------------------------|
| AC Short Circuit Protection | Integrated | Integrated | Integrated | Integrated |
| AC Overvoltage Protection | Integrated | Integrated | Integrated | Integrated |
| AC Surge Protection | Type II | Type II | Type II | Type II |
| Remote Shutdown | Integrated | Integrated | Integrated | Integrated |
| General Data | | | | |
| Power Factor | 0.8 leading ... 0.8 lagging |
| Operating Temperature Range (°C) | -35~+60 | -35~+60 | -35~+60 | -35~+60 |
| Operating Environment | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor |
| Relative Humidity | 0~100% | 0~100% | 0~100% | 0~100% |
| Max. Operating Altitude (m) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) |
| Cooling Method | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling |
| User Interface | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|---------------------------------------|---|---|---|---|
| Communication with BMS | CAN | CAN | CAN | CAN |
| Communication | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) |
| Communication Protocols | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP |
| Weight (kg) | 30 | 30 | 30 | 30 |
| Dimension (W×H×D mm) | 800*340*270 | 800*340*270 | 800*340*270 | 800*340*270 |
| Noise Emission (dB) | ≤35 | ≤35 | ≤40 | ≤40 |
| Topology | Non-isolated | Non-isolated | Non-isolated | Non-isolated |
| Self-consumption at Night (W) | ≤10 | ≤10 | ≤10 | ≤10 |
| Conditional Short-circuit Current (A) | 6000 | 6000 | 6000 | 6000 |
| Ingress Protection Rating | IP66 | IP66 | IP66 | IP66 |
| DC Connector | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal |
| AC Connector | VACONN Terminal | VACONN Terminal | VACONN Terminal | VACONN Terminal |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|----------------------------------|---------------------------------|---------------------------------|---------------------------------|---------------------------------|
| Environmental Category | 4K4H | 4K4H | 4K4H | 4K4H |
| Pollution Degree | III | III | III | III |
| Overvoltage Category | DC II / AC III |
| Protective Class | I | I | I | I |
| Storage Temperature (°C) | -40~+70 | -40~+70 | -40~+70 | -40~+70 |
| The Decisive Voltage Class (DVC) | Battery: C | Battery: C | Battery: C | Battery: C |
| | AC: C | AC: C | AC: C | AC: C |
| | Com: A | Com: A | Com: A | Com: A |
| Mounting Method | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted |
| Active Anti-islanding Method | SMS(Slip-mode frequency) +AFD*4 | SMS(Slip-mode frequency) +AFD*4 | SMS(Slip-mode frequency) +AFD*4 | SMS(Slip-mode frequency) +AFD*4 |
| Type of Electrical Supply System | three phase | three phase | three phase | three phase |
| Country of Manufacture | China | China | China | China |
| Certification | | | | |
| Grid Standard | | | | |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|-------------------|--------------------------------------|---------------|---------------|---------------|
| Safety Regulation | Please refer to the official website | | | |
| EMC | | | | |

| Technical Data | GW25K-BTA-G20 | GW29.999K-BTA-G20 | GW30K-BTA-G20 |
|---|---------------|-------------------|---------------|
| Battery Side | | | |
| Battery Type | Li-Ion | Li-Ion | Li-Ion |
| Nominal Voltage (V) | 750 | 750 | 750 |
| Voltage Range (V) | 700-950 | 700-950 | 700-950 |
| Start-up Voltage (V) | 720 | 720 | 720 |
| Number of Battery Inputs | 1 | 1 | 1 |
| Max. Continuous Charging Current (A) | 33.3 | 40.0 | 40.0 |
| Max. Continuous Discharging Current (A) | 36.7 | 44.1 | 44.1 |
| Max. Charging Power (kW) | 25 | 30 | 30 |
| Max. Discharging Power (kW) | 27.5 | 33 | 33 |
| AC Side (On-Grid) | | | |
| Rated Power (kW) | 25 | 29.999 | 30 |

| Technical Data | GW25K-BTA-G20 | GW29.999K-BTA-G20 | GW30K-BTA-G20 |
|--------------------------------------|--|--|--|
| Max. Power (kW) | 25 | 29.999 | 30 |
| Rated Apparent Power to Grid (kVA) | 25 | 29.999 | 30 |
| Rated Apparent Power from Grid (kVA) | 25 | 29.999 | 30 |
| Max. Apparent Power to Grid (kVA) | 25 | 29.999 | 30 |
| Max. Apparent Power from Grid (kVA) | 55.2 | 55.2 | 55.2 |
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Voltage Range (V) | 180 ~ 260 (According to local standard) | 180 ~ 260 (According to local standard) | 180 ~ 260 (According to local standard) |
| Nominal Frequency (Hz) | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current to Grid (A) | 37.9 at 380V 36.3 at 400V | 45.5 at 380V 43.5 at 400V | 45.5 at 380V 43.5 at 400V |
| Rated Current from Grid (A) | 37.9 at 380V 36.3 at 400V | 45.5 at 380V 43.5 at 400V | 45.5 at 380V 43.5 at 400V |
| Max. Current to Grid (A) | 37.9 at 380V 36.3 at 400V | 45.5 at 380V 43.5 at 400V | 45.5 at 380V 43.5 at 400V |
| Max. Current from Grid (A) | 80.0 | 80.0 | 80.0 |

| Technical Data | GW25K-BTA-G20 | GW29.999K-BTA-G20 | GW30K-BTA-G20 |
|---|---|---|---|
| Max. Output Fault Current (Peak and Duration) (A) | 125@4 μ s | 125@4 μ s | 125@4 μ s |
| Inrush Current (Peak and Duration) (A) | 32.3@5ms | 32.3@5ms | 32.3@5ms |
| THDi | <3% | <3% | <3% |
| Maximum Output Overcurrent Protection (A) | 125 | 125 | 125 |
| Type of Voltage | a.c. | a.c. | a.c. |
| Back-up Side | | | |
| Rated Output Apparent Power (kVA) | 25 | 30 | 30 |
| Max. Output Apparent Power (kVA)*6 | Off-grid: 27.5(45.0, 10s), on-grid: 55.2 | Off-grid: 33(45.0, 10s), on-grid: 55.2 | Off-grid: 33(45.0, 10s), on-grid: 55.2 |
| Nominal Output Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Nominal Output Frequency (Hz) | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Output Current (A) | 37.9 at 380V 36.3 at 400V | 45.5 at 380V 43.5 at 400V | 45.5 at 380V 43.5 at 400V |
| Max. Output Current (A)*3 | Off-grid: 50.0, on-grid: 80 | Off-grid: 50.0, on-grid: 80 | Off-grid: 50.0, on-grid: 80 |

| Technical Data | GW25K-BTA-G20 | GW29.999K-BTA-G20 | GW30K-BTA-G20 |
|---|----------------------|--------------------------|----------------------|
| Max. Output Fault Current (Peak and Duration) (A) | 125@4 μ s | 125@4 μ s | 125@4 μ s |
| Inrush Current (Peak and Duration) (A) | 32.3@5ms | 32.3@5ms | 32.3@5ms |
| Maximum Overcurrent Protection (A) | 125 | 125 | 125 |
| THDv (@Linear Load) | <3% | <3% | <3% |
| On/Off-grid Switching Time (ms) | <4 | <4 | <4 |
| Efficiency | | | |
| Max. Efficiency | 98.20% | 98.20% | 98.20% |
| European Efficiency | 97.40% | 97.40% | 97.40% |
| CEC Efficiency | NA | NA | NA |
| Max. Battery to AC Efficiency | 98.00% | 98.00% | 98.00% |
| Protection | | | |
| Residual Current Monitoring | Integrated | Integrated | Integrated |
| Battery Reverse Polarity Protection | Integrated | Integrated | Integrated |
| Anti-islanding Protection | Integrated | Integrated | Integrated |

| Technical Data | GW25K-BTA-G20 | GW29.999K-BTA-G20 | GW30K-BTA-G20 |
|----------------------------------|-----------------------------|-----------------------------|-----------------------------|
| AC Overcurrent Protection | Integrated | Integrated | Integrated |
| AC Short Circuit Protection | Integrated | Integrated | Integrated |
| AC Overvoltage Protection | Integrated | Integrated | Integrated |
| AC Surge Protection | Type II | Type II | Type II |
| Remote Shutdown | Integrated | Integrated | Integrated |
| General Data | | | |
| Power Factor | 0.8 leading ... 0.8 lagging | 0.8 leading ... 0.8 lagging | 0.8 leading ... 0.8 lagging |
| Operating Temperature Range (°C) | -35~+60 | -35~+60 | -35~+60 |
| Operating Environment | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor |
| Relative Humidity | 0~100% | 0~100% | 0~100% |
| Max. Operating Altitude (m) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) |
| Cooling Method | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling |
| User Interface | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP |
| Communication with BMS | CAN | CAN | CAN |

| Technical Data | GW25K-BTA-G20 | GW29.999K-BTA-G20 | GW30K-BTA-G20 |
|---------------------------------------|---|---|---|
| Communication | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) |
| Communication Protocols | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP |
| Weight (kg) | 32 | 32 | 32 |
| Dimension (W×H×D mm) | 800*340*270 | 800*340*270 | 800*340*270 |
| Noise Emission (dB) | ≤45 | ≤45 | ≤45 |
| Topology | Non-isolated | Non-isolated | Non-isolated |
| Self-consumption at Night (W) | ≤10 | ≤10 | ≤10 |
| Conditional Short-circuit Current (A) | 6000 | 6000 | 6000 |
| Ingress Protection Rating | IP66 | IP66 | IP66 |
| DC Connector | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal |
| AC Connector | VACONN Terminal | VACONN Terminal | VACONN Terminal |
| Environmental Category | 4K4H | 4K4H | 4K4H |
| Pollution Degree | IV | IV | IV |
| Overvoltage Category | DC II / AC III | DC II / AC III | DC II / AC III |

| Technical Data | GW25K-BTA-G20 | GW29.999K-BTA-G20 | GW30K-BTA-G20 |
|----------------------------------|---|---|---|
| Protective Class | I | I | I |
| Storage Temperature (°C) | -40~+70 | -40~+70 | -40~+70 |
| The Decisive Voltage Class (DVC) | Battery: C | Battery: C | Battery: C |
| | AC: C | AC: C | AC: C |
| | Com: A | Com: A | Com: A |
| Mounting Method | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted |
| Active Anti-islanding Method | SMS(Slip-mode frequency) +AFD ^{*4} | SMS(Slip-mode frequency) +AFD ^{*4} | SMS(Slip-mode frequency) +AFD ^{*4} |
| Type of Electrical Supply System | three phase | three phase | three phase |
| Country of Manufacture | China | China | China |
| Certification | | | |
| Grid Standard | Please refer to the official website | | |
| Safety Regulation | | | |
| EMC | | | |

*1: When the input voltage ranges from 950V to 1000V, the inverter will enter the standby mode, and the voltage returns to 950V to enter the normal operation state.

*2: Please refer to the user manual for the MPPT Voltage Range at nominal Power.

*3: The Max. Output Current in off-grid operation accounts for a three-phase maximum 150% unbalanced capability.

*4: AFDPF: Active Frequency Drift with Positive Feedback, AQDPF: Active Q Drift with Positive Feedback.

9.2 Battery Technical Data

| Technical Data | GW5.1-BAT-D-G20 | GW8.3-BAT-D-G20 | GW5.1-BAT-D-G21 | GW8.3-BAT-D-G21 |
|---|----------------------------|-----------------|-----------------|-----------------|
| Rated Energy (kWh) | 5.12 | 8.32 | 5.12 | 8.32 |
| Usable Energy (kWh)*1 | 5 | 8 | 5 | 8 |
| Battery Type | LFP (LiFePO ₄) | | | |
| Operating Voltage Range (V) (single phase system) | 350~550 | | | |
| Operating Voltage Range (V) (three phase system) | 700~950 | | | |
| Max. Input Current (System) (A) | 12 | 19 | 12 | 19 |
| Max. Output Current (System) (A) | 13.2 | 21 | 13.2 | 21 |
| Max. Input Power (System) (kW)*2 | 5 | 8 | 5 | 8 |
| Max. Output Power (System) (kW)*2 | 5 | 8 | 5 | 8 |
| Peak.Output Power (System) (kW)*2 | 7.5 @10s | 12 @10s | 7.5 @10s | 12 @10s |
| Charging Temperature Range (°C) | -18~55 | | 2~55 | |
| Discharging Temperature Range (°C) | -20~55 | | -20~55 | |
| Relative Humidity | 5-95% | | | |
| Max. Operating Altitude (m) | 4000 | | | |

| Technical Data | | GW5.1-BAT-D-G20 | GW8.3-BAT-D-G20 | GW5.1-BAT-D-G21 | GW8.3-BAT-D-G21 |
|---------------------------------|----------------|---|-----------------|-----------------|-----------------|
| Noise Emission (dB) | | ≤29 | | | |
| Communication | | CAN | | | |
| Weight (kg) | | 57.5±1 | 79±1 | 57.5±1 | 79±1 |
| Dimensions (W×H×D mm) | | 800*326*270 | | | |
| Optional Function Configuration | | heating | | / | |
| Ingress Protection | | IP66 | | | |
| Storage Temperature (°C) | | -20 ~55 | | | |
| Max. Storage time | | 12 months (-20°C~35°C) | | | |
| | | 6 months (35°C~45°C) | | | |
| Scalability | | 6 pcs | | | |
| Mounting Method | | Floor stacked / Wall-mounted | | | |
| Cycle Life | | ≥6000 (25±2°C, 0.5C, 90%DOD, 70%EOL) | | | |
| Country of Manufacture | | China | | | |
| Standard and Certification | Safety | IEC62619, IEC60730, EN62477, IEC63056, IEC62040, CE, CEC, VDE2510 | | | |
| | EMC | CE, RCM | | | |
| | Transportation | UN38.3 ADR | | | |

| Technical Data | | GW6.0-BAT-D-G20 | GW9.0-BAT-D-G20 |
|---------------------|--|-----------------|-----------------|
| Battery Type | | LFP (LiFePO4) | |
| Rated Capacity (Ah) | | 314Ah | |
| Rated Energy (kWh) | | 6 | 9 |

| Technical Data | GW6.0-BAT-D-G20 | GW9.0-BAT-D-G20 |
|---|------------------------------------|------------------------|
| Usable Energy (kWh) ^{*1} | 5.9 | 8.85 |
| Nominal Voltage(V) (Battery) | 19.2 | 28.8 |
| Voltage Range(V) (Battery) | 16.2~21.9 | 24.3~32.8 |
| Operating Voltage Range (V) (single phase system) | 350~550 | |
| Operating Voltage Range (V) (three phase system) | 700~950 | |
| Max. Input Current (System) (A) | 7.1 | 10.7 |
| Max. Output Current (System) (A) | 7.9 | 11.8 |
| Max. Input Power (System) (kW) ^{*2} | 3 | 4.5 |
| Max. Output Power (System) (kW) ^{*2} | 3 | 4.5 |
| Peak Output Power (System) (kW) ^{*2} | 4.5 (10s) | 6.75 (10s) |
| Charging Temperature Range(°C) | -20~55 | |
| Discharging Temperature Range (°C) | -20~55 | |
| Relative Humidity | 4-100% | |
| Max. Operating Altitude (m) | 4000 | |
| Noise Emission (dB) | ≤27 | |
| Communication | CAN&485 | |
| Weight (kg) | 61±1kg | 77±1kg |
| Useable Extinguishing Agent | CO2, H2O | |
| Crucial Material | LiFePO4, C, Cu, LiPF6, Al, (C3H6)n | |
| Ingress Protection | IP66 | |
| Protective Class | I | |
| Dimensions (W×H×D mm) | 800*326*270 | |

| Technical Data | | GW6.0-BAT-D-G20 | GW9.0-BAT-D-G20 |
|----------------------------|----------------|---|-----------------|
| Function Configuration | | Heating (Integrated); Aerosol fire extinguishing (Integrated) | |
| Storage Temperature (°C) | | -20 ~55 | |
| Max. Storage time | | 12 months (-20°C~35°C) 6 months (35°C~45°C) | |
| Scalability*3 | | 12P | |
| Mounting Method | | Floor stacked / Wall-mounted / Grounded | |
| Cycle Life | | ≥6000 (25±2°C 0.5C 90%DOD 70%EOL) | |
| Country of Manufacture | | China | |
| Standard and Certification | Safety | IEC62619, IEC60730, EN62477, IEC63056, IEC62040, CE, CEC, Regulation 2023/1542 , VDE2510-50 | |
| | EMC | CE, RCM | |
| | Transportation | UN38.3 ADR | |

*1: Test conditions, 100% DOD (cell 2.85~3.6V voltage range), 0.2P charge & discharge at 25±2 °C for battery system at the beginning of life. Usable energy is defined by its initial design value. Actual available energy may vary depending on charge/discharge rate, environmental conditions (e.g. temperature), transport and storage factors.

*2: Max. Input Power /Max. Output Power/Peak.Output Power derating will occur related to Temperature and SOC.

*3 For single-column stacked installations, the maximum number of parallel units is 6.

9.3 Smart Meter Technical Data

9.3.1 GM330

| | |
|-------------------|-------|
| model | GM330 |
| Measurement Range | |

| | |
|----------------------------------|--|
| model | GM330 |
| Supported Grid Types | 1P2W/3P3W/3P4W |
| Operating voltage (Vac)* | 3P4W: 100~472 L-N 3P3W: 100~472 L-L |
| Frequency (Hz) | 50/60 |
| CT ratio | nA: 5A |
| Accuracy Parameters | |
| voltage/current | Class 0.5 |
| Active Energy | Class 0.5 |
| Reactive Energy | Class 1 |
| Communication Parameters | |
| Communication Method | RS485 |
| Communication Distance (m) | 1000 |
| General Parameters | |
| Dimensions (W*H*D mm) | 72*85*72 |
| Housing | 4-module |
| Weight (g) | 240 |
| Mounting Method | DIN Rail |
| User Interface | 4 LEDs, Reset Button |
| Power Consumption (W) | < 5 |
| Environmental Parameters | |
| IP Rating | IP20 |
| Operating Temperature Range (°C) | -30~+70 |

| | |
|------------------------------------|--------------|
| model | GM330 |
| Storage Temperature Range (°C) | -30+70 |
| Relative Humidity (non-condensing) | 0-95% |
| Max. Operating Altitude (m) | 3000 |

*Supports 1.1 times voltage access.

*The standard CT for the meter has been uniformly updated to the 120A:40mA specification. Meters equipped with the 200A:50mA specification CT will no longer be sold after June 2026.

9.3.2 GMK330

| | |
|---------------------------------|--------------------------------------|
| model | GMK330 |
| Measurement Range | |
| Supported Grid Types | 1P2W/3P3W/3P4W |
| Operating voltage (Vac)* | 3P4W: 90~264 L-N 3P3W: 90~264 L-L |
| Frequency (Hz) | 50/60 |
| CT ratio | 120A: 40mA 200A: 50mA* |
| Number of CTs | 3 |
| Accuracy Parameters | |
| voltage/current | Class 0.5 |
| Active Energy | Class 0.5 |
| Reactive Energy | Class 1 |
| Communication Parameters | |
| Communication Method | RS485 |

| | |
|------------------------------------|----------------------|
| model | GMK330 |
| Communication Distance (m) | 1000 |
| General Parameters | |
| Dimensions (W*H*D mm) | 72*85*72 |
| Housing | 4-module |
| Weight (g) | 240 |
| Mounting Method | DIN Rail |
| User Interface | 4 LEDs, Reset Button |
| Power Consumption (W) | < 5 |
| Environmental Parameters | |
| IP Rating | IP20 |
| Operating Temperature Range (°C) | -30+70 |
| Storage Temperature Range (°C) | -30+70 |
| Relative Humidity (non-condensing) | 0-95% |
| Max. Operating Altitude (m) | 3000 |

*Supports 1.1 times rated voltage connection.

*The standard CT for the meter has been uniformly changed to the 120A:40mA specification. Meters equipped with CTs of the 200A:50mA specification will no longer be sold after June 2026.

9.4 Smart Dongle Technical Data

9.4.1 WiFi/LAN Kit-20

| technical parameter | | WiFi/LAN Kit-20 |
|----------------------------------|---------------------------|---|
| Output Voltage (V) | | 5 |
| Power Consumption (W) | | ≤2 |
| Communication Interface | | USB |
| Communication Parameters | Ethernet | 10M/100Mbps Auto-negotiation |
| | Wireless | IEEE 802.11 b/g/n @2.4 GHz |
| | Bluetooth | Bluetooth V4.2 BR/EDR and Bluetooth LE Standard |
| Mechanical Parameters | Dimensions (W×H×D mm) | 48.3*159.5*32.1 |
| | Weight (g) | 82 |
| | Ingress Protection Rating | IP65 |
| | Mounting Method | USB Port Plug and Play |
| Operating Temperature Range (°C) | | -30~+60 |
| Storage Temperature Range (°C) | | -40~+70 |
| Relative Humidity | | 0-95% |
| Max. Operating Altitude (m) | | 4000 |

9.4.2 4G Kit-G20

| Product Model | 4G Kit-G20 |
|-------------------------------------|--|
| Device Management | |
| Maximum Supported Inverter Quantity | 1 |
| Power Parameters | |
| Input Voltage (V) | 5 |
| Power Consumption (W) | ≤5 |
| Interface Method | USB |
| Communication Parameters | |
| 4G/3G/2G | LTE-FDD: B1/2/3/4/5/7/8/12/13/18/19/20/25/26/28/66 LTE-TDD: B34/38/39/40/41 WCDMA: B1/2/4/5/6/8/19 GSM/EDGE: B2/3/5/8 |
| GNSS Positioning | / |
| Bluetooth | Bluetooth V5.0 |

| Product Model | 4G Kit-G20 |
|--|---|
| Mechanical Parameters | |
| Dimensions (Width × Height × Thickness mm) | 48.3*328*32.3 (Including external antenna) |
| Weight (g) | 100 (Including external antenna) |
| indicator | LED* 2 |
| Mounting Method | Plug and Play |
| SIM Card Size | Micro sim, 15mm*12mm |
| Environmental Parameters | |
| Operating Temperature Range (°C) | -30~+65 |
| Storage Temperature Range (°C) | -40~+70 |
| Relative Humidity | 0-100% |
| IP Rating | IP66 |
| Max. Operating Altitude (m) | 4000 |
| Standards Met | |
| Certification | CE-RED (EN18031), RCM |

10 Appendix

10.1 FAQ

10.1.1 How to conduct auxiliary detection for smart meters/CT?

The meter detection function can detect whether the meter CT is connected correctly and the current operating status of the meter and CT.

1. Navigate to the detection page via **[Home]** > **[Settings]** > **[Meter/CT Auxiliary Detection]**.
2. Click Start Detection, wait for the detection to complete, and then view the detection results.

10.1.2 How to Upgrade the Device Version

Through firmware information, you can view or upgrade:

The inverter's DSP version, ARM version, communication module software version, battery's BMS version, DCDC version, etc.

- **Prompt Upgrade:**

When the user opens the App, an upgrade prompt pops up on the home page. The user can choose whether to upgrade. If they choose to upgrade, they can complete the upgrade by following the on-screen instructions.

- **Regular Upgrade:**

Go to **[Home]** > **[Settings]** > **[Firmware Information]** to enter the firmware information viewing interface.

Click "Check for Updates". If a new version is available, complete the upgrade by following the on-screen instructions.

- **Forced Upgrade:**

The App pushes upgrade information. The user must upgrade according to the prompts; otherwise, the App cannot be used. Complete the upgrade by following the

on-screen instructions.

Inverter Software Version Upgrade

- The inverter supports software upgrade via a USB drive.
- Before using a USB drive to upgrade the device, please contact the after-sales service center to obtain the software upgrade package and upgrade method.

10.2 Explanation of Terms

- **Definition of Overvoltage Categories**
 - **Overvoltage Category I:** Equipment connected to circuits where measures are taken to limit transient overvoltages to a suitably low level.
 - **Overvoltage Category II:** Energy-consuming equipment supplied from a fixed electrical installation. This category includes appliances, portable tools, and other household and similar loads. If special requirements for reliability and suitability of such equipment exist, Overvoltage Category III applies.
 - **Overvoltage Category III:** Equipment in fixed electrical installations where special requirements for reliability and suitability must be met. This includes switching devices in fixed installations and industrial equipment permanently connected to fixed electrical installations.
 - **Overvoltage Category IV:** Equipment used at the origin of the electrical installation. This includes meters and primary overcurrent protection devices, etc.
- **Definition of Damp Location Categories**

| Environmental Parameters | Level | | |
|--------------------------|-----------|-------------|------------|
| | 3K3 | 4K2 | 4K4H |
| Temperature Range | 0~+40°C | -33~+40°C | -33~+40°C |
| Humidity Range | 5% to 85% | 15% to 100% | 4% to 100% |

- **Definition of Environmental Categories:**
 - **Outdoor Inverter:** Ambient air temperature range from -25°C to +60°C, suitable for Pollution Degree 3 environments.
 - **Indoor Type II Inverter:** Ambient air temperature range from -25°C to +40°C, suitable for Pollution Degree 3 environments.
 - **Indoor Type I Inverter:** Ambient air temperature range from 0°C to +40°C,

suitable for Pollution Degree 2 environments.

• **Definition of Pollution Degree Categories**

- **Pollution Degree 1:** No pollution or only dry, non-conductive pollution.
- **Pollution Degree 2:** Normally only non-conductive pollution occurs. Temporary conductivity caused by condensation must be expected occasionally.
- **Pollution Degree 3:** Conductive pollution occurs, or dry non-conductive pollution becomes conductive due to condensation.
- **Pollution Degree 4:** Persistent conductive pollution occurs, for example, due to conductive dust, rain, or snow.

10.3 Battery SN Code Meaning

*****2388*****
 └─┘

The 11th-14th digits

LXD10DSC0002

The 11th to 14th digits of the product SN code represent the production time code. The production date in the above image is 2023-08-08

- The 11th and 12th digits are the last two digits of the production year, e.g., 2023 is represented as 23;
- The 13th digit is the production month, e.g., August is represented as 8; Details are as follows:

| Month | Jan-Sep | Oct | Nov | Dec |
|------------|---------|-----|-----|-----|
| Month Code | 1~9 | A | B | C |

- The 14th digit is the production date, e.g., the 8th day is represented as 8; Numbers are preferred for representation, e.g., 1~9 represent the 1st to 9th days, A represents the 10th day, and so on. Among them, the letters I and O are not used to avoid confusion. Details are as follows:

| Production Day | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|----------------|---|---|---|---|---|---|---|---|---|
|----------------|---|---|---|---|---|---|---|---|---|

| | | | | | | | | | |
|------|---|---|---|---|---|---|---|---|---|
| Code | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|------|---|---|---|---|---|---|---|---|---|

| | | | | | | | | | |
|-----------------|----|----|----|----|----|----|----|----|----|
| Production Date | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 |
|-----------------|----|----|----|----|----|----|----|----|----|

| | | | | | | | | | |
|------|---|---|---|---|---|---|---|---|---|
| Code | A | B | C | D | E | F | G | H | J |
|------|---|---|---|---|---|---|---|---|---|

| | | | | | | | | | |
|-----------------|----|----|----|----|----|----|----|----|----|
| Production Date | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 |
|-----------------|----|----|----|----|----|----|----|----|----|

| | | | | | | | | | |
|------|---|---|---|---|---|---|---|---|---|
| Code | M | N | P | Q | R | S | T | U | V |
|------|---|---|---|---|---|---|---|---|---|

11 Contact Information

GoodWe Technologies Co., Ltd.
90 Zijin Road, Suzhou New District, China
400-998-1212
www.goodwe.com
service@goodwe.com